



# Installation Instruction

Item No.: V04-35




## Replacement parts



## Part List

| NO. | Draw                                   | QTY | NO. | Draw                                | QTY |
|-----|--|-----|-----|-------------------------------------|-----|
| A   | Screws $\phi 4 \times 14 \text{mm}$    | 34  | H   | Bracket (19x19x35mm)                | 2   |
| B   | Two-in-one connector                   | 27  | I   | I-L Track                           | 1   |
| C   | Two-in-one connector                   | 27  | J   | U-Shaped plastic                    | 1   |
| D   | Wood plug                              | 2   | K   | Screws $\phi 4 \times 20 \text{mm}$ | 6   |
| E   | Plastic anchor ( $\phi 10 \text{mm}$ ) | 2   | L   | Screws $\phi 4 \times 10 \text{mm}$ | 7   |
| F   | Screws for fix on the wall             | 2   | M   | Anti-collision gasket               | 2   |
| G   | Bracket (53x70x44mm)                   | 2   | N   | Screwdriver                         | 1   |

## Recommended tools You Will Need-Outils Requis




Power drill



Silicone




Screwdriver








Hammers



# Step 1





Note: Follow the holes positions exactly.




-  I-L I-R x1
-  I
-  (Ø4 x 14mm) x6
-  A
-  N




# Step 3




-  B x8
-  C x8
-  D x1
-  N





# Step 2




-  B x3
-  C x3
-  N

# Step 4




-  B x8
-  C x8
-  D x1
-  N









Notes: Screw installation depth as shown


Attention: The lock handle arrow points to the side face.




### Step 5








-  x2
-  x2
-  (Ø4 x 14mm) x20
-  x20
-  Tool








### Step 7




-  Tool
-  (Ø4 x 14mm) x4
-  (Ø4 x 20mm) x6
-  (Ø4 x 10mm) x7
-  x1

### Step 6




-  x8
-  x8
-  x8
-  Tool

### Step 8



Note: stuck the rear holes.

Step 9




- (Ø4 x 14mm) x4
- A
- Tool



Note: The bottom of the rail is fixed with screw A

Note: The rails adjust their height 3mm.


Step 12



Step 10



Step 11



- x2
- E
- Tool

Finished

