


















ASSEMBLY INSTRUCTION















ASSEMBLY INSTRUCTION



Part List


<div>A1</div> <div></div> <div>Legs-2pcs</div>	<div>A2</div> <div></div> <div>Leg-1pc</div>	<div>A3</div> <div></div> <div>Leg-1pc</div>
<div>B1</div> <div></div> <div>Panel(FB)-1pc</div>	<div>B2</div> <div></div> <div>Wood Bar(HB)-1pc</div>	<div>B3</div> <div></div> <div>Panel(HB)-1pc</div>
<div>B4</div> <div></div> <div>Wood Bar(HB)-1pc</div>	<div>B5</div> <div></div> <div>Wood Bar(HB)-1pc</div>	<div>B6</div> <div></div> <div>Top Rail(HB)-1pc</div>
<div>B7</div> <div></div> <div>Top Rail(HB)-1pc</div>	<div>B8</div> <div></div> <div>Back Rail(HB)-1pc</div>	<div>C1</div> <div></div> <div>Side Rails-2pcs</div>
<div>C2</div> <div></div> <div>Side Rails-2pcs</div>	<div>C3</div> <div></div> <div>Support Side Rails-2pcs</div>	<div>D</div> <div></div> <div>Slats-10pcs</div>

Hardware List

1	 Screws 1/4" x80 4pcs	2	 Screws 1/4" x50 1pc	3	 Ø10 x 40 mm Wood dowel 11pcs
4	 M4 x 50 mm Wood Screws 1pc	5	 M4 x 30 mm Wood Screws 20pcs	6	 Allen Key 1pc
7	 M4 x 40 mm Wood Screws 7pcs	8	 Ø1/4" x 25 mm Hex-Head bolts 8pcs	9	 Ø1/4" x 15 mm Canopy head though -8pcs
10	 Ø1/4" x 30 mm Hex-Head bolts 2pcs	11	 Ø1/4" x 100 mm Hex-Head bolts 8pcs	12	 Ø1/4" x 13 mm Horizontal-Hole bolts 8pcs


STEP 1: Following below illustration ::

-Using hardware #1,#2 and Dowel 3 connect B2,B5,B6 Wood Bars and B3 panel with A2,A3 Legs




STEP 2: Following below illustration ::

-Using hardware #4,#7 connect B8 Wood Bars a with Frame (completed on step 1)




STEP 3: Following below illustration .:

-Using hardware #7 and Dowel 3 connect B7 Top Rail with Frame (completed on step 2)



3



1pc

7




3pcs

7



2pcs




STEP 4: Following below illustration .:

-Using hardware #7 connect B6 Top Rail with Frame (completed on step 3)

STEP 5: Following below illustration .:

-Using hardware #12 connect B1 panel with A1(x2) Legs




10



2pcs

STEP 6: Following below illustration:

.Using hardware #8,#9 and dowel #3 connect Siderail C1,Siderail C2 with Support Siderail C3



8



8pcs

9



8pcs

3






2pcs


07/09

STEP 7: Following below illustration:

Using hardware #11, #12 and dowel #3 to Assembly Frame (completed on step 4, step 5) with siderail Frame (completed on step 6).

Look at detail view for more detail

12	11	3
		
8pcs	8pcs	4pcs



STEP 8: Following below illustration:



-Assembly 10 slat D using hardware #5.

- Look at detail view

5



20pcs



ATTENTION: REMEMBER
TO COMPLETE SCREW
ALL SLATS WITH SIDERAIL
BEFORE USING.