

















ASSEMBLING INSTRUCTION

Ax1 	Bx2 	Cx1 	Dx1 
Ex1 	Fx5 	Gx4 (M8x40mm) 	Jx4 (M6x18mm) 
		Hx1 (M8) 	Kx1 (M6) 

<p>STEP 1:</p>  <p>Diagram showing the five-point base (D) with casters (F) being attached to its legs.</p>	<p>STEP 2:</p>  <p>Diagram showing the cylinder (E) being inserted into the central hole of the base (D). An upward arrow indicates the cylinder's position, and a downward arrow indicates the base being pushed onto it.</p>	<p>STEP 3:</p>  <p>Diagram showing the seat (A) being attached to the base (B). Screws (G) are used to secure the base to the seat. A bracket (H) is also shown being attached to the base.</p>
<p>STEP 4:</p>  <p>Diagram showing the seat cushion (A) being attached to the seat (B) using screws (J) and brackets (K).</p>	<p>STEP 5:</p>  <p>Diagram showing the seat being lowered into its final position on the base, indicated by a downward arrow.</p>	<p>STEP 6:</p>  <p>Diagram showing the fully assembled office chair.</p>