










NOTE:DO NOT TIGHTEN ANY OF THE BOLTS UNTIL IS FULLY ASSEMBLED
ASSEMBLY INSTRUCTION

- #1 SEAT CUSHION (2)
- #2 SEAT FRAME (2)
- #3 SWIVEL (2)
- #4 TOP SUPPORT FRAME (2)
- #5 LEG (2)
- #6 FOOT REST (2)


FOR EASE OF IDENTIFICATION ALL PARTS ARE LABELED TO CORRESPOND TO THE STEP NUMBER IN WHCTH THE PART IS USED




IMPORTANT
 DO NOT TIGHTEN BOLTS COMPLETELY UNTIL ALL BOLTS ARE COMPLETELY LINED UP AND INSERTED INTO HOLES/NUTS
 DO NOT OVER TIGHTEN SCREWS AND BOLTS TO AVOID STRIPPING.

HARDWARE IDENTIFICATION

Please line up the hardware with the correct full size image to make sure you are installing the hardware correctly.




BOLT
A x 8 PCS
Ø1/4" * 1-1/8"




BOLT
B x 24 PCS
Ø1/4" * 5/8"




**SPRING
WASHER**
C x 48 PCS



**FLAT
WASHER**
D x 48 PCS




NUT
E x 16 PCS
Ø1/4"



BOLT
F x 16 PCS
Ø1/4" * 7/8"





**ALLEN
WRENCH**
1 PCS






**OPEN
WRENCH**
1 PCS

STEP 1.
X2








DO NOT OVER TIGHTEN SCREWS
AND BOLTS TO AVOID STRIPPING.

B		8PCS
C		8PCS
D		8PCS



STEP 2.
X2

DO NOT OVER TIGHTEN SCREWS
AND BOLTS TO AVOID STRIPPING.



B		4PCS
C		4PCS
D		4PCS



STEP 3.
X2



F		4PCS
C		4PCS
D		4PCS
E		4PCS


STEP 4.
X2

UP OF THE STEEL SEAT FRAME CONNECTED WITH THE SEAT CUSHION (#2).
DOWN OF THE STEEL SEAT FRAME CONNECTED WITH THE SWIVILE (#3).






F		4PCS
C		4PCS
D		4PCS
E		4PCS


STEP 5.
X2



DO NOT OVER TIGHTEN SCREWS
AND BOLTS TO AVOID STRIPPING.
IT IS NOT RECOMMENDED TO USE
A POWERFUL ELECTRIC TOOL.

A		4PCS
C		4PCS
D		4PCS

STEP 6.
X2



PLACE BAR STOOL ON A FLAT &
LEVEL SURFACE, THEN FASTEN
ALL THE BOLTS.
DO NOT TIGHTEN BOLTS COMPLETELY
UNTILL ALL BOLTS ARE COMPLETELY
LINE UP AND INSERTED INTO HOLES/NUTS.