


# Storage Cabinet



## WARNING

Serious or fatal injury may occur from unexpected assembly or use.

1. During the assembly process, keep all parts away from babies or children.
2. Always securely fix this product to the wall. Make sure the wall area to be drilled is free from hidden electrical wires, water and gas pipes.
3. Use of tip-over restraints may only reduce, but not eliminate the risk of tip-over.
4. Unless specially designed to accommodate, do not set heavy objects on top of this product.
5. Place the heaviest items on the lowest shelf.
6. Never allow children to climb or bang on drawers, doors or shelves.


## WARNING







**Children have died from furniture tipover. To reduce the risk of furniture tipover:**

- **ALWAYS** install tipover restraint provided.
- **NEVER** allow children to stand, climb or hang on drawers, doors, or shelves.
- **NEVER** open more than one drawer at a time.
- **Place heaviest items in the lowest drawers.**

# Parts List (EN) / Teile Liste (DE)












# Parts List (EN) / Teile Liste (DE)







<p>①</p> <p>1500*400*15mm</p> <p>1PC</p>	<p>②</p> <p>440*335*15mm</p> <p>1PC</p>
<p>③</p> <p>440*335*15mm</p> <p>1PC</p>	<p>④</p> <p>250*370*15mm</p> <p>2PCS</p>
<p>⑤</p> <p>1370*384*15mm</p> <p>1PC</p>	<p>⑥</p> <p>150*370*15mm</p> <p>2PCS</p>
<p>⑦</p> <div style="display: flex; justify-content: space-around;"> <div style="text-align: center;"> <p>one side</p> <p>1370*384*15mm</p> </div> <div style="text-align: center;"> <p>the other side</p> </div> </div> <p style="text-align: right;">1PC</p>	
<p>⑧</p> <p>441*243*15mm</p> <p>3PCS</p>	<p>⑨</p> <p>555*50*25mm</p> <p>1PC</p>














# Parts List (EN) / Teile Liste (DE)



<p>⑩</p>  <p>555*50*25mm</p> <p>1PC</p>	<p>⑪</p>  <p>555*50*25mm</p> <p>1PC</p>
<p>⑫</p>  <p>555*50*25mm</p> <p>1PC</p>	<p>⑬</p>  <p>1376*156*3mm</p> <p>1PC</p>
<p>⑭</p>  <p>1376*256*3mm</p> <p>1PC</p>	




# Hardware List (EN) / Teile Liste (DE)







<p><b>A</b></p>  <p>Ø15*9mm 36PCS</p>	<p><b>B</b></p>  <p>Ø6*29mm 36PCS</p>	<p><b>C</b></p>  <p>Ø8*30mm 14PCS</p>	<p><b>D</b></p>  <p>M4*20mm 3PCS</p>
<p><b>E</b></p>  <p>Ø28mm 3PCS</p>	<p><b>F</b></p>  <p>Ø3*15mm 66PCS</p>	<p><b>G</b></p>  <p>Ø26mm 6PCS</p>	<p><b>H</b></p>  <p>Ø8*50mm 2PCS</p>
<p><b>I</b></p>  <p>215mm 3PCS</p>	<p><b>J</b></p>  <p>Ø20mm 36PCS</p>	<p><b>K</b></p>  <p>11*11*15mm 16PCS</p>	<p><b>L</b></p>  <p>115mm 2PCS</p>
<p><b>M</b></p>  <p>29*14*9mm 3PCS</p>			

# Assembly (EN) / Montageschritte (DE)

## CAM BOLT INSTALLATION AS BELOW:





## STEP 1






B \* 8PCS



# Assembly (EN) / Montageschritte (DE)




## STEP 2



	B * 4PCS
	C * 2PCS
	A * 4PCS


## STEP 3






	B * 4PCS
	C * 2PCS
	A * 4PCS


# Assembly (EN) / Montageschritte (DE)


## STEP 4



	M * 3PCS
	F * 6PCS
	B * 8PCS


## STEP 5






	B * 4PCS
---	----------

# Assembly (EN) / Montageschritte (DE)


## STEP 6




	C * 6PCS
	A * 8PCS




## STEP 7



	A * 4PCS
---	----------


# Assembly (EN) /Montageschritte (DE)

## STEP 8



Thin back board needs to be inside the slot, otherwise blocks the opposite plate montage.


## STEP 9





A \* 4PCS


# Assembly (EN) /Montageschritte (DE)



## STEP 10



	F * 8PCS
	L * 2PCS


## STEP 11




	H * 2PCS
	A * 4PCS

# Assembly (EN) / Montageschritte (DE)

## STEP 12





Thin back board needs to be inside the slot, otherwise blocks the opposite plate montage.



C \* 4PCS


## STEP 13





B \* 8PCS


# Assembly (EN) /Montageschritte (DE)



## STEP 14



	A * 8PCS
	J * 36PCS


## STEP 15






	F * 12PCS
	G * 6PCS


# Assembly (EN) / Montageschritte (DE)



## STEP 16



	D * 3PCS
	E * 3PCS
	F * 12PCS


## STEP 17





	F * 12PCS
	I * 3PCS

# Assembly (EN) /Montageschritte (DE)

## STEP 18



	K * 16PCS
	F * 16PCS

## STEP 19

