


Assembly Instructions




Before Assembly

Tips Before Your Start:


- Remove all wrapping material, including staples & packing straps before you start to assemble.
- DO NOT tighten all screws and bolts until the assembly is completely assembled.
- Keep all hardware parts out of reach of children.

QUICKFIT



Tighten quickfit until shoulder is flush with panel. Do not overtighten or undertighten.


CAM LOCK



When fitting a cam lock, ensure the starting position is correct before inserting the connecting QUI CKFIT

Quickfit head should be in the centre of the cam lock when the two panels are joined.

Cam lock should be inserted before quickfit.





Turn cam lock clockwise to tighten.


Before Assembly

Tips Before Your Start


How to separate the drawer slider:



Drawer Front Alignment
















If the drawer front panel is NOT level after being assembled, then...




Loosen the screws on the left and right hand side, then adjust the drawer slide up or down, until the drawer fronts are even/level, then tighten the screws.


Part List

<p>No. A Quantity:52 Pcs Cam Lock Dowel 8*28mm</p> 	<p>No. B Quantity:52 Pcs Cam Ø15</p> 	<p>No. C Quantity:52 Pcs Sticker Ø20</p> 	<p>No. D Quantity:10 Pcs Dowel 8*30mm</p> 
<p>No. E Quantity:3 Sets Drawer Slider 10"</p> 	<p>No. F Quantity:24 Pcs Screw M3.5*12mm</p> 	<p>No. G Quantity:12 Pcs Screw M3.5*25mm</p> 	<p>No. H Quantity:12 Pcs Screw M4*30mm</p> 
<p>No. I Quantity:3 Pcs Handle</p> 	<p>No. J Quantity:6 Pcs Screw M4*20mm</p> 	<p>No. K Quantity:4 Pcs Foot Pad Ø15</p> 	<p>No. L Quantity:6 Sets Plastic Wedge</p> 
<p>No. M Quantity:1 Sets Anti-falling Parts</p> 			

Product structure




STEP 1



No. A
Quantity: 8 Pcs
8*28mm




STEP 2



No. A
Quantity: 8 Pcs
8*28mm




STEP 3



No. B
Quantity: 4 Pcs
Ø15




No. D
Quantity: 4 Pcs
8*30mm



STEP 4


Note: The part with the number "7" needs to be divided into front and back, with the shorter side of the pilot hole facing forward.




No. G
Quantity: 12 Pcs
M3.5*25mm




STEP 5



The first screw hole should correspond with the board location hole




No. E
Quantity: 3 Sets
10"



No. F
Quantity: 12 Pcs
M3.5*12mm




STEP 6




No. B
Quantity: 4 Pcs
Ø15



STEP 7




STEP 8




No. B
Quantity: 4 Pcs
Ø15




No. D
Quantity: 2 Pcs
8*30mm



STEP 9




STEP 10




No. B
Quantity: 4 Pcs
Ø15



No. D
Quantity: 2 Pcs
8*30mm




STEP 11



No. A
Quantity: 8 Pcs
8*28mm




STEP 12



No. A
Quantity: 4 Pcs
8*28mm



STEP 13




No. B
Quantity: 4 Pcs
Ø15



Pay attention to this step when assembling, the hole positions on the side need to be kept on the same side.


STEP 14




No. B
Quantity: 8 Pcs
Ø15



No. D
Quantity: 2 Pcs
8*30mm




STEP 15



No. K
Quantity: 4 Pcs
Ø15




STEP 16



No. A
Quantity: 24 Pcs
8*28 mm




No. I
Quantity: 3 Pcs
Handle




No. J
Quantity: 6 Pcs
M4*20mm




STEP 17



No. H
Quantity: 12 Pcs
M4*30mm




STEP 18




No. B
Quantity: 6 Pcs
Ø15



STEP 19



STEP 20




No. B
Quantity: 18 Pcs
Ø15



STEP 21




The first screw hole should correspond with the board location hole



× 3


No. E
Quantity: 3 Sets
10"





No. F
Quantity: 12 Pcs
M3.5*12mm



STEP 22




STEP 23




Description: Insert the thinner end of the reinforcement into the gap in this back panel, then tighten the screws. This will make the cabinet more stable.






No. L
Quantity: 6 Sets




STEP 24



STEP 25



No. M
Quantity: 1 Sets



Note:
Please lift up the furniture by two people when moving is needed. Dragging may cause the legs failure.