

Bucket cabinet

Assembly Instructions



Dimensions

Width - 120CM

Depth - 40CM

Height - 85CM

Important – Please read these instructions fully before starting assembly




Safety and Care Advice

Important – Please read these instructions fully before starting assembly

- Check you have all the components and tools listed on the following pages.
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts could choke if swallowed.
- Make sure you have enough space to layout the parts before starting.

- During assembly do not stand or put weight on the product, this could cause damage.
- Assemble the item as close to its final position (in the same room) as possible.
- Assemble on a soft level surface to avoid damaging the unit or your floor.
- Parts of the assembly will be easier with 2 people.



- To reduce the likelihood of damaging your product please ensure that your power drill is set on a low torque setting.

Care and maintenance



- Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.
- From time to time check that there are no loose screws on this unit.
- This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Handy Hints

- Assemble all parts and bolts loosely during assembly, only once the product is complete should you fully tighten the bolts
- Regularly check and ensure That all bolts and fittings are tightend properly.



WARNING


























Children have died from furniture tipover.
To reduce the risk of furniture tipover:
-ALWAYS install Anti-tip device provided.
-NEVER put a TV on this product.
-NEVER allow children to stand climb or hang on any drawers, doors, or shelves.
-NEVER open more than one drawer at a time.
-Place heaviest items in the lowest drawers.

This is a permanent label.

Do not remove!

Components - Panels



















Please check you have all the panels listed below


<p>①</p>  <p>1 PC</p>	<p>②</p>  <p>1 PC</p>	<p>③</p>  <p>2 PCS</p>	<p>④</p>  <p>2 PCS</p>	<p>⑤</p>  <p>1 PC</p>
<p>⑥</p>  <p>1 PC</p>	<p>⑦</p>  <p>1 PC</p>	<p>⑧</p>  <p>1 PC</p>	<p>⑨</p>  <p>1 PC</p>	<p>⑩</p>  <p>1 PC</p>
<p>⑪</p>  <p>1 PC</p>	<p>⑫</p>  <p>1 PC</p>	<p>⑬</p>  <p>1 PC</p>	<p>⑭</p>  <p>1 PC</p>	<p>⑮</p>  <p>6 PCS</p>
<p>⑯</p>  <p>6 PCS</p>	<p>⑰</p>  <p>6 PCS</p>	<p>⑱</p>  <p>8 PCS</p>	<p>⑲</p>  <p>6 PCS</p>	<p>⑳</p>  <p>2 PCS</p>
<p>㉑</p>  <p>2 PCS</p>	<p>㉒</p>  <p>2 PCS</p>	<p>㉓</p>  <p>2 PCS</p>		

Components - Fittings


Please check you have all the panels listed below

Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

A  Male Camlock x 72	B  Female Camlock x 72	C  Dowel x 12
D  Drawer slider 14" X 8	E  3*12mm Screw x 64	F  4*30mm Screw x 32
G  3*17mm Screw x 12	H  Plastic wedge x12	I  Protective Feet x 12
J  Handle & Fixings x 6	K  6.8*48mm Screw x 8	L  Ø20 Sticker x 44
M  Socket x1	N  3.5*14mm Screw x 2	O  Light Strip x 1
P  Wall Fixing Pack x 2	Q  Glue Thread Clasp x 2	 M4 x 1




Tools required



Phillips screwdriver
(medium & large)

Ruler - Use this ruler to help correctly identify the screws



The screws length is measured from the head to the point (35mm screw shown).


Using Camlocks

Step 1

Connect the male camlock as directed in the assembly instructions using a screwdriver.

1


DO NOT OVER TIGHTEN.
NE PAS SERRER EXCESSIVEMENT.



Step 2

Push the male camlock into the entry hole.

2




Step 3

Insert the female camlock as shown in the instruction.

Note: ensure that the arrow on the top of the camlock points towards the entry hole for the male camlock.

3




Step 4

Turn the female camlock clockwise with a screwdriver.


You should feel a click when the camlock is locked in place.

The joint is now secure.

4




Assembly Instructions




Assembly Instructions

Step 1




Step 2




Assembly Instructions

Step 3



Step 4





Assembly Instructions

Step 5

B



B x 2





Step 6

B



B x 4





Assembly Instructions

Step 7

B



B x 2




Step 8

A




A x 10





Assembly Instructions

Step 9




Step 10



Assembly Instructions


Step 11




B



B x 4



Step 12




K




K x 4

Assembly Instructions

Step 13




Step 14




Assembly Instructions

Step 15





Step 16




Assembly Instructions

Step 17



Step 18




Assembly Instructions

Step 19

A



A x 4



Step 20

A




A x 2

C





C x 6





Assembly Instructions

Step 21




Step 22



Assembly Instructions


Step 23



A
A x 6



K
K x 4

Step 24





O
R x 1

Q
Q x 1




Assembly Instructions

Step 25





Step 26





Assembly Instructions

Step 27




Step 28




Assembly Instructions

Step 29



X6



Step 30






X6

Assembly Instructions

Step 31



Step 32




Assembly Instructions

Step 33

A



A x 8





Step 34

B




B x 8




Assembly Instructions

Step 35





Step 36





Assembly Instructions

Step 37




Step 38





Assembly Instructions


Step 39



Step 40




L X18



L x18

Assembly Instructions

Step 41



G





G x 12


H



H x 12





Step 42



Q



Q x 1



Assembly Instructions

Step 43

P



P x 2

The unit is floor standing, but it is recommended that the unit is secured to the wall.



1. Move the unit into desired position.
2. Mark the wall with a suitable scribe the position of the fixing holes.



Warning:
Before drilling, check wall for hidden pipes and cables.

3. Drill holes and insert 2 x wall plug
4. Attach 2 x Wall Straps to the top of the unit using 2 x Washers and 2 x Screws
5. Secure the straps to the wall using 2 x Washers and 2 x Screws

Note: To hide the straps behind the unit, drill the



Assembly is complete.

Assembly Instructions

Step 44



LED mobile phone Bluetooth controller
For details, please see the
attached below manual

LED mobile phone Bluetooth controller

Scan QR code download APP

1. Connect LED color strip and controller,
power on controller
2. Scan QR code download APP:



3. Start APP, search and connect controller
4. Enjoy the Bluetooth wireless control experience

LED mobile phone Bluetooth controller

Product Features

.LED Bluetooth controller is directly via mobile phone control
remote distance can reach 10m without the need to set up, easy to
connect open the software within 5 seconds you can automatically
connect the controller

.Flow the rhythm of the music changes

.Group control

.Brightness, speed addition and subtraction

.Maximum can be 5 meters RGB(W) strip

.The software shows that the text is based on the language of the
mobile phone set up automatic transformation of Chinese and
English

Animation Effect:

.Colorful gradient

.All kinds of monochrome , double color gradient

.All kinds of monochrome, double color , colorfull flashing

.Colorful jump

.Follow the thymh of the music chagnes

Product Paramters:

.Bluetooth: BLE V4 .2

.Input Voltage: 4.5-26V

.Working Temp: -25- 75°C

.Size: 43*22 *11mm

.Weight: 30g

.Max Power : 144W(24V)

A Guide to Wall Mounting & Fixings

Important note:

If plastic wall plugs (rawl plugs) are supplied with your product, e.g.:



- these are only suitable for use in masonry walls.

If you are in any doubt about the correct wall plugs for your wall, seek professional advice.


Failure of the product due to using the incorrect fixings is the responsibility of the installer.



Important: when drilling into walls always check that there are no hidden wires or pipes etc.

Make sure that the screws and wall plugs being used are suitable for **supporting your unit**. **Consult a qualified tradesperson if you are unsure.**


Hints:

- 1: General rule:  always use a larger screw and wall plug if you are not sure.
- 2: Ensure you use the recommended drill bit to match the wall plug and hole size.
- 3: Ensure you drill the hole horizontally; do not force the drill or enlarge the hole.
- 4: Take extra care when drilling high walls, ceilings and ceramic tiles. Ensure wall plugs are inserted beyond the thickness of the ceramic tiles to avoid the tiles splitting or cracking.
- 5: Ensure wall plugs are well fitted and are a tight fit in the drilled hole.

Types of walls


You can use one of the following types of wall plug if your walls are made of brick, breeze block, concrete, stone or wood.

No.1 "General Purpose" wall plug




Generally aerated blocks should not be used to support heavy loads, use a specialist fitting in this case. For light loads, general purpose wall plugs can be used.

No.3 "Cavity Fixing" wall plug




For use with plasterboard partitions or hollow wooden doors.

No.5 "Hammer Fixing" wall plug




For use with walls stuck with plasterboard. The hammer fixing allows it to be fixed to the wall rather than the plasterboard. Always check the fixing is secure to the retaining wall.

No.2 "Plasterboard" wall plug




For use when attaching light loads onto plasterboard partitions.

No.4 "Cavity Fixing – Heavy Duty" wall plug



For use when fitting or supporting heavy loads such as shelving, wall cabinets and coat racks.

No.6 "Shield Anchor" wall plug – heavy loads



For use with heavier loads such as TV and HiFi speakers and satellite dishes etc.



Care & Maintenance

Safety: always check the fitting and location to ensure your safety in and around the home.

Fitting: from time to time check the fitting to ensure the wall plugs or screws do not become loose.