EXAMPLE PARTS LIST SEE DELIVERY SET

ID NUMBER		XX	
Building:		8x8 wooden cabin with double doors	
Building Size:	2390x2390(8x8)	please quote ID	
Date:	16-May-11	number in all	
LOG	19mm	correspondence	

0Roof Boards114x12 e -matching1350470Floor Boards114x12 e -matching2150210Floor Bearers $34X62$ PRESSURE TREATED219070NAIL PACK0010NAIL PACK0010Roof Joists NO NOTCHES $3x2$ 259032Roof Edging44X44259024Angled Eaves Edging0259025Fascia95x1914002 sets5skirtingRadius 1 corner225036SkirtingRadius 1 corner45027Window insertW6S-FECONOMY16GoorsES-DD501 PAIR1Jingepiano162520UNTREATED BeadingLONGECONOMY360GlassECONOMY3636
0Floor Boards114x12 e - matching2150210Floor Bearers34X62 PRESSURE TREATED219070NAIL PACK0010NAIL PACK001Roof Joists NO NOTCHES3x225903Roof Edging44X4425902Angled Eaves Edging025902Fascia95x1914002 setsskirtingRadius 1 corner22503skirtingRadius 1 corner4502Window insertW68-IECONOMY1GoorsES-DD501 PAIRhingepiano162520UNTREATED BeadingLONGECONOMY360GlassECONOMY3618
0Floor Bearers34X62 PRESSURE TREATED219070NAIL PACK0010NAIL PACK001Roof Joists NO NOTCHES3x225903Roof Edging44X4425902Angled Eaves Edging025902Fascia95x1914002 setsskirtingRadius 1 corner22503skirtingRadius 1 corner4502Window insertW6S-IECONOMY1doorsES-DD501 PAIRhingepiano162520UNTREATED BeadingLONGECONOMY360GlassECONOMY3618
0NAIL PACK001Roof Joists NO NOTCHES3x225903Roof Edging44X4425902Angled Eaves Edging025902Angled Eaves Edging025902Fascia95x1914002 setsskirtingRadius 1 corner22503skirtingRadius 1 corner4502Window insertW6S-IECONOMY1GoorsES-DD501 PAIRhingepiano162520UNTREATED BeadingLONGECONOMY360GlassECONOMY1268x373
Roof Joists NO NOTCHES $3x2$ 2590 3 Roof Edging $44X44$ 2590 2 Angled Eaves Edging 0 2590 2 Fascia $95x19$ 1400 2 setsskirtingRadius 1 corner 2250 3 skirtingRadius 1 corner 450 2 Window insertW6S-IECONOMY 1 Hamiltonian 1625 2 2 0UNTREATED BeadingLONGECONOMY 36 0GlassECONOMY 36 2
Roof Edging44X4425902Angled Eaves Edging025902Fascia95x1914002 setsskirtingRadius 1 corner22503skirtingRadius 1 corner4502Window insertW6S-IECONOMY1FRAME KITW6S-FECONOMY1doorsES-DD501 PAIRhingepiano162520UNTREATED BeadingLONGECONOMY360GlassECONOMY182
Angled Eaves Edging025902Fascia95x1914002 setsskirtingRadius 1 corner22503skirtingRadius 1 corner4502Window insertW6S-IECONOMY1FRAME KITW6S-FECONOMY1doorsES-DD501 PAIRhingepiano162520UNTREATED BeadingLONGECONOMY360GlassECONOMY3618
Fascia95x1914002 setsskirtingRadius 1 corner22503skirtingRadius 1 corner4502Window insertW6S-IECONOMY1FRAME KITW6S-FECONOMY1doorsES-DD501 PAIRhingepiano162520UNTREATED BeadingLONGECONOMY360GlassECONOMY18268x373
skirtingRadius 1 corner22503skirtingRadius 1 corner4502Window insertW6S-IECONOMY1FRAME KITW6S-FECONOMY1doorsES-DD501 PAIRhingepiano162520UNTREATED BeadingLONGECONOMY360GlassECONOMY3618
skirtingRadius 1 corner4502Window insertW6S-IECONOMY1FRAME KITW6S-FECONOMY1doorsES-DD501 PAIRhingepiano162520UNTREATED BeadingLONGECONOMY360UNTREATED BeadingSHORTECONOMY360GlassECONOMY3618
Window insertW6S-IECONOMY1FRAME KITW6S-FECONOMY1doorsES-DD501 PAIRhingepiano162520UNTREATED BeadingLONGECONOMY360UNTREATED BeadingSHORTECONOMY360GlassECONOMY3618
O UNTREATED Beading LONG ECONOMY 1 0 Glass ES-DD5 0 1 PAIR
InternationalInternationalInternationaldoorsES-DD501 PAIRhingepiano162520UNTREATED BeadingLONGECONOMY0UNTREATED BeadingSHORTECONOMY0GlassECONOMY360GlassECONOMY18
InitialInitialhingepiano162520UNTREATED BeadingLONGECONOMY360UNTREATED BeadingSHORTECONOMY360GlassECONOMY3618
0UNTREATED BeadingLONGECONOMY360UNTREATED BeadingSHORTECONOMY360GlassECONOMY36
0 UNTREATED Beading SHORT ECONOMY 36 0 Glass ECONOMY E- Georgian 268x373 18
0 Glass ECONOMY E- Georgian 18 18
0 LOGS 0 0 SET
0 Knocking Blocks SHORT CUT LOG 0 6
0 Diamonds small 0 2
0 Gables 0 0 2
DOUBLE DOOR KIT
frame kit TAPED SET
FELT
felt 1x10m & 1x6m
Nail bag contents
QTY 60 105 75 0
DESCRIPTION 25 screw 40 screw 50 screw 60 screw
QTY 30 0 315 0
DESCRIPTION 80 screw 75 nail 40 NAIL 25 oval d door only
QTY 245 145 165
DESCRIPTION 40 OVAL panel pin FELT NAIL
door bolts 2
CASEMENT SET 1
NIGHT VENT FASTENER 1
HINGES 8

Instructions inside pack

8x8 wooden cabin with double doors

2390x2390(8x8)

19mm

NO OTHER PARTS REQUIRED CHECK ALL PARTS BEFORE ASSEMBLY OR EMPLOYING TRADESPEOPLE

Instructions inside pack

8x8 wooden cabin with double doors

2390x2390(8x8)

19mm

NO OTHER PARTS REQUIRED CHECK ALL PARTS BEFORE ASSEMBLY OR EMPLOYING TRADESPEOPLE



R8

8x8 wooden cabin with double doors

2390x2390(8x8)

19mm

NO OTHER PARTS REQUIRED CHECK ALL PARTS BEFORE ASSEMBLY OR EMPLOYING TRADESPEOPLE

LOG SHEET

8x8 wooden cabin with double doors

Building: Building Size:

Date:

2390x2390(8x8)

16-May-11

LOG 28mm IMM

Lag	T on oth	Queene4:4	
	Length		
A	2390	37	
Al	2390	2	
A2	2390	1	
A3	2390		
C	465	30	
F	845	24	
J	2590	2	
0	0	0	
0	0	0	
0	0	0	
0	0	0	
0	0	0	
0	0	0	
0	0	0	
0	0	0	
0	0	0	
0	0	0	
0	0	0	
0	0	0	
0	0	0	
0	0	0	
0	0	0	
0	0	0	
	SPA	ARE LOGS	
A	0	2	
C	0	1	
F	0	1	
1	0	1	
222	moof boom		

	2271		
J			
	2590		
	2370		-
F 845	20 INC T	ONGUE	
A3			
	,	2390	
-	4	2390	-
		Δ	
A2			
	75	2390	
	1460		
	2271	465	
	~~ 1 1	D	
	2200		
•	2390		
A1	2300		
	2390		

ID NO

3A2 root bearers

2590	_

SHORT E-DOUBLE DOOR -INNER FRAME ASSEMBLY



SHORT E-DOUBLE DOOR OUTER FRAME ASSEMBLY

PARTS LIST

DC	70x20	1625	4
DD	90x20	1520	4
drip	bar	1520	1
\overline{C}	over strip	o for dooi	<u> </u>
code	size	length	qty
CS	70x20	780	2

TOP





SCREW HERE



8x8 Wooden cabin

Thank you and congratulations on the purchase of your pine lodge. We believe that this product will give you many years of excellent service. This is a natural product manufactured to a high standard therefore if you have any queries or experience any difficulties then please contact our customer service hotline on—



Tools required

- •Hammer
- Rubber mallet
- Spirit level
- Stepladder
- · Battery-powered drill/screwdriver
- •8mm drill
- 3mm drill
- Tape measure
- Gloves
- Sharp knife and saw
- string
- •Oil for lock

IMPORTANT!

1. Check all components before

commencing with the construction of your Cabin

2. Keep all timber dry or your building will not fit together.

3. We also recommend that you seal the corner log joints with silicone sealant (not supplied).

4. We recommend a minimum of two people required for assembly.

5. Read through all the instructions before constructing your pine lodge.
6. You will see there is a set of lettered drawings showing each side of the building. You will find these letters printed at one end of each log or in the slot.

PLEASE NOTE

Wood is a natural product and is therefore prone to changes in appearance, including some warping, movement and splitting, particularly during unusual climatic conditions (long hot or wet spells of weather). As a natural occurrence this is not covered by a guarantee.

Preparation of base

The base onto which you build your Cabin needs to be flat and level. We only recommend you use concrete that is a minimum of 10 cm thick

Base size at least 2190mm x 2190mm

Please refer to section B and drawing pages 1& 2. Please note that the corner joints protrude over the edge of the base.

Treatment/care of your pine lodge

- All timber must be dry to apply the timber treatment.
- Treat with a suitable decorative wood finish immediately. We recommend that you treat the door and window glazing rebates and beading with a top quality timber treatment before assembly and treat the entire building as soon as assembly is complete, we further recommend that all pieces are treated and again within 3 months of assembly and again at least annually or as frequently as the instructions on the product used recommends.
- <u>Note</u> the back of the door and window units unscrew so they can be removed for painting
- We would also remind you that you would rarely (if ever) be able to re-treat the underside of the floor boards following assembly.
- We strongly recommend that the underside of the floor is treated an absolute minimum of twice.
- The floor bearers are pressure treated and don't need to be treated although you may if you wish. We also recommend that you seal the external corner joints (fig E2) with silicone sealant (not supplied)
- <u>LUBRICATE LOCK</u> It is extremely important that you lubricate your lock through the key hole and all moving parts as soon as possible after assembly and at least at monthly intervals thereafter. Also ensure that you regularly operate the lock especially during the winter or when not in use.
- See drawings for log quantities
- See yellow parts list sheet please quote ID number and your order number in all correspondence

IMPORTANT!

The only parts that require cutting are the angled eaves edgings , final roof and floor boards and the skirting. <u>DO NOT CUT ANYTHING ELSE</u> Caledonian Assembly –please thoroughly read and familiarise yourself with the instructions and parts prior to assembly

IMPORTANT SAFETY INFORMATION

- We recommend the wearing of non-slip protective gloves throughout the assembly process. We also recommend the wearing of steel capped protective shoes, protective head gear, safety glasses and full length clothing. If step ladders are to be used we recommend one person holds the ladder whilst the other is using them. If necessary a third person should be used. Do not attempt to erect the building in windy conditions. Follow any safety precautions quoted by the manufacturer for any equipment you use.
- Every precaution has been taken to ensure that your building has no element incorrectly placed or possibly hazardous. However prior to use please check for raised grain or splinters and sand if necessary. Check that all elements are secure against reasonable force.

A Window Frame

- Refer to the window drawing page and to letter codes in contents table. The WT and WD parts will be at the top of the window frame.
- To be sure you can lay all the pieces, including inserts together without fixing to familiarise yourself with the assembly.
- Make sure the window insert fits inside the frame with a 5mm gap all around.
- 4. Lay out the parts WA and WB and WT as in the inner frame assembly drawing. The narrowest (25mm) edge to the work bench and the side the size is the same as the log thickness as shown in fig A1. Part WT must be inside parts
- 5. WA and part WB underneath the two WA parts (Fig A1).
- Pre drill 2 3mm holes at one end of the WA only and at both ends of the WB parts (see drawing)and screw together at each corner,10mm in from the edge (ensuring each corner is flush) with 2x50mm screw (fig A1).



Fig A1



Fig A2

 Layout parts WC ,WD & WE as in fig A2 & drawing on top of the frame from steps 1-6 flush with the inner edge of the frame.



Fig A3

- Mark the first hole position 30mm from the end of part WC <u>that is next to part</u> WD, at the other end mark the hole central to the WB underneath and then the rest at approximately 260mm centres between these holes.
- Note the WC, WD & WE pieces fitted to the opposite side must be drilled offset to this side to ensure the screws miss each other.
- Place the other WC part underneath and drill through both pieces with a 3mm drill (fig A3).



11. Place one of the WC parts on top of the **WA** parts level with the inside of the frame and the bottom of the **WT** part (fig A4).

- 12. Fix to part **WC** to **WA** with 40mm screws (fig A5 & A6)
- important fix at both ends first ensuring that they stay flush then the screws in between again ensuring that parts WA & WC are flush as you go.



Fig A5



Fig A6

14. Place a **WD** part on top of a **WB** part. The **WD** part is positioned so there is an even overhang (fig A7). Mark out and drill fix as steps 8 to 10. But start at 100mm from the end of part **WD**.



Fig A7 15. Drill (not too deep) and screw in each corner with 40mm screws (fig A8).



Fig A8

16/05/2011

- 16. With a pencil mark the screw centres on the inside long edge of the frame to help ensure the hinge screws will miss these screws.
- 17. Turn frame over and repeat steps 4 to 12 on the other side (fig A9 &A10).
- 18. Note offset drilled holes from first side to ensure they miss each other first hole part WC =30mm part WD =100mm



Fig A10

- 20. **Window insert.** Place one hinge on the inner rebate part of the window; approx. One hinge width along from the rebate edge **on the top side**. The rounded part of the hinge should sit above the outer edge of the window. Screw the inner piece into position
- 21. (fig. A11 &A12) using the pre drilled holes in the hinge and 3 x 25mm screws. Repeat with the other hinge. And close the hinges together.



Fig A11– STYLE MAY VARY



Fig 1A12 22. Place the window into the aperture (fig

A13) **ensure that part <u>WD</u>** (FIG A13) is against the hinges (TOP HUNG)<u>or</u> against the **WC** (side hung).

- 23. Secure the window to the panel using 3x 25mm screws per hinge, (fig. A14) again through the predrilled holes in the hinge.
- 24. Repeat.



Fig A13



Fig A14 25. Open the window fully in order to fit a further 2x 25mm screws per hinge (Fig. A15).



Fig A15 26. <u>Fitting the Casement Stays</u>. Place the casement stay evenly on the inside of the window (Fig A16) on top of the draught excluder.

27. Place the 2 pins under each casement stay. Position so that it is not resting on the window frame and not so high that the pins are of no use.



Fig A16 28. Fit the Casement Stay (fig A17) on the window using 2x 25mm screws.



Fig A17 32. Mark where the 'pins' will be placed.



Fig A18 33. Secure into position using 4x 25mm screws - 2 in each pin.



Fig A19

- 34. Latch Along side one of the horizontal bars in the window insert place the side latch on top of the draught excluder. (fig A19)
- Use the pin to correctly place the lever and secure using 2x25mm screws for each part (Fig A19).
- 37. **Drip bar.** Turn the window unit over so the opening insert is uppermost .





- 38. Position the drip bar he drip bar by measuring 45mm down from the top of the WD part above the hinges and fix the drip bar with 3x25mm screws.
- 39. Put the completed unit to one side until required .
- <u>Note</u> do not glaze until all parts have been treated and the units fitted in the building

- 1. Refer to letter codes in the table on the front page.
- Lay out the parts DA and DB as in fig B1 and see drawings
- 3. The 25mm edge to your work surface , Parts **DB** must be inside parts **DA**.
- Screw together at each corner, 10mm in from the edge (ensuring each corner is flush) with 2x50mm screws (fig B2).





Fig B2 5. **REF**. This frame is set out similar to the pre-constructed window frame.



 Mark the first hole position 30mm from each end of part DC and then the rest at approximately 200mm centres. 8. Note the **DC**, **DD & DE** pieces fitted to the opposite side must be drilled offset to this side to ensure the screws miss each other.



Fig B4 9. Place the other **DC** part underneath and drill through both pieces with a 3mm drill (fig B4)



Fig B5 10. Place one of the **DC** parts on top of the **DA** parts level with the inside of the frame (fig B5)



Fig B6 11. Fix to part **DC** to **DA** with 40mm screws (fig B6 &B7) important fix at both ends first ensuring that they stay flush then the screws in between again ensuring that parts DA &DC are flush as you go.



12. Place the **DD** part on top of a **DB** part. The **DD** part is positioned so there is an even overhang (figB8). Mark out and drill fix as before. But start at 100mm from the end of part **DD**.



Fig B8 13. Drill (not too deep) and screw in each corner with 40mm screws (fig B9).





- 14. With a pencil mark the screw centres on the inside long edge of the frame to help ensure the door hinge screws will miss these screws.
- 15. Turn frame over and repeat steps 9 to 14 on the other side (fig B10&B11).
- <u>Note</u> offset drilled holes from first side to ensure they miss each other first hole part DC=40mm part DD 110mm part DC=40mm part DD =110mm







Fig B7

C Doors

- Lay doors on the floor, as you would view them from the inside of the building. Make sure the door with the lock is situated on the left when viewed from the bottom.
- 2. Lay the outer frame in position (fig C1).
- 3. The hinges are fitted on the longest outside edge of the doors.
- Make a visual judgement to the gap top and bottom of the doors then transfer the screw centre marks (see step B <u>14</u>) to the doors. This is to ensure the hinge screws miss the frame screws.
- 5. Lift off the outer frame making note of which way around you have put it.
- Place the hinges as shown in fig C1 Screw the inner piece of the hinge to the door with 3 x 25mm screws.



Fig C1 7. Close the hinges and lay the frame assembly over the doors (fig C2).



 Make a visual judgement to set an even gap top/bottom of the doors and secure each hinge with 1x25mm screws (fig C3). Ensure the hinges are tight against the face of the doorframe.



Fig C3

- Stand the assembly up. Note two people needed for this step. Open the doors and secure hinges with remaining 4x25mm screws per hinge
- 10. Fitting the draught excluder. This must be done before fitting the door bolts.
- 11. Lay the assembled unit with the doors downwards onto your work surface (see Fig A17 window assembly).
- Position the draught strips so the rubber is against the opening insert and fix with 3x25mm oval nails per strip (Fig A17 window assembly).



Fig C4

- Fit two bolts on the door without the lock (fig C4). The top bolt should be positioned just below the draught excluder. Fix with 4x10mm screws.
- 14. Extend the bolt to meet the frame and mark then drill an 8mm hole (not through the frame) to take the bolt.
- 15. Put the door assembly to one side until required.

D Floor bearers & first logs

See drawing pages 1&2

Read the Following the instructions below fully and study the drawing pages before you assemble your building up to and including the gables



Fig D1

- Take four bearers and place them in pairs with the longest faces together and nail at an angle with 4 70mm nails each. These are for the outer bearers.
- 2. Take the half height log (A1) that sit on the bearers so that you see the bearer ends and mark the floor bearer centres, **but not the outer bearers**, from one end (fig D1 & drawing pages



Fig D2

- Place the 'A1' logs against each other and transfer all the lines across (fig D2).
- The bearers stand with the narrowest edge to the floor (fig D3) and their ends level with the A1 logs face. Do not fix until step 11.



Fig D3

- Assemble the first row of logs on top of the bearers by placing the half height (A1)logs in position and then the first of the logs (A) from each wall that run parallel to the bearers on top of them. (See drawing page 1 and section E4).DO NOT FIX YET.
- 6. The logs are assembled with the tongues upwards
- Position the outer bearers so the outer log sits 5mm in from the outer face (fig D3 & D4) of the side log and level with the front and back logs.



Fig D4

 Cut notches out of the tongues on the A1 logs (fig D5 & D6) at centre marks (previous steps) and drill through for fixing to the bearers.

9. Important

10. Measure corner to corner, as building must be square



- 3. The logs are assembled with the tongues upwards
- 4. Each log needs to be tapped home to log below using timber block supplied and a rubber mallet (E2).



<u>UNDER NO CIRCUMSTANCES MUST</u> <u>THE DOOR OR WINDOW FRAMES BE</u> <u>NAILED TO THE LOGS .The logs must be</u> fee to move within the frame lots to allow for expansion and contraction. <u>AS SOON AS</u> <u>YOU FIT DOOR UNIT FIT HANDLES</u> <u>AND UNLOCK DOOR</u>

- Door unit must be placed into position after the first two layers of full logs have been assembled
- Slide unit into aperture from above (Fig F1 & F2) ensuring unit is completely down and in position.



Fig F1 EXAMPLE



Fig F2 3. Window units are fitted as above (fig F3) when you have built up to the correct height



Fig F3 example

- 4. <u>Note</u> Door and window units do not require fixing to the logs
- Once the door and window units are in place continue assembling the walls as before but slide the logs into the door or window frame (fig 54) from above then tap them down.



Fig F4

Continue building until you get to the height were the gable starts.
 7.

G Gables

See drawing pages

- 1. Assemble the gables as with the walls.
- Once gables are in place knock down all the walls again as in fig E2 to ensure all the walls are fully home
- Fix the gable with1x80mm screw at each end (fig G1 and as shown on the drawing pages (Some screws may go into roof joists)

4. 0



Fig G1

H Roof joists

1. Fit roof bearers into slots provided in the gable sections (fig H1 & H2).



Fig H1

- 2. Measure the distance between each roof bearer and the roof bearers and walls to ensure all components are fully home before continuing.
- 3.

Fig H2 example

I Roof boards

- There are eaves edging strips for the building (2 places) (These may need cutting to fit).
- Position the eaves edging strips (fig I1 & I2) level at both ends with the gable angle (front and back walls) and screw to the wall with 50mm screws at approximately 400 centres.



Fig I1



The first roof board is now ready to be positioned (fig I3).Bevals downwards
 NOTE only the final boards need

trimming.



Fig I3

- 5. Start at the front, place the board level with the end of the roof bearers and central over the middle bearer to produce an even overhang (fig I3).
- Fix into place at the roof bearers and angled eaves edgings using two 40mm ROUND HEAD nails at each bearer & eaves edging





- The final roof board will need to be cut. Place it in position and measure the distance between the end of the roof bearers and the edge of the board. This will tell you how much you need to cut off (fig I4).
- 8. Next fit the roof edgings to the outer edges of the roof boards with 50 mm screws at approximately 300mm centres (Fig. I5).



Fig I5

J Felt Roof

- Measure the length of the roof and layout a roll and cut into lengths 20cm longer than the roof.(Fig J1).You can use a board as a straight edge.
- 2. Repeat with all the felt.





- Starting at the lower edge (eaves) place 1 piece from front to back of the building.
- An overhang of approximately 50mm should be allowed at the front and the back (all felt strips) and the length of the eaves edgings at the side (Fig J2 & J3).



Fig J2

 Secure with felt nails at approximately 100mm spacing. But only a couple along the high edge at this time (nailed with overlap).



Fig J3

- 7. Repeat on the other side.
- Place the next piece of felt over the high point of the roof (ridge) overlapping the lower pieces either side then nail as before.
- 15. Nail with felt nails at each roof bearer leaving space for fixing the Fascia's (either side of the ridge).

K Fascia

 Fascia boards can now be drilled and screwed (fig K1) with 1x 50mm screw at each roof bearer and the roof edgings.



Fig K1 2. Drill diamond and screw with 2x50mm screws . (fig K2)



Fig K2

L Floor

- The floor is fitted working from front to back with 40mm nails Bevels downwards.
- Position the first floorboard under the doorframe (Fig L1), with the groove against the wall.



Fig L1 3. Fix into position with two nails at each floor bearer (Fig L2 & L3).



Fig L2



Fig L3

- 4. Continue with remaining floorboards until you have three remaining.
- 5. Place these in position without nailing them down, as the last floorboard will require trimming.
- 6. Measure the distance between the last full board and the wall (Fig L4). This measurement is then marked on the final board and then cut to Fit , **leaving the groove on the board**.



Fig L47. Curl the boards up (fig L5) to put it into position and nail the remaining boards before





 Cut the skirting boards to suit and fix with 40mm oval nails at approx 400mm centres (fig L6)



Fig L6

M Glazing

After painting

- 1. **<u>NOTE</u>** ensure that you have treated the beading and the rebate where the glass fits before fixing the glazing.
- 2. Place glazing material into the aperture of each window.
- Hold into position with four pieces of beading. The beading may need to be swapped around to get the best fit. When satisfied secure into position using 2x15mm panel pins per piece of beading. (fig M1)Repeat for all window and door apertures.



Fig M1







2390x2390(8x8)

or 8x8 wooden cabin with double door <u>19mm</u> <u>FRONT</u> PARTS LIST A1 X 1 A2 X 1 C X 30



page 3

2390x2390(8x8)

or 8x8 wooden cabin wit double door 19mm

> BACK Parts list A x 16 A1 x 1





page 5

2390x2390(8x8)

or 8x8 wooden cabin with double door $\frac{19mm}{RH SIDE}$ PARTS LIST A x 3 A3 x 1 F x 24 J x 1



To build opposite hand just swap logs around



page6

2390x2390(8x8)

or 8x8 wooden cabin with double door <u>19mm</u> <u>ROOF ASSY</u> Parts list 3 Roof bearers 2 Angled eaves edging strips 2 44x44 square roof edgings 46 Roof boards 1350 long