




















<b>A. Backrest-1PC</b> 	<b>H. Footring+Height Adj. Knob</b> 	<b>Step 1</b>  <p>Set the base (E) upside down, insert castors (G). Flip the base (E) upright, insert the pneumatic cylinder (F) into the center hole on the base (E)</p>	<b>Step 2</b>  <p>Attach arms(C) with backrest (A) with screws (I), lock them tightly, then put cover caps (M) on the holes of arms.</p>	<b>Step 3</b>  <p>Then Fix arms (C) to Seating (B) with screws (K).</p>
<b>B. Seating-1PC</b> 	<b>I. Screw-4PCS</b>  M6*25	<b>Step 4</b>  <p>Put mechanism (D) on seating (B) fix it with screws (J), keep the tension knob in the front of seating.</p>	<b>Step 5</b> 	
<b>C. Arms-2PCS</b> 	<b>J. Screw-4PCS</b>  M6*20			
<b>D. Mechanism-1PC</b> 	<b>K. Screw &amp; Washer-4PCS</b>  M6*35  Ø21*1.5			
<b>E. Base-1PC</b> 	<b>L. Allen key-1PC</b> 			
<b>F. Pneumatic Cyinder-1PC</b> 	<b>M. Cap Cover-4PCS</b> 			
<b>G. Cator-5PCS</b> 				

**KEEP THIS PAGE FOR FUTURE REFERENCE.**