

Important

- The vanity must not be exposed to excessive moisture e.g. directly beside a bath or open shower. The materials used in the manufacture of vanities are water resistant **NOT WATER-PROOF**. If the installation is likely to encounter excessive moisture please consult your merchant for further advice.
- **When tiling, do not cut the tiles to fit around the vanity. Pre-tile then place the vanity in front** (the warranty does not cover any costs associated with re-tiling or re-decoration).
- Ensure the water temperature at the tap outlet does not exceed 55°C. **This will void warranty.**
- Do not expose the vanity to solvents. Only use cleaning agents recommended for acrylics.

Tools and Materials

Drill and drill bits	Level	Tape Measure	Caulking gun	
Screws	Screw driver	Pencil	Silicone Sealant	Cleaning materials

Wall Hung Vanity Installation

Important

Wall hung vanities MUST be installed into solid studs and nogs. Additional studs or nogs must be strategically located in the wall for screwing the vanity to. Failure to provide adequate support will void warranty.

1. Inspect that the unit is correct and undamaged.
2. Check that the walls plumb and straight
 - The wall must not be bowed in either the horizontal or vertical plane as this will cause a twist in the cabinet resulting in door & drawer alignment issues and the soft close mechanisms not functioning.
3. Determine the height that vanity will be mounted at. This will depend on the required working height of vanity top surface and clearance requirements between tap ware and any mirrors above the vanity.
4. Place the cabinet into the proposed position (rest the cabinet on firm supports). Mark the positions of any plumbing outlets. Access to the cabinet can be made easy by the removal of the shelf, doors and drawers. Refer to "Removal & Alignment" section. When removing the drawers ensure their positions are recorded as they are not interchangeable.
(Shelf and drawers where applicable)
5. Reposition the cabinet back onto the supports. With a level check that the cabinet is leveled.

6. Using the 4 lag bolts (supplied) drill lag bolts through the plywood vanity back into studs. **If no studs available, build a back support to hold the vanity up.**
7. Once the cabinet is in position the vanity top can be installed. Please refer to the Vanity Top installation section.

Vanity Top Installation

1. Clean the perimeter of the vanity and the underside of the top ensuring they are free of dust and any particles.
2. Apply a small bead of neutral cure silicone (not supplied) to the four corners of the cabinet.
3. Place the vanity top into position
4. Install the tap-ware.
 - If the tap-ware being installed does not have a gasket to seal it to the vanity top its recommended that silicone sealant be applied to the underside of tap-ware flange.
5. Install the waste. Seal the underside of the waste flange with either plumbers' putty or silicone sealant.

If tap-ware and waste are to be fitted immediately after installation, care must be taken to ensure top remains in correct position until silicone is cured.

CAUTION

Do not over tighten the waste fitting during installation.

PLEASE NOTE: ALL PLUMBING CONNECTIONS MUST BE MADE BY A REGISTERED PLUMBER.

Allow the sealant to cure for a minimum of 24 hrs. before use.