


TV Stand




ASSEMBLY INSTRUCTION


ADULT ASSEMBLY REQUIRED

**THE PRODUCT MAY RECOMMENDED
ASSEMBLING BY MORE THAN ONE
PERSON.**

**PLEASE ASK FOR ASSISTANCE AT YOUR
CONVENIENCE BEFORE ASSEMBLING.**



Before You Start



Read through each step carefully and follow the proper order

Separate and count all your parts and hardware


Give yourself enough room for the assembly process

Have the following tools: Flat Head Screwdriver, #2 Phillips Head Screwdriver and Hammer


Caution: If using a power drill or power screwdriver for screwing, please be aware to slow down and stop when screw is tight. Failure to do so may result in stripping the screw.

Cam Lock Fastening System


This Cam Lock Fastening System will be used throughout the assembly process.



Parts Identification




Parts Identification




(A)

TOP




(B)

BOTTOM




(C)

LEFT




(D)

RIGHT




(E)

MID-VERTICAL SHELF




(F)

LEFT SHELF




(G)

RIGHT SHELF




(H)

FRONT LEFT DECOR




(I)

BACK LEFT DECOR




(J)

BACK RIGHT DECOR



(K)


BACK PANEL




(L)

LEFT DOOR


Parts Identification




MIDDLE LEFT DOOR




MIDDLE RIGHT DOOR




RIGHT DOOR




RIGHT AND LEFT END x 2




LOWER SUPPORT x 2



MIDDLE LEG




INNER SIDE SUPPORT x 4




FRONT RIGHT DECOR

Hardware Identification




DOUBLE-HEADED SCREWDRIVER:
THIS TOOL ALLOWS YOU TO USE DIFFERENT HEAD FOR DIFFERENT TYPE OF SCREWS BY SWITCH THE YELLOW HANDLE


Hardware Identification




CAM BOLT
QTY: 28+1 spare




CAM LOCK
QTY: 28+1 spare




WOOD DOWEL
QTY: 32+1 spare




SCREW
QTY: 8+1 spare




BOLT
QTY:10+1 spare




BOLT
QTY:4+1 spare




BOLT
QTY:10+1 spare




HEX KEY
QTY: 1




SCREW
QTY: 18+1 spare




EUROPE HINGE
QTY: 4




EUROPE HINGE
QTY: 4




SCREW
QTY: 48+2spare



BOLT
QTY: 8+1 spare




HANDLE
QTY: 4




TIPPING RESTRAINT
HARDWARE KIT
QTY:1



Step 1




Assemble screws
(part#1) vertically





Make sure screws are
lock up evenly on board






Step 2




Step 3



Proper orientation of CAM LOCK







Step 4




Proper orientation of CAM LOCK


FINISHED EDGE




Step 5



Step 6




Step 7



Step 8




Do Not Screw Hardware Part 6 Tightly At This Step





Parts 9

Step 9

Please Lock All Screws Tightly At This Step




Step 10



Before attaching the back panel, be sure that the unit is at 90°


Avant d'attacher le panneau arrière, assurez-vous que l'unité est à 90°

Antes de fijar el panel posterior, asegúrese de que la unidad esté a 90°




Parts 10






Step 11



Step 12





Step 13









****This hinge is hardware part 11****

Step 14





Make sure parts "L" and "O" are assembled aligning with parts "H" and "T"







To adjust the vertical height.

Loosen the four screws "A" on both hinges. Two of them are usually in slotted holes which allows you to adjust up or down by a few mm. Then tighten back up.



To adjust depth.


Loosen screw "B" and adjust door, if the door can not be adjusted, please loosen screw "C", then try again. Tighten screw "B" and "C".




To adjust side ways.

Turning the screw "C" on BOTH hinges on each door.

Step 15



Step 16




Follow the instructions printed on the plastic bag containing the tipping restraint hardware to attach the tip-over restraints to the unit and the wall.

NOTE: The tipping restraint hardware included is for drywall construction. It will be necessary to drill holes for the wall anchors. Depending upon your wall construction, different anchor hardware may be required. Please contact your local hardware store for assistance.

Safety Maximum Loads

This unit has been designed to support the maximum loads shown. Exceeding these load limits could cause sagging, instability, product collapse, and/or serious injury.



WARNING

Please make sure that all objects are removed before moving the assembled unit. The unit must be team lifted, not dragged or pushed. Failure to do so could cause instability, product collapse, and/or serious injury.