


Assembly Instructions




Before Assembly

Tips Before Your Start:


- Remove all wrapping material, including staples & packing straps before you start to assemble.
- DO NOT tighten all screws and bolts until the assembly is completely assembled.
- Keep all hardware parts out of reach of children.

QUICKFIT



Tighten quickfit until shoulder is flush with panel. Do not overtighten or undertighten.


CAM LOCK



When fitting a cam lock, ensure the starting position is correct before inserting the connecting QUI CKFIT

Quickfit head should be in the centre of the cam lock when the two panels are joined.

Cam lock should be inserted before quickfit.





Turn cam lock clockwise to tighten.


Before Assembly

Tips Before Your Start


How to separate the drawer slider:



Drawer Front Alignment





















If the drawer front panel is NOT level after being assembled, then...




Loosen the screws on the left and right hand side, then adjust the drawer slide up or down, until the drawer fronts are even/level, then tighten the screws.


Part List

<p>No. A Quantity:44 Pcs Cam Lock Dowel 8*28mm</p> 	<p>No. B Quantity:52 Pcs Cam Ø15</p> 	<p>No. C Quantity:52 Pcs Sticker Ø20</p> 	<p>No. D Quantity:21 Pcs Dowel 8*30mm</p> 
<p>No. E Quantity:1 Pcs Drawer Slider 10"</p> 	<p>No. F Quantity:20 Pcs Screw M3.5*14mm</p> 	<p>No. G Quantity:8 Pcs Screw M3.5*12mm</p> 	<p>No. H Quantity:4 Pcs Screw M4*30mm</p> 
<p>No. I Quantity:4 Pcs Adjust The Foot</p> 	<p>No. J Quantity:23 Pcs Screw M6*40mm</p> 	<p>No. K Quantity:1 Pcs Allen Key 4#</p> 	<p>No. L Quantity:4 Pcs Screw M4*14mm</p> 
<p>No. M Quantity:2 Pcs Handle 200*20mm</p> 	<p>No. N Quantity:12 Pcs Screw M6*40mm</p> 	<p>No. O Quantity:4 Pcs Double-ended rod 6*64mm</p> 	<p>No. P Quantity:2 Pcs L Shape Part 38*31*31mm</p> 
<p>No. Q Quantity:2 Pcs Connecting piece 60*38*1.5mm</p> 	<p>No. R Quantity:1 Pcs Cover hole</p> 		

Product structure



STEP 1




No. A
Quantity: 8 Pcs
8*28mm



STEP 2


Note: lock the bolt hole on the same side.



No. B
Quantity: 4 Pcs
Ø15




STEP 3



No. B
Quantity: 4 Pcs
Ø15



STEP 4




No. J
Quantity: 1 Pcs
M6*40mm



No. K
Quantity: 1 Pcs
4#




STEP 5



No. A
Quantity: 8 Pcs
8*28mm



STEP 6




Note: lock the bolt hole on the same side.

No. B
Quantity: 4 Pcs
Ø15




STEP 7



No. B
Quantity: 4 Pcs
Ø15



STEP 8




No. J
Quantity: 1 Pcs
M6*40mm



No. K
Quantity: 1 Pcs
4#




STEP 9



No. A
Quantity: 4 Pcs
8*28mm




No. E
Quantity: 1 Sets
10"



No. G
Quantity: 4 Pcs
M3.5*12mm




STEP 10




No. B
Quantity: 8 Pcs
Ø15




No. D
Quantity: 4 Pcs
8*30mm



No. O
Quantity: 4 Pcs
6*64mm




STEP 11



No. A
Quantity: 16 Pcs
8*28mm



STEP 12



No. B
Quantity: 4 Pcs
Ø15



STEP 13






Align the arrow on the Cam-lock to the Cam-bolt head and insert the Cam-lock. Ensure Cam-lock is fully inserted.


No. B
Quantity: 12 Pcs
Ø15



No. D
Quantity: 6 Pcs
8*30mm



STEP 14




No. F
Quantity: 12 Pcs
M3.5*14mm



No. P
Quantity: 2 Pcs
38*31*31mm




STEP 15




No. B
Quantity: 4 Pcs
Ø15



No. D
Quantity: 3 Pcs
8*30mm



STEP 16



No. J
Quantity: 4 Pcs
M6*40mm




No. K
Quantity: 1 Pcs
4#



STEP 17

There is wax on the sliding door, and it needs to be pushed and rubbed back and forth before use, so that the wax is evenly attached to the board.



No. L
Quantity: 4 Pcs
M4*14mm




No. M
Quantity: 2 Pcs
200*20mm



STEP 18


No. D
Quantity: 8 Pcs
8*30mm




No. J
Quantity: 14 Pcs
M6*40mm



No. K
Quantity: 1 Pcs
4#



STEP 19




No. J
Quantity: 3 Pcs
M6*40mm



No. K
Quantity: 1 Pcs
4#




STEP 20




No. F
Quantity: 8 Pcs
M3.5*14mm




No. Q
Quantity: 2 Pcs
60*38*1.5mm



STEP 21




No. N
Quantity: 12 Pcs
M6*40mm



No. K
Quantity: 1 Pcs
4#




STEP 22



No. I
Quantity: 4 Pcs




STEP 23



No. A
Quantity: 8 Pcs
8*28mm




STEP 24




No. B
Quantity: 2 Pcs
Ø15




No. H
Quantity: 4 Pcs
M4*30mm



STEP 25



STEP 26




No. B
Quantity: 6 Pcs
Ø15





STEP 27




The first screw hole should corresponded with the board location hole



 Here are only the corresponding holes




No. E
Quantity: 1 Sets
10"



No. G
Quantity: 4 Pcs
M3.5*12mm



STEP 28



No. R
Quantity: 1 Pcs

