

APPLICATIONS FOR AQUABAR® “B” UNDERLAYMENT MEMBRANE

THE DETAILS SHOWN HERE REFER TO GENERALLY ACCEPTED WOOD FLOOR INSTALLATION PRACTICES

Aquabar “B” is the most effective moisture vapor retarder for use under wood flooring. It is a cleaner and easier handling product than roofing felt and poly film. Aquabar “B” slows moisture migration and is a superior vapor retarder. It is not a vapor barrier or waterproof membrane. Aquabar “B” meets IBC® and IRC® code requirements as a Class II membrane.

HARDWOOD FLOORS

Under wood floors, Aquabar “B” serves as a moisture vapor retarder, reducing or preventing moisture migration from below the floor system, along the wood flooring to acclimate gradually. As a semi-permeable material, Aquabar “B” is also much less likely than poly film, coated paper or other materials to trap moisture condensation between it and the sub-floor. Installed under wood floors as a “slip sheet”, Aquabar “B” helps keep down dust and reduces squeaks. Aquabar “B” may be used in applications over a wood sub-floor, on joists or concrete. This application guide provides examples of typical wood flooring installations using Aquabar “B”. The descriptions are brief and do not cover all circumstances that the installer may encounter during installation. It is the responsibility of the installer to obtain, read and follow the flooring manufacturer’s instructions, NWFA guidelines and all applicable building codes for proper installation of wood flooring. For best results when installing, we suggest using a NWFA Certified Professional.

JOB SITE CONDITIONS


- Building must be completely enclosed
- Site drainage directs water away from foundation
- All other interior work should be completed
- Interior environmental conditions must be at occupied levels
- Basements and crawl spaces must be dry
- Acclimate flooring per manufacturer’s recommendation

SUB-FLOOR PREPARATION

- All surface debris and protrusions must be removed
- Check sub-floor for squeaks and repair
- Sweep and vacuum prior to filling or repairing voids
- Fill voids and level high spots, sweep again

WOOD SUB-FLOORS – NAILED

Always read and follow the floor manufacturer’s installation instructions. For installations over wood joist construction be sure, if above a crawl space, the ground is covered by a vapor retarder with a perm rating of ≤ 0.04 , and crawl space is properly ventilated. Cut Aquabar “B” to length and position over sub-floor as needed for proper coverage. Overlap all seams a minimum of 4 inches. Aquabar “B” may be loose-laid or stapled over sub-floor. Once Aquabar “B” is installed, snap chalk lines to desired layout.



CONCRETE SUB-FLOORS – FLOATED & NAILED



For on-grade slabs, the following conditions must be met:

- An underslab vapor retarder has been properly installed
- The slab is thoroughly dry before installation of wood flooring. Generally, slabs must be 60 days old. Test for moisture, following flooring manufacturer's recommendations.
- To be certain normal slab moisture does not reach the wood flooring, install a vapor retarder with a perm rating of ≤ 0.04 over the slab. Then follow wood floor manufacturer's recommendation for placement of plywood. Cut and install Aquabar "B" over plywood as above.

CONCRETE SUB-FLOORS – SCREED SYSTEM

Install flat, dry, preservative treated 2x4s, cut 18-24" long, laid flat at right angles to finished floor, spaced 12" o.c. and embed in adhesive.

Then lay a vapor retarder with a perm rating of ≤ 0.04 over screeds, install plywood and cover with Aquabar "B" as above



APPLICATIONS FOR AQUABAR® "B" TILE & FLOORING UNDERLAYMENT

THE DETAILS SHOWN HERE REFER TO GENERALLY ACCEPTED TILE INSTALLATION PRACTICES



Aquabar "B" is suitable for use in interior tile and stone applications as a moisture retardant membrane, or cleavage membrane on walls, countertops, or residential showers. Aquabar "B" is not a vapor barrier or waterproof membrane and should not be used in waterproofing assemblies or where a waterproof membrane is specified. Meets ANSI A108.02 Sec. 3.8.7 material standards for tile.

TILE & STONE INSTALLATIONS

The following illustrations are examples of typical tile and stone installations using Aquabar "B". The following illustrations are designed to show the positioning of Aquabar "B" within the assembly and do not attempt to give step-by-step installation details for the assembly. To obtain detailed installation instructions, please refer to the Handbook for Ceramic Tile Installation, "The Industry's Guide for Installation Practices", or ANSI Standards. Contact The Tile Council of North America, Inc., on-line at www.tileusa.com or call (864) 646-8453.

All tile applications should be installed in accordance with appropriate ANSI A108, A118 and A136 standards for installation of ceramic tile, the architect/specifier instructions, tile and setting manufacturer's recommendations and all local building codes. When installing behind a cementitious

backer unit follow the CBU manufacturer's instructions for a moisture retarder membrane or cleavage membrane. In applications where a duplex type reinforced asphalt



LIMITATIONS: Aquabar "B" hardwood floor and tile underlayment is not a vapor barrier or a waterproof membrane and should not be used in waterproofing assemblies where a moisture or vapor barrier is specified. Do not leave exposed to direct moisture contact or use in areas that are soaked or saturated for extended periods of time, such as gang showers, saunas, steam rooms, pools, hot tubs and exterior areas.

Aquabar "B" has no offensive odor, however it does contain asphalt. Individual sensitivity to chemicals varies and should be considered prior to purchase of any product.

Aquabar "B" may be used following manufacturer's recommendations with radiant heat as long as the substrate temperature is limited to a maximum of 85°F.

Aquabar "B" is not recommended for use on exterior

wall assemblies. Properly prepared walls, sub-floors or jobsite conditions and proper installation of flooring and tile are the responsibility of the installer.

For best results when installing, use a properly trained installer such as a CTEF Certified Installer, NTCA contractor or TCAA contractor. **INSTALLATION** – Cut Aquabar "B" to length and position over substrate as needed for proper coverage. It may be applied to wall framing either horizontally (best method) or vertically. Overlap seams a minimum of 4 inches or more as required by CBU manufacturer or architect/specifier and local building codes. Be sure to overlap tub, shower lip or shower pan membrane and seal gap between the tile installation and tub/shower unit with a high quality elastomeric caulking after tile work and grout are dry

