



Product manual



Arrive in 2 separate boxes and may not be part of the same shipment;
Please install the product after receiving all the packages.

V1.0



THE FOLLOWING INFORMATION:

- Order number
- Purchase platform
- Purchase date
- Detailed description of the issue along with photos (if applicable)

Important – Please read these instructions carefully before starting the installation.



Warning: Please read these instructions fully before starting assembly. Check you have all the components and tools listed on pages. Keep the instructions for later reference. Parts of the assembly will be easier with 2 people. Seek professional assistance if necessary.

Warning: Please place all parts on a flat surface. Place a soft blanket or similar underneath to protect against scratches or stains. Avoid dragging or sliding components across the floor.

Warning: Regularly check all fittings and fastenings to ensure they are secure and to prevent accidents. If any parts are missing, broken, damaged, or worn, discontinue use of the product until repairs have been made using factory authorized parts.

Warning: Do not allow children to climb on the furniture as this may result in tipping and serious personal injury. Assemble the furniture away from the reach of children.

Warning: Do not place furniture close to fire sources or high-temperature objects to avoid the risk of fire. Do not place furniture in damp environments to prevent material damage.

Warning: Clean furniture with a damp cloth or alcohol, avoid using cleaning agents containing corrosive chemicals.

Warning: This product is equipped with an anti-tilt device. Please be sure to install this device to prevent unnecessary injuries caused by tipping.

A Guide to Wall Mounting & Fixings

Important note:

If plastic wall plugs (rawl plugs) are supplied with your product, e.g.:



- these are only suitable for use in masonry walls.

If you are in any doubt about the correct wall plugs for your wall, seek professional advice.


Failure of the product due to using the incorrect fixings is the responsibility of the installer.



Important: when drilling into walls always check that there are no hidden wires or pipes etc.

Make sure that the screws and wall plugs being used are suitable for **supporting your unit**. **Consult a qualified tradesperson if you are unsure.**


Hints:

- 1: General rule:  always use a larger screw and wall plug if you are not sure.
- 2: Ensure you use the recommended drill bit to match the wall plug and hole size.
- 3: Ensure you drill the hole horizontally; do not force the drill or enlarge the hole.
- 4: Take extra care when drilling high walls, ceilings and ceramic tiles. Ensure wall plugs are inserted beyond the thickness of the ceramic tiles to avoid the tiles splitting or cracking.
- 5: Ensure wall plugs are well fitted and are a tight fit in the drilled hole.

Types of walls


You can use one of the following types of wall plug if your walls are made of brick, breeze block, concrete, stone or wood.

No.1 "General Purpose" wall plug




Generally aerated blocks should not be used to support heavy loads, use a specialist fitting in this case. For light loads, general purpose wall plugs can be used.

No.2 "Plasterboard" wall plug




For use when attaching light loads onto plasterboard partitions.

No.3 "Cavity Fixing" wall plug




For use with plasterboard partitions or hollow wooden doors.

No.4 "Cavity Fixing – Heavy Duty" wall plug




For use when fitting or supporting heavy loads such as shelving, wall cabinets and coat racks.

No.5 "Hammer Fixing" wall plug



For use with walls stuck with plasterboard. The hammer fixing allows it to be fixed to the wall rather than the plasterboard. Always check the fixing is secure to the retaining wall.

No.6 "Shield Anchor" wall plug – heavy loads




For use with heavier loads such as TV and HiFi speakers and satellite dishes etc.




Care & Maintenance

Safety: always check the fitting and location to ensure your safety in and around the home.


Fitting: from time to time check the fitting to ensure the wall plugs or screws do not become loose.




QUICKFIT: Tighten quickfit until shoulder is flush with panel. Do not overtighten or undertighten.



CAM LOCK: When fitting cam lock, ensure starting position is correct before you insert connecting quickfit.




Quickfit head should be in the centre of the cam lock when the two panels are joined.
Cam lock should be inserted before quickfit.




Turn cam lock clockwise to tighten.


It may be necessary to adjust the hinges so that the doors align. Use the instructions below as a guide.




To adjust the door vertically loosen the screw as shown and move up and down as needed.



To adjust the gap from the door to the main frame turn the screw clockwise or anti-clockwise as needed.



To adjust the door laterally adjust the screw as shown by turning clockwise or anti-clockwise.



Please fix other screws

CUSTOMER SERVICE GUIDE

Thank you for choosing our product! We are committed to providing you with excellent service. If you find any missing parts, damaged packaging, or product damage after receiving all packages, please follow the steps below to quickly contact our customer service team. We will do our best to resolve your issue.

1. Missing Parts

Verify Parts:

1. Refer to the “Parts List” in the manual to verify the name, specifications, and quantity of the missing parts.
2. Take a clear photo of the parts list and mark the missing parts with detailed information, e.g., “Missing 5 pieces of M6X30mm screws.”

Contact Us:

· By Email:

We with the subject line “Missing Parts Issue.” Include the following in the email:

- A description of the missing parts and a photo of the parts list.
- Order details (order number, purchase platform, purchase date).

2. Product or Packaging Damage

If it affects normal use:

Steps:

1. Take clear photos or videos showing the damaged parts and the extent of the damage (multi-angle shots are recommended).
2. Email the photos/videos along with order details, with the subject line “Product Damage Issue.”

Resolution:

After verification, we will arrange for a replacement part, product exchange, or refund as quickly as possible.

If it does not affect normal use:

Steps:

Provide a description of the damage and include relevant photos or videos.

Resolution:


We will provide repair guidance or an appropriate compensation plan based on the specific situation.

Helpful Tips

To process your issue efficiently, please prepare the following information:





- Order details (order number, purchase platform, purchase date).
- Clear photos or videos.
- We are committed to providing quick and professional solutions, no matter the size of the issue, to ensure your satisfaction.











Thank you for your trust and support! We hope you enjoy using our product!






























BOX-1/2




BOX-2/2

| NO. | PARTS | QTY |
|-----|---|-----|
| 2 |  | 1 |
| 3 |  | 1 |
| 10 |  | 4 |
| 14 |  | 2 |


| NO. | PARTS | QTY |
|-----|---|-----|
| 1 |  | 1 |
| 4 |  | 1 |
| 5 |  | 1 |
| 6 |  | 1 |
| 7 |  | 1 |
| 8 |  | 1 |
| 9 |  | 1 |
| 13 |  | 4 |
| 15 |  | 2 |
| 16 |  | 2 |

| NO. | PARTS | QTY |
|--|---|-----|
| 11 |  | 2 |
| 12 |  | 1 |
| 17 |  | 2 |
| 18 |  | 2 |
| 20 |  | 2 |
| 19 |  | 2 |
|  Fittings Box | | |



| | | | |
|---|--|--|---|
|  <p>1 x1 760x500x15mm</p> |  <p>2 x1 1370x500x15mm</p> |  <p>3 x1 1370x500x15mm</p> |  <p>4 x1 760x500x15mm</p> |
|  <p>5 x1 385x500x15mm</p> |  <p>6 x1 385x500x15mm</p> |  <p>7 x1 760x500x15mm</p> |  <p>8 x1 724x30x15mm</p> |
|  <p>9 x1 728x115x15mm</p> |  <p>10 x4 638x368x3mm</p> |  <p>11 x2 620x12x6mm</p> |  <p>12 x1 737x393x3mm</p> |
|  <p>13 x4 180x60x25mm</p> |  <p>14 x2 1365x360x15mm</p> |  <p>15 x2 724x188x15mm</p> |  <p>16 x2 674x115x15mm</p> |
|  <p>17 x2 297x115x15mm</p> |  <p>18 x2 297x115x15mm</p> |  <p>19 x2 681x290x3mm</p> |  <p>20 x2 282x55x15mm</p> |

| | | | |
|--|---|---|---|
| <p>Ax16</p>  <p>6x30mm</p> | <p>Bx22</p>  | <p>Cx22</p>  | <p>Dx8</p>  <p>6x40mm</p> |
| <p>Ex40</p>  <p>4x14mm</p> | <p>Fx20</p>  <p>3x12mm</p> | <p>Gx12</p>  <p>4x35mm</p> | <p>Hx8</p>  <p>4x40mm</p> |
| <p>Ix1</p>  | <p>Jx6</p>  | <p>Kx2</p>  | <p>Lx2</p>  |
| <p>Mx12</p>  | <p>L300mm</p>  <p>CL DL CR DR</p> | | <p>Nx2</p> |
| <p>Ox2</p>  | | | |



Ruler - Use this ruler to help correctly identify the screws mm









The screws length is measured from the head to the point (30mm screw shown).




inch



1. Install parts B onto panel(2,3)
2. Install parts K onto panel(2,3) using parts E





02




Connect panel(9) to panel(2) and tighten with parts C



03





Connect panel(9) to panel(3) and tighten with parts C





1. Join panel(10,11) together and insert into the slots of panel(2,3)
2. Insert parts A into panel(2,3)









Install parts L onto panel(4) with screws, rotate 180 degrees, then install parts B onto panel(4)








Connect panel(4) to panel(2,3) and tighten with parts H

1. Install slide rail CL onto panel(5) using parts F, paying attention to the arrow direction









2. Install slide rail CR onto panel(6) using parts F, paying attention to the arrow direction



Use parts A to connect panel(4) to panel(5,6), and tighten with parts C



Insert parts A into panel(5,6), Insert panel(12) into the slots of panel(5,6)






Install panel(13) sequentially onto panel(7) using parts D


Connect the assembled panel(7) to panel(5,6) and tighten with parts H



- 1.Join panel(10,11) together and insert into the slots of panel(2,3)
- 2.Insert parts A into panel(2,3)



A x 4
6x30mm




B x 4

L x 1


O x 2




Install parts L onto panel(1) with screws, install parts B onto panel(1), rotate 180 degrees, then install parts O onto panel(1) with screws

Connect the assembled panel(1) to panel(2,3) and tighten with parts C




Use parts G to assemble panel(16,17,18,20) together










1. Insert panel(19) into the slots of panel(17,18)
2. Install parts B onto panel(15)
3. Connect panel(15) with panel(17,18) and tighten with parts C

Install slide rail DL onto panel(17) and slide rail DR onto panel(18) using parts F





F x 8

 3x12mm

N x 2
 DL
 DR





Place drawer(15) into the cabinet










x2






1. Install parts J onto panel(14) using parts E
2. Install the assembled panel(14) onto the cabinet using parts E









Place component(8)





Tighten parts M onto panel(10) with screws to enhance cabinet stability

1. First, mark the position with a marker, then drill holes in the wall using an electric drill.
2. Then, hammer expansion plug O into the wall holes.
3. Pass screws through the holes of the anti-tip L-shaped bracket and tighten them into the wall.



Wall





MAINTENANCE AND CARE

1. Prevent Pests

Keep wooden furniture away from damp environments to prevent pest infestations and wood deterioration. Use a dehumidifier or air conditioner during humid seasons to maintain a dry atmosphere.

2. Protect from Sunlight

Avoid placing furniture in direct sunlight to prevent cracking, discoloration, and fading. If sunlight exposure is unavoidable, use curtains or blinds to shield the furniture.

3. Keep Away from Heat Sources

Position furniture away from heaters, radiators, or open flames to avoid damage and maintain its structural integrity.

4. Routine Care

Apply furniture oil periodically to enhance the wood's shine, prevent cracking, and prolong its lifespan.

5. Regular Cleaning

Vacuum dust and debris frequently, especially beneath and around furniture, to ensure a clean and hygienic environment.

6. Maintain Dryness

Ensure adequate ventilation to prevent moisture buildup. Use a dehumidifier if necessary to protect the furniture from dampness.

7. Avoid Contact with Corrosive Substances

Keep the furniture away from acidic or alkaline substances to protect its finish and durability.

8. Gentle Cleaning

Wipe surfaces with a damp, well-wrung cloth to clean without causing water damage or swelling.

9. Minimize Sun Exposure

Prolonged exposure to sunlight can dry out and damage wood. Place furniture in shaded areas or use curtains to block harmful UV rays.