




12'x14' Metal Patio Gazebo

ASSEMBLY MANUAL



MODEL#: LGMF1670

Missing part? Damaged? Contact us via email at

service@domioutdoorliving.com

www.domioutdoorliving.com

Pre-assembly



1. Two or more people are required for assembly.



2. You will need one or more stepladders.



3. Wearing protective gloves is recommended.



4. You may need a safety hat.



5. Please use a Phillips screw driver.



6. For ease of construction, you may need a drill.



7. You may need a safety goggle.



8. Do not fully tighten screws prior to complete assembly.

Warning & Attention




-Try to assemble this product on the flat ground, otherwise it is difficult to carry out;

-It would be much easier to assemble the product with three or more people;



-After assembly, please check whether all screws are tightened, to prevent parts from falling apart.

▲ Use bolts to secure the frame to the ground to against the strong wind.

IMPORTANT: A gaze may entail to purchase a municipal permit or be subject to specific building codes. It is the consumer's responsibility to inform themselves of any restrictions.





1




x12

If the deck is hard wood and the depth of it is over 3 inch, you can use **5/16 in. x4 in. Structural Wood Screw** to mount the gazebo.







2




If the ground is concreted and the depth of it is over 3 inch, you can use 1/4 inch expansion bolts to mount the gazebo



















3




















Or you can make a concrete footing for gazebo, **15×15×15 inches** is recommended. use expansion bolts to mount the pergola like ② shows.

IMPORTANT:
Anchor is not recommended




 <p>Pole 2080 A (x4)</p>	 <p>Outside Roof Cover 865 D (x1)</p>
 <p>Beam 2015 B (x2)</p>	 <p>Inside Roof Cover 789 D1 (x1)</p>
 <p>Beam 2015 B1 (x2)</p>	 <p>Union Bar 600 E (x4)</p>
 <p>Beam 1715 B2 (x2)</p>	 <p>Corner Cover F (x4)</p>
 <p>Beam 1715 B3 (x2)</p>	 <p>Joint Cover G (x4)</p>
 <p>Track 1883 C (x2)</p>	 <p>Silicone Sealant H (x1)</p>
 <p>Track 1883 C1 (x2)</p>	 <p>Corner Solidifying Bar 592 J1 (x4)</p>
 <p>Track 1583 C2 (x2)</p>	 <p>Corner Solidifying Bar 592 J2 (x4)</p>
 <p>Track 1583 C3 (x2)</p>	 <p>Base K (x4)</p>

 <p>Base Cover</p> <p>K1 (x4)</p>	 <p>Mesh</p> <p>P (x1)</p>
 <p>Bracket</p> <p>K2 (x8)</p>	 <p>Finishing End</p> <p>Q (x8)</p>
 <p>Corner Roof Tube Connector</p> <p>690</p> <p>L (x4)</p>	 <p>Hooks</p> <p>R1 (x2)</p>
 <p>Corner Roof Tube</p> <p>2115</p> <p>L1 (x4)</p>	 <p>Black Rubber</p> <p>S (x128)</p>
 <p>Roof Tube</p> <p>1927</p> <p>M (x4)</p>	 <p>Solidfying Bar</p> <p>1085</p> <p>U1 (x4)</p>
 <p>Finishing Bar</p> <p>740</p> <p>N (x2)</p>	 <p>Solidfying Bar</p> <p>1385</p> <p>U2 (x4)</p>
 <p>Finishing Bar</p> <p>1340</p> <p>N1 (x2)</p>	 <p>Bracket</p> <p>U3 (x4)</p>
 <p>Finishing Bar</p> <p>1020</p> <p>O1 (x2)</p>	 <p>Bracket</p> <p>U4 (x4)</p>
 <p>Finishing Bar</p> <p>1620</p> <p>O2 (x2)</p>	




M6x16

1#
x193




M6x25

10#
x4




M6x20

2#
x24




M6x12

11#
x12




3#
x16




ST6.3*15

12#
x4




4#
x120




M6x28

5#
x80



M6x45

6#
x8



M6x50

7#
x36












M5x16

8#
x4





ST4.8x13


9#
x24




Mosquito Netting





Strap



Solid Sidewall




Plastic Clips




Z1 (x6)






Z2 (x6)



Z3 (x2)




Z4 (x2)



Plastic Bar


Pa (x2)





Plastic Bar

Pb (x2)



POST ASSEMBLY:








(1) Put on Base Cover
#K1 first;

(2) Attach Base #K to
Pole #A with 3 Bolts
#1.




X4






(1) Slide the Plastic Hooks #4 to the double-rail track #C (each slot should slide 8 plastic hooks).


(2) Repeat the above procedures for the other track C.



(1) Slide the Plastic Hooks #4 to the double-rail track #C1 (each slot should slide 8 plastic hooks).


(2) Repeat the above procedures for the other track C1.






(1) Slide the Plastic Hooks #4 to the double-rail track #C2 (each slot should slide 7 plastic hooks).


(2) Repeat the above procedures for the other track C2.




(1) Slide the Plastic Hooks #4 to the double-rail track #C3 (each slot should slide 7 plastic hooks).

(2) Repeat the above procedures for the other track C3.






BEAM ASSEMBLY




- (1) Insert Part #E into Part #B1, and secure with 4 Bolts #1.
- (2) Insert the other side of Part #E into Part #B and secure with 4 Bolts #1.

Repeat the above procedures to assemble the other Part #B1 and #B.






TIPS: It's a normal situation that there's a gap between the 2 beams, please use silicone sealant (part #H) and Joint Cover #G to affix the gap.(see P12)




1#
x16

(1) Use 8 Bolts #1 to fix the track C & C1 to the beam B1 & B.
Repeat the above procedures for another beam B1 & B.






- (1) Insert Part #E into Part #B3, and secure with 4 Bolts #1.
 - (2) Insert the other side of Part #E into Part #B2 and secure with 4 Bolts #1.
- Repeat the above procedures to assemble the other Part #B3 and #B2.**




TIPS: It's a normal situation that there's a gap between the 2 beams, please use silicone sealant (part #H) and Joint Cover #G to affix the gap.(see P12)




1#
x16

(1) Use 8 Bolts #1 to fix the track C2 & C3 to the beam B3 & B2.
Repeat the above procedures for another beam B3 & B2.






2#
x16




3#
x16


FRAME ASSEMBLY:




Inside View



Please don't tighten
all bolts.





Outside View



Inside View

CORNER SOLIDIFYING
BAR ASSEMBLY:



Outside View







F (x4)






9#
x16

CORNER COVER & JOINT COVER ASSEMBLY:





Use 5mm silicone sealant(part #H) and Joint Cover #G to affix the gap.






L (x4)




L1 (x4)




2#
x8

CORNER ROOF TUBE ASSEMBLY:





(1) Connect Part #L1 and Part #L with 2 Bolts #2.
Repeat the above procedures to assemble the
other 3 Corner Roof Bars.




D1 (x1)

CORNER ROOF TUBE AND INSIDE ROOF CONNECTOR ASSEMBLY:






Place 4 Corner Roof Tubes on the 4 corners of Inside Roof Cover #D1, secure with 8 Bolts #1 (from bottom to top).




Lift 4 corner roof Tubes and inside roof connector to the top of the frame.(You may need 2 people and 2 ladder).




1#
×4

Secure with 4 Bolts #1.




INSIDE VIEW






M (x4)




1#
x12


MIDDLE ROOF TUBE ASSEMBLY:




Check the the frame as pictures below shows.



Frames in Parallelogram shape



Frames in rectangular shape



P (x1)







Pa (x2)



Pb (x2)


PLASTIC BAR ASSEMBLY:








OUTSIDE ROOF COVER AND MESH ASSEMBLY :


- (1) Place the Outside Roof Cover on the inside Roof Cover.
- (2) Align the holes and use 2 Hooks #R1 and 1 bolt #1 to secure Mesh #P to the inside Roof Cover (From Bottom to Top).










BOTTOM VIEW






INSIDE VIEW



Please do not pull plastic bar out when installing it with #N&N1 on the middle roof tube.




BOTTOM VIEW



Plastic Bar
on the mesh


■ Plastic Bar on the mesh



■ #N/N1



N1





Q






Remove the protective film of the panels before installing the roofing panels.


Please install Clips in strict accordance with the instructions.




Attach Part #Z,#Z1,#Z2,#Z3&#Z4 by lightly tapping with screwdriver.



O1 (x2)




O2 (x2)





12# x4




1# x4

SMALL ROOF PANEL AND FINISHING BAR ASSEMBLY:






If you can't install #V4&V5, push the Outside Roof Cover up and try to insert them again.








Remove the protective film of the panels before installing the roofing panels.

Please install Clips in strict accordance with the instructions.




Remove the protective film of the panels before installing the roofing panels.

Please install Clips in strict accordance with the instructions.













Attach Part #Z,#Z1,#Z2 by lightly tapping with screwdriver.

Install the Middle Panels (#X4, X5 or #W4,W5) first, then the small panels on the edge.




The Black Rubber #S should be assembled when installing the roof panels; please see the next page.




S x4





10#
x4



Solidifying Bar



Middle Roof Tube







S x36

7#
x36











④

Beam





5#

5#







MOSQUITO NETTING AND SOLID SIDEWALL ASSEMBLY:



Please close your gazebo curtain when it is incoming over 30 mph wind, and tie with Strap #Yb.





Thanks for your purchase.

At domi outdoor living, we believe in our products.

That's why we provide a 12-month warranty and friendly, easy-to-reach after-sales service. So, if you have any questions about our product or assembly, please feel free to contact us. We are here for you.

Support:  

After-sales contact email:

service@domioutdoorliving.com

Business cooperation contact email:

marketing@domioutdoorliving.com

Please have your order ID available if you reach out for support.

If you have damaged parts or product, please send us photos for an immediate response.