


As this item contains many parts, please read the installation instruction carefully before installation and complete the installation with the cooperation of your partner. Please use tools properly and carefully.

---

# Before You Start



- ✓ Read through each step carefully and follow the proper order
- ✓ Separate and count all your parts and hardware
- ✓ Give yourself enough room for the assembly process
- ✓ Have the following tools: Flat Head Screwdriver, #2 Phillips Head Screwdriver and Hammer
- ✓ Caution: If using a power drill or power screwdriver for screwing, please be aware of to slow down and stop when screw is tight. Failure to do so may result in stripping the screw.

# Helpful Hints

PEOPLE NEEDED FOR ASSEMBLY: 1-2


- Open your item in the area you plan to keep it to avoid excessive heavy lifting.
- Identify, sort and count the parts before attempting assembly.
- Compression dowels are lightly tapped in with a hammer.
- Slides are labeled with an **R** (right) and **L** (left) for proper placement.
- Make sure to always face the point on the top of the Cam Lock towards the outer edge.
- Use all the nails provided for the back panel and spread them out equally.
- Back panel must be used to make sure your unit is sturdy.
- Do NOT use harsh chemicals or abrasive cleaners on this item.
- Never push, pull, or drag your furniture.




---

# Board Identification


Not actual size




**(A)**  
TOP  
Qty:1




**(B)**  
LEFT SIDE PANEL  
Qty:1




**(C)**  
RIGHT SIDE PANEL  
Qty:1




**(D)**  
LOWER BACK PANEL  
Qty:1




**(E)**  
UPPER BACK PANEL  
Qty:1




**(F)**  
FRONT SLAT PANEL  
Qty:1



**(G)**  
DRESSING MIRROR  
Qty:1



**(H)**  
HUTCH BACK PANEL  
Qty:1




**(I)**  
HUTCH RIGHT FIXED SHELF  
Qty:2

---


# Board Identification

Not actual size




ⓐ

DRAWER FRONT  
Qty:1




ⓑ

DRAWER LEFT PANEL  
Qty:1




ⓒ

DRAWER RIGHT PANEL  
Qty:1




ⓓ

DRAWER BACK PANEL  
Qty:1




ⓔ

DRAWER BOTTOM  
Qty:1




ⓕ

DRAWER MIDDLE PARTIION  
Qty:1




ⓖ

DRAWER SUPPORT RAIL  
Qty:1



ⓗ

STOOL BACK APRON  
Qty:1




ⓘ

STOOL SIDE PANEL  
Qty:2

---


# Board Identification

Not actual size




Ⓢ

STOOL FRONT APRON  
Qty:1




Ⓣ

STOOL BOTTOM BOARD  
Qty:1




Ⓤ

SPONGE CUSHION  
Qty:1



Ⓥ

HOTCH LEFT FIXED SHELF  
Qty:1




Ⓦ

HOTCH SIDE PANEL  
Qty:2


---

# Board Identification


Not actual size




# Part List




CAM LOCK  
spare:2




CAM BOLT  
spare:2




WOOD DOWEL  
spare:3




WOOD DOWEL  
spare:2




WOOD DOWEL  
spare:1




SCREW  
spare:3




SCREW  
spare:2




SCREW  
spare:1




SCREW  
spare:1




HANDLE




METAL PLATE




PLUG BOARD




PERFECT STICKERS  
spare:3



HAIR DRYER RACK




LEFT CABINET MEMBER




RIGHT CABINET MEMBER


# Part List




LEFT DRAWER RUNNER




RIGHT DRAWER RUNNER




GROMMET




HINGE




HEX KEY




LIGHT BULB



ANTI-TIPPING HARDWARE







SCREW  
spare:1



SCREW  
spare:1






# Cam Lock Fastening System

Insert the cam bolt into the hole first, then insert the cam lock and lock it.





The opening must point toward the edge of the board

# STEP 1








# STEP2






---



# STEP3









# STEP 4









# STEP 6

---








# STEP 7



---



# STEP 8





You can install the hair dryer rack(14) on the left or right according to your needs





Proper orientation of CAM LOCK


# STEP 9



|  |    |
|--|----|
| <br>Ø3.5X12mm |    |
| 7  | X4 |






|  |    |
|--|----|
| <br>45X11.5*1mm |    |
| 11   | X2 |

|   |        |
|---|--------|
| <br>SCREW: Ø3.5*14 |        |
| 20  | X1 set |






# STEP 11




# STEP 12




M4X18mm

|   |    |
|---|----|
| 9 | X2 |
|---|----|




104\*5\*16mm

|    |    |
|----|----|
| 10 | X1 |
|----|----|




|    |    |
|----|----|
| 12 | X1 |
|----|----|




Ø3.5X12mm

|   |    |
|---|----|
| 7 | X2 |
|---|----|




|    |    |
|----|----|
| 13 | X4 |
|----|----|





Cabinet Slide


Drawer Slide





# STEP13








|  |     |
|--|-----|
| <br>Ø8X40mm |     |
| 4  | X12 |

|  |    |
|--|----|
|  |    |
| 17   | X2 |



|  |    |
|--|----|
| <br>Ø3.5X14mm |    |
| 21   | X4 |



# STEP14




# STEP15




### To adjust the vertical height.

Loosen the four screws "A" on both hinges. Two of them are usually in slotted holes which allows you to adjust up or down by a few mm. Then tighten back up.



### To adjust depth.

Loosen screw "B" and adjust door, if the door can not be adjusted, please loosen screw "C", then try again. Tighten screw "B" and "C".




### To adjust side ways.

Turning the screw "C" on BOTH hinges on each door.



# STEP16

---





For specific installation and debugging,  
please read the last two pages

**USB PLUG**




**ABS lamp holder**



**Switch regulator**

# STEP17




We have included a set of tipping restraint hardware for this unit. You must install this hardware to prevent accidents or injuries that can result from the unit falling. When properly installed, this restraint can provide protection against the unexpected tipping of the unit due to small tremors, bumps or climbing. We strongly recommend mounting this hardware to a wall stud and your unit.




**NOTE:**The tipping restraint hardware included is for wooden stud wall construction. It must be attached to a wall stud. Depending upon your wall construction different anchor hardware maybe required. Please contact your local hardware store for assistance. Young children can be seriously injured by tipping furniture. You must install the tipping restraint hardware with the unit to prevent the unit from tipping, causing any accidents or damage. The tipping restraints are intended only as a deterrent and are not a substitute for proper adult supervision. The tipping restraints are not earthquake restraints. If you wish to add the extra security of earthquake restraints, they must be purchased and installed separately.




## Install the tipping restraint hardware




1. make mark on the wall




2. drill two Ø6 holes on the wall




3. put two anchors in the holes



4. fix the device on the wall by the long screws



5. Push the cabinet close to the wall so that the two bases are close to each other, and then put on nylon tie to tighten it.



# CONTINUED

---

Thank you for purchasing our company's DIY makeup mirror fill Light products, this product supports DIY own home mirror, instantly make their own mirror into a modern fashion makeup with LED Fill mirror. Even more interesting is that you can adjust the color temperature by yourself!

## Product Features:

1. The standard USB power supply, safety voltage.
2. PC soft mask, don't stab the eyes.
3. All transparent lines, beautiful and stylish.
4. Multilevel luminance adjustable, beauty skin and beauty face.
5. The color temperature is adjustable with the buttons.
6. By rotating the bulbs, the excess connecting wire can be hidden in the bottom shell - make the installation more simple and beautiful.

## Product parameters:

Product Name: Vanity Mirror Lights.

Bulb Size: 50 X 50 X 55 mm.

Power Supply: Standard USB 5V 2A or above.

LED colour temperature : 3000K/4500K/6500K

Power: a single lamp maximum power is 0.8W.

Material: ABS lamp-holder and PC lampshade.

## Wisdom in design:

Rotate the bulbs clockwise or anticlockwise, the ball bubble spacing becomes shorter, the connection line shrinks and hides in the ball bubble bottom cover. Simple and beautiful installation, use more comfortable.

## Rest assured dressing:


USB 5V low voltage power supply, safe! Multilevel luminance adjustable, suitable for different dressing needs.

Three kinds of color temperature can be adjusted: Warm White, Natural White and Pure White.

## Vanity Mirror Lights

The color temperature is adjustable

## Instructions




See Yourself Better!!!

Wisdom in design, Enjoy your life!

# CONTINUED

Use the installation details see inside pages.

## Functional Description:





## Application notes:

1. It is recommended to choose 2A or above USB power adapter, mobile phone charger and other standard USB mobile power can be use.
2. The product uses double-side adhesive paste installation of the bonding surface must be clean, dry, smooth, can not have rust and oil.
3. The wire can be adjustable through the winding between the base slot, and the bulb spacing can be adjusted between 9-26CM.

Reminded: When the bulb is pasted, please press the product for about 30 seconds, it takes 24 hours to achieve the best adhesive strength.

See Yourself Better!!!

## Install reference diagram:



## Installation steps:

1. Cosmetic mirror or be installed surface treatment : should be sticky surface should be dry, clean, and no rust, oxidation, grease, dust and other pollutants.
2. According to the design of the number of mirrors and bulbs ,each bulb installation location, note the lamp spacing of up to 26 CM, the minimum spacing of about 9 CM.
3. Remove the product to determine the power and control switch to place the seat is appropriate to determine the first light paste location (with the control switch to connect the first line).
4. The bottom of the product is double-side adhesive tape tear off the film, and then affixed to the first lamp position ,forced down, so that double-side adhesive is pasted better. Make the tape and the bonding surface get full contact.
5. After the installation, the rotating bulbs will shrink the redundant connecting wires and hide them in the bottom shell to ensure the simple and beautiful installation and achieve the best use effect.
6. When you use the lights, you can adjust the color temperature and the brightness with the function buttons. And choose your favorite color!