


Because it's a narrow cabinet, it must permanently be fixed to the wall with the included anti-tipping device to prevent the cabinet from tipping over. It will be very stable and safe when locked on the wall. Please see STEP 11 for steps to lock the wall.

As this item contains many parts, please read the installation instruction carefully before installation. Please use tools properly and carefully. If you have any questions about the product and installation, please contact us.

Our professional after-sales team will serve you online all day.

Before You Start



- ✓ Read through each step carefully and follow the proper order
- ✓ Separate and count all your parts and hardware
- ✓ Give yourself enough room for the assembly process
- ✓ Have the following tools: Flat Head Screwdriver, #2 Phillips Head Screwdriver and Hammer
- ✓ Caution: If using a power drill or power screwdriver for screwing, please be aware of to slow down and stop when screw is tight. Failure to do so may result in stripping the screw. (Assembly speed can be increased by using electric screwdriver)

Helpful Hints

PEOPLE NEEDED FOR ASSEMBLY: 1-2

- Open your item in the area you plan to keep it to avoid excessive heavy lifting.



- Identify, sort and count the parts before attempting assembly.

- Compression dowels are lightly tapped in with a hammer.



- Slides are labeled with an **R** (right) and **L** (left) for proper placement.



- Make sure to always face the point on the top of the Cam Lock towards the outer edge.

- If there is a back panel in the package, please install it to make sure your unit is complete and sturdy.



- Please fix all the screws provided for the back panel which can enhance product stability. If it is difficult to fix it when tightening, it can be fixed with the help of a hammer and then tightened.




- Do NOT use harsh chemicals or abrasive cleaners on this item.



- Never push, pull, or drag your furniture.

Board Identification


Not actual size



①

TOP PANEL


Qty:1



②

LEFT SIDE PANEL


Qty: 1



③

RIGHT SIDE PANEL


Qty:1



④

UPPER CROSS BAR


Qty:1



⑤

LOWER CROSS BAR


Qty:1



⑥

BOTTOM PANEL


Qty:1



⑦

LOWER CROSS BAR


Qty: 1



⑧

LOWER DOOR

Qty:2




⑨

SHOE BOX BOTTOM

Qty: 2

Board Identification


Not actual size



⑩

SHOE BOX LAYER
Qty: 4

Part List



Ø6 X35mm

(A)

X8

CAM BOLT

spare: 1




Ø15X9mm

(B)

X8

CAM LOCK

spare: 1




Ø6 X30mm

(C)

X12

WOOD DOWEL

spare: 1




M4X40mm

(D)

X2

SCREW




M4X22mm

(E)

X4

METAL L-SHAPED PLATE

spare: 1




M4X14mm

(F)

X28

SCREW

spare: 3




M3X12mm

(G)

X4

SCREW

spare: 1




M4X12mm

(H)

X6


SCREW

spare: 1



(I)


X2



(J)

X4


PLASTIC PLUG



(K)

X4


PLASTIC PIN



(L)

X4

SCREW




M5X40mm

(M)

X14

BOLT


spare: 2



(N)

X2


SHOE BOX LEFT SUPPORT



(O)

X2

SHOE BOX RIGHT SUPPORT




(P)


X2

HANDLE

Part List




ALLEN WRENCH




Cam Lock Fastening System

Insert the cam bolt into the hole first, then insert the cam lock and lock it.








Board Identification


Not actual size



STEP 1




STEP2




ø6X30mm

(C)	X2
-----	----




M5X40mm

(M)	X2
-----	----















M3

(Q)	X1
-----	----









STEP 3








Proper orientation of CAM LOCK

STEP 5







STEP 6








Proper orientation of CAM LOCK

STEP 7






x2

STEP 8







x2

STEP 9





x2

STEP 10



x2

STEP 11




Cabinet must permanently fixed to the wall with included anti-tipping device to prevent the cabinet from tipping over.

.Mark the drill position on the wall with a pencil.





.Drill holes on the marked position using a bit.

Gently inert the wall anchor (D) into the drilled hole with the help of a hammer

.Fixed the cabinet to the wall with provided screws (D)



STEP 12



STEP 13

