


# INSTRUCTIONMANUAL

# NOTES //


- You need a helper to finish the installation.
- Don't over-tighten the screws until all the parts are in place.
  Failure to follow the instructions may cause misalignment of the screws.
- DO NOT let children climb the product.
- To avoid suffocation danger, keep small parts and package materials away from children.
- Adult assembly required. Keep children away during the installation.
- Children should not use it without parents' supervision.
- You could use "corner guard" to protect children from getting hurt by the edges.
- If any parts were missing, broken or wrong delivered, contact us immediately via email we are here to help you.

To better adapt to your home layout and environment, we provide 2 installation methods for you to choose from. There may be extra screw holes after installation, please do not worry.

### INSTALLATION METHOD 1




## INSTALLATION METHOD 2



# PARTS LIST


### Parts •



## PARTS LIST


















## PARTS LIST


#### Hardware •






















Note: Extra parts will be presented as spare use.







#### **INSTALLATION METHOD 1**




Step1 •




### Step2 •




### Step3 •




#### Step4 •




### Step5 •




### Step6 •




### Step7 •



### Step8 •




### Step9 •




### Step10 •

Note: When using Screw A and C, please distinguish between the two as shown, to avoid using wrong screws.







### Step11 ◆




### Step12 •




### Step13 •




### Step14




### Step15 •




#### **INSTALLATION METHOD 2**




Step1 •




### Step2 •




### Step3 •




#### Step4 •




### Step5 •




### Step6 •




### Step7 •




### Step8 •




### Step9 •




### Step10 •




### Step11 •




### Step12 •




### Step13



### Step14 •



# REMOTE CONTROL INSTRUCTION



# **Specification**

Dynamic mode	22 modes
Dynamic mode	22 modes
Static Color	20 colors
PWM Grade	256 levels
Brightness Grade	5 levels
Speed Grade	10 levels
Demo mode	Yes
Direct Color Select	Yes
Output Color Switchable	Yes, 6 options
Working Voltage	DC 5~24V
Output Current	3x4A peak, 3x2A constant
Remote frequency	433.92MHz