



MAXIMUM WEIGHT CAPACITY: 300 LBS

## Instructions for unfolding



Hold armrests  
and push outward




Place one hand on  
each side of seat  
frame, and push  
down simultaneously  
until seat snaps into  
secured position.

To avoid possible injury,  
do not wrap fingers around  
seat frame while pushing down.

## Instructions for folding



Facing side of chair,  
place one foot on the  
bottom support bar.



Pull upward on front and back  
edges of seat until the chair  
snaps out of secured position.  
Push armrests together to fold chair.