Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts which may have come loose inside the carton during shipment. Separate, identify and count all parts and hardware. Compare with the parts list to be sure all parts are present.

IMPORTANT: PLEASE READ INSTRUCTION BEFORE STARTING THE ASSEMBLY.

"DO NOT TIGHTEN SCREWS UNTIL COMPLETELY ASSEMBLED"

"DO NOT OVERTIGHT ANY HARDWARE"


WARNING: SMALL PARTS AND HARDWARE NOT FOR CHILDREN UNDER 3 YEARS. ADULT ASSEMBLY REQUIRED.

TABLE OF CONTENTS				
HARDWARES LIST	PAGE 2			
PARTS LIST	PAGE 2 - 3			
PARTS' LOCATION	PAGE 4			
ASSEMBLY STEPS	PAGE 5 - 12			
ASSEMBLY COMPLETED	PAGE 13			

^{**}COFFEE TABLE ASSEBLY STEP START FROM STEP 1 TO 8.

ASSEMBLY TOOLS REQUIRED

1. Screwdriver (not provide)



Skip the power drill this time.



^{**}END TABLE ASSEBLY STEP START FROM STEP 9 TO 16.

ASSEMBLY INSTRUCTION				
HARDWARES LIST				
ITEM	DESCRIPTION	DRAWING	QTY	
А	MINIFIX CAM LOCK		52 PCS	
В	MINIFIX CAM BOLT		52 PCS	
С	WOOD DOWEL (M8 x 25MM)		32 PCS	
D	PANHEAD SCREW (M4 x 28MM)		8 PCS	
COFFEE TABLE PARTS LIST				
ITEM	DESCRIPTION	DRAWING	QTY	
1	TOP PANEL	<u> </u>	1 PC	
2	CENTRE PANEL	· · · · · · · · · · · · · · · · · · ·	1 PC	
3	SUPPORT PANEL		4 PCS	
4	SUPPORT LEG		4 PCS	

FND TABLE PARTS I	IQT


LIND TABLET ACTORIOT				
ITEM	DESCRIPTION	DRAWING	QTY	
7	TOP PANEL	<u> </u>	2 PCS	
8	BOTTOM PANEL	0 0 0	2 PCS	
9	LONGER APRON		4 PCS	
10	SHORTER APRON		4 PCS	
11	SUPPORT LEG (i)		4 PCS	
12	SUPPORT LEG (ii)		4 PCS	


ASSEMBLY INSTRUCTION PARTS ' LOCATION COFFEE TABLE x 1 PC 2 4 4 END TABLE x 2 PCS 7 10 (10) 11 8 11

ASSEMBLY STEPS

STEP 1


Insert 8 pieces (B) to (1) as shown.






STEP 2


Insert 4 pieces (A) to (2) as shown.




STEP 3


Insert 2 pieces (A), 3 pieces (B), 6 pieces (C) to (4) as shown.






STEP 4 Insert 2 pieces (A) to (3) as shown.






STEP 5

Combine 4 pieces (3) to 2 pieces (4) then tighten the 4 pieces (A)-(pre insert in step 4) as shown. Attention the direction of (4).




STEP 6

Combine (2) to (4) then tighten the 2 pieces (A)-(pre insert in step 2) as shown. Attention the direction of (2) and (3).




STEP 7

Combine the remaining 2 pieces (4) to (2),(3) then tighten the 6 pieces (A)-(pre insert in step 2 and 4) as shown.




STEP 8

Combine (1) to (4) then tighten the remaining 8 pieces (A)-(pre insert in step 3) as shown.




STEP 9

Insert 4 pieces (B) to (7) as shown.




STEP 10

Insert 4 pieces (A) to (8) as shown.



STEP 11


Insert 6 pieces (A) to (10) as shown.




STEP 12

Separate insert 3 pieces (B),1 piece (C) to (11),(12).








STEP 13


Combine 1 piece (10),(11), another 1 piece (10),(12) then tighten the 4 pieces (A)-(pre insert in step 11) as shown. Attention the direction of (10).






STEP 14

Combine (8) to (11),(12) then tighten the 2 pieces (A)-(pre insert in step 10) as shown.



STEP 15

Combine the remaining 1 piece (11),(12) to (8),(10) tighten the 6 pieces (A)-(pre insert in step 10 and 11) as shown.



STEP 16

Combine (10) to (1) then tighten the 4 pieces (A)-(pre insert in step 11). Insert 4 pieces (D) to combine (9),(11),(12) as shown.

