

Assembly Instructions

How to Install a Back on a La-Z-Boy® Recliner

Please read through all instructions prior to beginning the repair.

NOTICE – To prevent damage to electrical components:

If installing a back on a style with electrical features, some or all electrical connections must be made before installing the back. Electrical connections vary by style; refer to the appropriate operating instructions manual, available online and in ASAP, for complete information.

Tools Required:

Standard Screwdriver

⚠ WARNING – Risk of injury:


Do not operate the unit until the back is installed and locked.

To Install the Back:


1. Lay the back across the arms of the body with the top of the back toward the front of the chair.



2. Lift the locking levers, located on the brackets attached to the back (one on each side), to a 90 degree angle. This will make locking the back easier once the back has been installed. Refer to the image at the top, right column.



3. Locate the brackets on the body. Notice the brackets can be adjusted in and out. Pull both brackets out away from the arm.



4. Lift the back at a slight angle, aligning the brackets on the back with the brackets on the body.

If installing a back on a unit with connections to be made between the back and the body, carefully rotate the back until the connectors on the back are able to reach the connectors on the body. Make the appropriate connections, making sure they are fully seated and the locking covers are closed.

For best results, hold the back with one hand at the top of the back and one hand at the bottom of the back to guide the back into position.



5. Lower the back onto the body, making sure the back and body brackets are completely engaged.

Assembly Instructions

6. To make sure the back is properly installed with both sets of back and body brackets engaged, stand behind the chair and gently move the back from side to side. If one or both sides move out of position, the brackets are not engaged. Remove the back and start over.



7. Lock both back brackets. Use a screwdriver to push the locking levers down completely.



8. For power units, connect the power transformer to the recliner.

⚠ DANGER – Risk of electric shock, serious injury or death:

Plug directly into a wall outlet. Do not use an extension cord or adapter.

9. For power units, plug the 120 volt power cord directly into a wall outlet.

To Remove the Back:

1. For power units, unplug the electrical plug from the wall outlet, disconnect all electrical connections behind the unit, and disconnect all connections between the back and the body.

Refer to the appropriate operating instructions manual, available online and in ASAP, for complete information.

2. Unlock both back brackets using a screwdriver to push the locking levers up.
3. If applicable, lift up on the back only high enough to disconnect any electrical connections between the back and the body.
4. Lift the back off the body.