




























































12 x 16FT
























□ □ □ □ □ □ □ □ □ □ WQG056 □ □ □ □ □ □ □ □ □ □




Assembly by more than one person is suggested.






 M6x35mm 1 x84	 2 x178	 M6x55 3 x34	 (4Door) x48  (4Track) x48
 M6x15mm 5 x126	 6 x8	 7 x4	 8 x4
 M6x25mm 9 x136	 10 x40	 M6 11 x72	 12 x16
 13 x16	 14 x16	 15 x16	 4mm 16 x1
 6mm 17 x1	 18 x1	 19 x2	 M6x40mm 20 x11
 21 x4	 B2 x2		


Before installing the sunshade, you should prepare the following tools for installation:
Ladder
Screwdriver
Allen wrench
Rubber hammer
Cordless drill




(A) x2



(A1) x2




(B) x4



(B1) x2



(B2) x2



M6x35mm

(1) x24



(2) x24



(C) Left x1



(C) Right x1



(C1) x1



(C2) x1




(C3) x2



(C4) x2

<1>



Step 1: first determine the location, and then arrange it in a regular manner.

① As shown in the picture: 12FT positions C , C2 and C1 are placed together. 16FT positions C3 and C4 are placed together.

② As shown in the picture: Connect door piece A and A1 to bottom C, C2 and C1 at the 12FT position, then use screw 1 and gasket 2 to pass through door piece A and A1, connect to bottom, and tighten the screws.

③ Connect the B and B1 door pieces to the bottom C3 at the 16FT position. Then use screw 1 and gasket 2 to pass through door piece B and door piece B1, connect to bottom C3, and tighten the screws.



④ x4





M6x35mm

① x36



② x36

<2> Note: There are additional accessories in D parts. Please take them out before assembling D.



Step 2:

① As shown in the picture: between door piece A and door piece B, put column D in, use screw 1 and gasket 2 to pass through door piece A, connect to column D, and tighten the screws.

② As shown in the picture: Connect door pieces B and B1 at the 14FT position, then use screw 1 and gasket 2 to pass through door piece B1, connect to door piece B, and tighten the screws. Note: All hole positions must be aligned.




X x4




(4Track)x24

<3>




Step3:As shown in the picture: insert the lower track X into the bottom, use self-tapping screws 4 to pass through the lower track and connect to the bottom, and tighten the screws. (It is recommended to use a cordless electric drill)



Z x4

<4>




7


Please be aware: If the Z component is too snug in door piece B.B1, you can employ pliers to gently clamp the frames of both door piece B and B1 outward, angling them to ease installation.

<5>


12FT



E x4



E1 x4



E2 x2



F1 x2




F x2



F2 x2



F3 x2





M6x55

3 x34




2 x34

8



16FT

x2






M6x35mm

1 x24




2 x24



(4Track)x24

<6>




M6x15mm

5 x8















2 x8

<7>




9





(H) x4



(I) x1




M6x15mm

(5) x10



(W) x1

<10>




(2) x4



M6x15mm


(5) x4

<11>



Note:

1. Let one person stand on the ladder to lift "I" and hold and let others fasten the screws connecting both ends of "H".
2. Please do not let go of holding "I" until all the "H" screws are installed.



J x8







2 x16




M6x15mm

5 x32


<12>



K x2



K1 x2



K2 x2






8 x4







M6x25mm

9 x12







<13>




12








<14>




<15>



<16>






(N) x1





M6x45mm

(20) x3




(19) x2


<17>




(O) x4



(O1) x4



(O2) x4



(6) x8



(7) x4




M6x15mm



(5) x36

15



<18>




<19>



<20>



<21>





<22>

Y x72



M6x25mm

9 x112






M6

11 x72



10 x40






(4 Door) x12



T x6




R x6




S x6



P x12



12 x6



13 x6



14 x6



15 x6




Q x18

20


<23>


x6



<24>

x6






(4 Door) x12



U x6



12 x6



13 x6



14 x6






15 x6

<25>

(4 Door)

x6







(4Door) x12



T x6




Rr x6



S x6



P x12



12 x6




13 x6



14 x6




15 x6




Q x18

<26>


x6



<27>




x6



(4Door) x12



Uu x6



12 x6



13 x6





14 x6





15 x6

<28> x6




<29>





V x4



V1 x4




M6x15mm

5 x12

<30>

Release the screw first, adjust the appropriate height of this plate, and then lock the screw to prevent the door falling off.



CARTON-1/9		CARTON-6/9		CARTON-8/9	
Part	Oty	Part	Oty	Part	Oty
M	4	H	4	E	4
M1	4	T	8	E1	4
M2	4	P	16	E2	2
M3	4	S	8	G	2
M4	4	U	4	G1	2
M5	2	R	4		
M6	4	Rr	4	CARTON-9/9	
M7	4	Uu	4	Part	Oty
M8	4	Y	72	D(There are additional accessories in D parts, please take them out.	4
		V	4		
CARTON-2/9		V1	4	I	1
Part	Oty	W	1	N	1
A	2	1.2.3.4.5.6	1	K	2
A1	1	.7.8.9.10.1			
M5	2	1.16.17.18			
		.19.20			
CARTON-3/9		12	16	K1	2
Part	Oty	13	16	K2	2
A1	1	14	16	L	2
B	1	15	16	L1	2
Q	24	21	4	L2	2
				O	4
CARTON-4/9		CARTON-7/9		O1	4
Part	Oty	Part	Oty	O2	4
B	3	C Left	1	X	4
M9	4	C Right	1	Z	4
		C1	1		
CARTON-5/9		C2	1		
Part	Oty	C3	2		
B1	2	C4	2		
B2	2	F	2		
		F1	2		
		F2	2		
		F3	2		
		G2	2		
		G3	2		
		J	8		