



12'x12' Metal Patio Gazebo

ASSEMBLY MANUAL



MODEL#: LGMF1669

Missing part? Damaged? Contact us via email at

service@domioutdoorliving.com

www.domioutdoorliving.com

Pre-assembly



1. Two or more people are required for assembly.



2. You will need one or more stepladders.



3. Wearing protective gloves is recommended.



4. You may need a safety hat.



5. Please use a Phillips screw driver.



6. For ease of construction, you may need a drill.



7. You may need a safety goggle.



8. Do not fully tighten screws prior to complete assembly.

Warning & Attention



-Try to assemble this product on the flat ground, otherwise it is difficult to carry out;

-It would be much easier to assemble the product with three or more people;



-After assembly, please check whether all screws are tightened, to prevent parts from falling apart.

▲ Use bolts to secure the frame to the ground to against the strong wind.

IMPORTANT: A gaze may entail to purchase a municipal permit or be subject to specific building codes. It is the consumer's responsibility to inform themselves of any restrictions.





1




x12

If the deck is hard wood and the depth of it is over 3 inch, you can use **5/16 in. x4 in. Structural Wood Screw** to mount the gazebo.






2




If the ground is concreted and the depth of it is over 3 inch, you can use 1/4 inch expansion bolts to mount the gazebo



















3














Or you can make a concrete footing for gazebo, **15×15×15 inches** is recommended. use expansion bolts to mount the pergola like ② shows.

IMPORTANT:
Anchor is not recommended




 <p>Pole 2080 A (x4)</p>	 <p>Joint Cover G (x4)</p>
 <p>Beam 1715 B1 (x4)</p>	 <p>Silicone Sealant H (x1)</p>
 <p>Beam 1715 B2 (x4)</p>	 <p>Corner Solidifying Bar 578 J1 (x4)</p>
 <p>Track 1583 C1 (x4)</p>	 <p>Corner Solidifying Bar 578 J2 (x4)</p>
 <p>Track 1583 C2 (x4)</p>	 <p>Base K (x4)</p>
 <p>Outside Roof Cover D1 (x1)</p>	 <p>Base Cover K1 (x4)</p>
 <p>Inside Roof Cover D2 (x1)</p>	 <p>Bracket K2 (x8)</p>
 <p>Union Bar 600 E (x4)</p>	 <p>Corner Roof Tube Connector 960 L (x4)</p>
 <p>Corner Cover F (x4)</p>	 <p>Corner Roof Tube 1860 L1 (x4)</p>

 <p>Roof Tube 1927 M (x4)</p>	 <p>Bracket U4 (x4)</p>
 <p>Finishing Bar 1102 N (x4)</p>	
 <p>Finishing Bar 1382 O (x4)</p>	
 <p>Mesh P (x1)</p>	
 <p>Finishing End Q (x8)</p>	
 <p>Hooks R1 (x1)</p>	
 <p>Black Rubber S (x116)</p>	
 <p>Solidfying Bar 1085 U (x8)</p>	
 <p>Bracket U3 (x4)</p>	




M6x16

1#
x192




M6x25

10#
x4




M6x20

2#
x24




M6x12

11#
x8




3#
x16




ST6.3*15

12#
x4




4#
x112




M6x28

5#
x72



M6x45

6#
x8



M6x50

7#
x32











M5x16

8#
x4



ST4.8x13

9#
x24



W1 (x4)

W2 (x4)

W3 (x4)


W4 (x4)

W5 (x4)


W6 (x4)

W7 (x4)


W8 (x4)



Mosquito Netting





Strap




Solid Sidewall


Plastic Clips




x1



x1





x1



Plastic Bar




Pa (x4)

POST ASSEMBLY:





(1) Attach 2 Part #K2 to Part #A with 6 Bolts #1.
Repeat the above procedures to assemble the other 3 Poles.

X4




(1) Put on Base Cover
#K1 first;


(2) Attach Base #K to
Pole #A with 3 Bolts
#1.



(1)



(2)



X4



C1 (x4)




4#
x112



C2 (x4)


(1) Slide the Plastic Hooks #4 to the double-rail track #C1 (each slot should slide 7 plastic hooks).

(2) Repeat the above procedures for the other 3 tracks C1.




(1) Slide the Plastic Hooks #4 to the double-rail track #C2 (each slot should slide 7 plastic hooks).

(2) Repeat the above procedures for the other 3 tracks C2.






B1 (x4)




B2 (x4)



E (x4)


1#
x32

BEAM ASSEMBLY




- (1) Insert Part #E into Part #B2, and secure with 4 Bolts #1.
- (2) Insert the other side of Part #E into Part #B1 and secure with 4 Bolts #1.



Repeat the above procedures to assemble the other Part #B2 and #B1.



TIPS: It's a normal situation that there's a gap between the 2 beams, please use silicone sealant (part #H) and Joint Cover #G to affix the gap.(see P9)




(1) Use 8 Bolts #1 to fix the track C1 & C2 to the beam B2 & B1.
Repeat the above procedures for other 3 beams B2 & B1.







2#
x16




3#
x16

FRAME ASSEMBLY:




Inside View






Outside View

Please don't tighten
all bolts.



Inside View

CORNER SOLIDIFYING BAR ASSEMBLY:



Outside View







F (x4)






9#
x16

CORNER COVER & JOINT COVER ASSEMBLY:





Use 5mm silicone sealant(part #H) and Joint Cover #G to affix the gap.






L (x4)




L1 (x4)




2#
x8

CORNER ROOF TUBE ASSEMBLY:





(1) Connect Part #L1 and Part #L with 2 Bolts #2.
Repeat the above procedures to assemble the
other 3 Corner Roof Bars.




D2 (x1)

CORNER ROOF TUBE AND INSIDE ROOF CONNECTOR ASSEMBLY:






Place 4 Corner Roof Tubes on the 4 corners of Inside Roof Cover #D2,secure with 8 Bolts #1 (from bottom to top).




Lift 4 corner roof Tubes and inside roof connector to the top of the frame.(You may need 2 people and 2 ladder).


1#
×4

Secure with 4 Bolts #1.



INSIDE VIEW








M (x4)

1#
x12

MIDDLE ROOF TUBE ASSEMBLY:




INSIDE VIEW




INSIDE VIEW


Check the the frame as pictures below shows.




Frames in Parallelogram shape



Frames in rectangular shape



D1 (x1)



P (x1)



R1 (x1)







Pa (x4)


OUTSIDE ROOF COVER AND MESH ASSEMBLY :



(1) Install the Plastic Bar #Pa to the Mesh #P.

(2) Place the Outside Roof Cover on the inside Roof Cover.


(3) Align the holes and use 1 Hook #R1 to secure Mesh #P to the inside Roof Cover (From Bottom to Top).












BOTTOM VIEW



INSIDE VIEW






Please do not pull plastic bar out when installing it with #N on the middle roof tube #M.






Plastic Bar
on the mesh




INSIDE VIEW




Remove the protective film of the panels before installing the roofing panels,




Please install Clips in strict accordance with the instructions.




Attach Part #Z,#Z1,#Z2 by lightly tapping with screwdriver.




If you can't install #V2 & #V3, push the Outside Roof Cover up and try to insert them again.











SOLIDIFYING BAR ASSEMBLY:




INSIDE VIEW







Install the Middle Panels (#W4,W5) first, then the small panels on the edge.



Remove the protective film of the panels before installing the roofing panels,



The Black Rubber #S should be assembled when installing the roof panels; please see the next page.






S x116

5#
x72

6#
x8


7#
x32

10#
x4




S x4




10#
x4




Solidifying Bar



Middle Roof Tube





Middle Roof Tube







④

Beam


5#

5#






Y (x4)









Yb (x4)



Ya (x4)

MOSQUITO NETTING AND SOLID SIDEWALL ASSEMBLY:







Ya


Y

Ya



Y

Ya



Yb

Please close your gazebo curtain when it is incoming over 30 mph wind, and tie with Strap #Yb.



Thanks for your purchase.

At domi outdoor living, we believe in our products.

That's why we provide a 12-month warranty and friendly, easy-to-reach after-sales service. So, if you have any questions about our product or assembly, please feel free to contact us. We are here for you.

Support:  

After-sales contact email:

service@domioutdoorliving.com

Business cooperation contact email:

marketing@domioutdoorliving.com

Please have your order ID available if you reach out for support.

If you have damaged parts or product, please send us photos for an immediate response.