



NOTE: THE APPEARANCE OF FIXTURE AND QUANTITY OF SOCKET(S) IS SUBJECT TO THE ACTUAL FIXTURE YOU RECEIVED, WHICH IS DIFFERENT FROM THE FIGURE IN THIS INSTRUCTION SHEET, BUT IN SAME INSTALLING WAY AS ABOVE.

## (3) INSTALLING INSTRUCTIONS

FEED FIXTURE WIRES AND GROUND WIRE THROUGH 17 ROD, SCREW ONE END OF 17 ROD ONTO 8 FIXTURE AND THE OTHER END INTO 15 HEX COUPLING TIGHTLY.

15 HEX COUPLING AT FIXTURE END HAS A DRIPPING HOLE WHICH CAN ALLOW
THE INFILTRATED WATER COME OUT. WHEN THREADING 17 ROD ONTO 8 FIXTURE, IT IS OPTIONAL TO USE THE PIPE SEALANT.

## (4) INSTALLING WAY:

- OUTLET BOX IN THE BUILDING: PULL OUT THE SUPPLY WIRES AND GROUND WIRE FROM THE OUTLET BOX AND PASS THROUGH THE WIRE OUTLET HOLE ON (12 ROUND UNIVERSAL BAR).
- 2 LONG SCREWS 2PCS: PLACE THE SUPPLIED 2 LONG SCREWS
  THROUGH THE HOLES IN (2 ROUND UNIVERSAL BAR),
  ADJUST TO DESIRED LENGTH AND SECURE TIGHTLY WITH
  (13 HEX NUTS).THIS WILL PREVENT (2 LONG SCREWS)
  FROM ROTATING WHEN (7 NUT CAPS) ARE ATTACHED.
- 3 SHORT SCREWS 2PCS: SECURE 12 ROUND UNIVERSAL BAR TO 1 OUTLET BOX WITH THE SUPPLIED 3 SHORT SCREWS
- 4 FIXTURE GROUND WIRE: WIND 4 FIXTURE GROUND WIRE AROUND
  (16 GREEN SCREW) LOCATED ON 12 ROUND UNIVERSAL BAR
  AND CONNECT 4 FIXTURE GROUND WIRE WITH GROUND WIRE FROM
  OUTLET BOX, SECURE WITH (11 WIRE CONNECTOR) (PROVIDED).
- WIRE CONNECTORS 2PCS: CONNECT FIXTURE WIRES AND WIRES FROM OUTLET BOX WITH (5 WIRE CONNECTORS). CAREFULLY TUCK ALL WIRE CONNECTORS INTO OUTLET BOX AND ENSURE THAT NO WIRE CONNECTORS ARE LOOSE AND NO BARE PARTS OF WIRES ARE EXPOSED.
- 6 CANOPY
- 7 NUT CAPS 2PCS : MAKE & LONG SCREWS PASS
  THROUGH THE HOLES OF & CANOPY , AND
  SECURE & CANOPY AGAINST CEILING WITH 7 NUT CAPS
- 8 FIXTURE
- TURN ON ELECTRICITY AFTER ASSEMBLING THE BULBS
  TO TEST IF THE ELECTRICITY CAN WORK NORMALLY.
  (MAKE SURE THE BULBS CAN WORK)
- GLASS SHADE: TWIST 10 GLASS SHADE INTO 8 FIXTURE AT
  CLOCKWISE DIRECTION TILL IT CAN NOT ROTATE ANY LONGER MAKE SURE
  10 GLASS SHADE BE FIXED FIRMLY TO AVOID ANY RISK OF FALLING OFF.
  WHEN TAKING 10 GLASS SHADE OFF, PLEASE TURN IT AT
  COUNTERCLOCKWISE DIRECTION. PLEASE BE CAUTIOUS WHEN INSTALLING OR
  TAKING 10 GLASS SHADE OFF TO PREVENT 10 GLASS SHADE BREAKAGE.
- DRAW APART THE CUT OF (BWIRE GUARD) AT OPPOSITE DIRECTION
  BY HAND TO MAKE IT LARGE ENOUGH TO LET SHADE ON (BFIXTURE
  SNAP IN, THEN FIX (18 WIRE GUARD) WITH (14 SCREW) TO PREVENT IT
  FALLING OFF.