

WARNING!!

Children have died from furniture tipover. Tip restraints have been included with this product; you must install the tip restraints according to these instructions in order to minimize the risk of furniture tipping. If you have any questions about this product or the tip restraint, please send us an email at tip_restraint_help@Noblehousefurniture.com

NEVER allow children to climb or hang on furniture, including drawers or cabinet doors.


In addition to installing the restrains, to help prevent tip-over
1. NEVER put a TV or other heavy objects on top of this product.
2. Do not stand on the product

 WARNING	
	<p>Children have died from furniture tipover. To reduce the risk of furniture tipover:</p> <ul style="list-style-type: none">• ALWAYS install tipover restraint provided.• NEVER put a TV on this product.• NEVER allow children to stand, climb or hang on drawers, doors, or shelves.• NEVER open more than one drawer at a time.• Place heaviest items in the lowest drawers.• Do not defeat or remove the drawer interlock system. <p><i>This is a permanent label. Do not remove!</i></p>
	




Assembly Instructions










Caution : You must read this before you proceed

SHOE CABINET























Parts List

Label	Picture	Description	QTY
A		Top Panel	1
B		Left Side Panel	1
C		Right Side Panel	1







D		Center Panel	1
E		Left Door Panel	1
F		Right Door Panel	2
G		Long Shelf Panel	2
H		Short Shelf Panel	2
I		Back Panel	2
J		Bottom Panel	1
K		Handle	3
L		Leg	5

Hardware

Label	Picture	Description	QTY
①		Cam Lock	7
②		Cam Bolt	7
③		Cam Cap	7
④		Positioning Dowel (φ 8*30mm)	23
⑤		Cap Wood Screw (M6*50mm)	7
⑥		Screw (M3.5*16mm)	45
⑦		Screw (M4*32mm)	7
⑧		Cap Wood Screw (M6*60mm)	5
⑨		Allen Key	1
⑩		Connector	6
⑪		Metal Shelf Support	17
⑫		Stopper	2
⑬		Screwdriver (not provided)	1
⑭		Hammer (not provided)	1
⑮		Power Drill (not provided)	1


Cabinet Restraint Device Hardware			
①6		Metal Bracket	4
①7		Wall Plug	2
①8		Wall Plug Screw	2
①9		Pan Head Screw	2
②0		Cabinet Restraint Strap	2

Assembly Preparation

Before Beginning Assembly:	 <p>The diagram illustrates the components and tools required for assembly. It includes various cabinet panels, shelves, and drawers, along with hardware such as screws, brackets, and straps. Each item is accompanied by a quantity in a box, such as X 7, X 23, X 7, X 45, X 5, X 1, X 6, X 17, X 1, X 2, X 3, X 5, and X 2.</p>
<ul style="list-style-type: none">  • Read instructions, cover to cover-  • Have 2 adults on hand for assembly-  • Do not assemble on flooring or carpet-  • Assemble on a clean non-marring surface (packing foam)-  • Save all packaging until finished- 	


Assembly Steps

Overview



This Shoe Cabinet has multiple parts and may require up to 60 minutes to assemble. To give you an overview of the Shoe Cabinet parts, the above picture is to help you put the various parts into perspective. Please read through the instructions below to familiarise yourself with the parts and steps before assembly.




Step 1




Unpack and place all parts on a clean, non-marring surface.


1.1) Insert Cam Bolts(2) into mounting positions on Top Panel(A) with Screwdriver(13).

1.2) Attach Stopper(12) to Top Panel(A) with Hammer(14).

<p><u>Step 2</u></p>	 <p>The diagram shows a rectangular panel labeled 'B'. On the left side, there are two mounting positions. Callout 2.1 shows a cam lock (1) being inserted into the top position. Callout 2.2 shows a positioning dowel (4) being inserted into the bottom position. The panel has four mounting positions in total, two on each side.</p>
<p>2.1) Insert Cam Locks(①) into mounting positions on Left Side Panel(B) by hand.</p> <p>2.2) Insert Positioning Dowels(④) into mounting positions on Left Side Panel(B) by hand.</p>	
<p><u>Step 3</u></p>	 <p>The diagram shows a rectangular panel labeled 'C'. On the right side, there are two mounting positions. Callout 3.1 shows a cam lock (1) being inserted into the top position. Callout 3.2 shows a positioning dowel (4) being inserted into the bottom position. The panel has four mounting positions in total, two on each side.</p>
<p>3.1) Insert Cam Locks(①) into mounting positions on Right Side Panel(C) by hand.</p> <p>3.2) Insert Positioning Dowels(④) into mounting positions on Right Side Panel(C) by hand.</p>	
<p><u>Step 4</u></p>	 <p>The diagram shows a rectangular panel labeled 'D'. On the center, there are two mounting positions. Callout 4.1 shows a cam lock (1) being inserted into the top position. Callout 4.2 shows a positioning dowel (4) being inserted into the bottom position. The panel has four mounting positions in total, two on each side.</p>
<p>4.1) Insert Cam Locks(①) into mounting positions on Center Panel(D) by hand.</p> <p>4.2) Insert Positioning Dowels(④) into mounting positions on Center Panel(D) by hand.</p>	




Insert Positioning Dowels(④) into mounting positions on Back Panel(G) by hand.



Attach Handle(K) to Left Door Panel(E) using Screws(⑦) with Screwdriver(⑬).

Tighten the Screws fully in a sequential manner.

Note: There are pre-existing mounting positions on the Left Door Panel(E) to attach the Handle.




Attach Handles(K) to Right Door Panels(F) using Screws(⑦) with Screwdriver(⑬).

Tighten the Screws fully in a sequential manner.

Note: There are pre-existing mounting positions on the Right Door Panels(F) to attach the Handles.

Step 8




Attach Connectors(⑩) to Left Door Panel(E) using Screws(⑥) with Screwdriver(⑬).

Tighten the Screws fully in a sequential manner.

Note: There are pre-existing mounting positions on the Left Door Panel(E) to attach the Handle.

Step 9




Attach Connectors(⑩) to Right Door Panels(F) using Screws(⑥) with Screwdriver(⑬).



Tighten the Screws fully in a sequential manner.

Note: There are pre-existing mounting positions on the Right Door Panels(F) to attach the Handles.


Step 10



Attach Positioning Dowels(④) from Back Panel(I) into mounting positions on the other Back Panel(I).

<p><u>Step 11</u></p>	 <p>The diagram shows a perspective view of a shoe cabinet assembly. A circular callout on the left contains a small cylindrical dowel labeled with a circled 4. Two lines from this callout point to the junctions of the back panel (labeled I) with the left side panel (labeled B) and the right side panel (labeled C). The panels are shown in a partially assembled state.</p>
<p>Insert Positioning Dowels(④) from Back Panel(I) into mounting positions on Left Side Panel(B) and Right Side Panel(C).</p>	
<p><u>Step 12</u></p>	 <p>The diagram shows the back panel (labeled I) being attached to the shoe cabinet assembly. A circular callout on the left shows a cap wood screw labeled with a circled 8 and an Allen key labeled with a circled 9. Two lines from this callout point to the screws being driven into the back panel. The back panel is shown being aligned with the side panels (B and C) and the bottom panel (D). Blue arrows indicate the direction of assembly.</p>
<p>Attach Back Panel(I) to Shoe Cabinet Assembly using Cap Wood Screws(⑧) with Allen Key(⑨).</p>	

Step 13




13.1) Insert Positioning Dowels(④) from Left Side Panel(B), Right Side Panel(C) and Center Panel(D) into mounting positions on Top Panel(A).

Note: Ensure the arrows on Cam Locks head points towards the Cam Bolt mounting positions.

13.2) Insert the mounting positions on side of Left Side Panel(B), Right Side Panel(C) and Center Panel(D) onto Cam Bolts(②) on Top Panel(A).


13.3) Turn the Cam Locks(①) clockwise with the Screwdriver(⑬) until they all lock into place.

Step 14




14.1) Insert Positioning Dowels(④) from Left Side Panel(B), Right Side Panel(C) and Center Panel(D) into mounting positions on Bottom Panel(J).

14.2) Attach Bottom Panel(J) to Shoe Cabinet Assembly using Cap Wood Screws(⑤) with Allen Key(⑨).




Attach Legs(L) to Bottom Panel(J) using Screws(⑥) with Screwdriver(⑬).


Note: There are pre-existing mounting positions on the Bottom Panel(J) to attach the Legs(L).



Attach Cam Caps(③) to all Cam Locks(①) by hand.




Insert Metal Shelf Supports(⑪) into mounting positions on Left Side Panel(B), Right Side Panel(C) and Center Panel(D) by hand.



Put Long Shelf Panels(G) and Short Shelf Panels(H) in place on Metal Shelf Supports(⑪).

Note: There are lead mounting positions on Long Shelf Panels(G) and Short Shelf Panels(H) to fit Metal Shelf Supports(⑪).

Step 19



19.1) Attach Connectors(⑩) to Left Side Panel(B), Right Side Panel(C) and Center Panel(D) with Screws(⑥) using Screwdriver(⑬).

Tighten the Screws fully in a sequential manner.

19.2) Rotate first screw on Connectors(⑩) to adjust left-right position of Left Door Panel(E) and Right Door Panels(F) when necessary.

19.3) Rotate second screw on Connectors(⑩) to adjust in-out position of Left Door Panel(E) and Right Door Panels(F) when necessary.


Note: There are pre-existing mounting positions on the Left Side Panel(B), Right Side Panel(C) and Center Panel(D) to attach the Connectors(⑩).

Cabinet Restraint Device Installation Instructions

WARNING

Serious or fatal crushing injuries can occur from tipping furniture.
To help prevent tip-over: ALWAYS secure this furniture to the wall using Cabinet Restraint Device.

See product instructions for more ways to help prevent furniture tip-over.




Usage For Cabinet Restraint Device:

To secure Shoe Cabinet against wall, attach two Metal Brackets(16) on wall and product, use Cabinet Restraint Strap(20) to connect the Metal Brackets(16).

Instructions:


Step 20



20.1) Turn the Shoe Cabinet so the back side faces you.

20.2) Attach Metal Brackets(16) to Back Panel(I), where labeled, using Pan Head Screws(19) with Screwdriver(13).

Step 21



21.1) Drill two holes on wall at same height as Metal Brackets(16) on Shoe Cabinet with Power Drill(15).

You can mark these points in two ways as below:


1) Move the Shoe Cabinet back to the wall. Mark two points same height as Shoe Cabinet on the wall.

Note: The Metal Brackets need to be secured to solid, load bearing surface. Please use a Stud Finder(not supplied) if needed to locate the Wall Frame.



2) Measure the height of the Metal Brackets(16) with ruler/measuring tape and mark on wall to keep them accurate and same height.

21.2) Insert Wall Plugs(17) into drilled holes on wall with Hammer(14).

Step 22



Attach Metal Brackets(16) to Wall Plugs(17) using Wall Plug Screws(18) with Screwdriver(13).

<p><u>Step 23</u></p>	
<p>Move Shoe Cabinet to the wall. Pull the Restraint Straps(20) through the Metal Brackets(16) on the wall and Shoe Cabinet one by one, and pull the Restraint Straps(20) tight.</p>	
<p><u>Step 24</u></p>	
<p>Your Shoe Cabinet is ready for use. This Shoe Cabinet can only be used on a flat, level surface.</p>	

Care & Maintenance



- Furniture may scratch floors. We recommend using furniture pads to protect your floors.



- Do not put hot items directly on furniture surface.



- Do not clean furniture with harsh cleansers or polish.



- Do not place furniture under direct sunlight.



- Do not place furniture near heating or cooling vents.



- Do not write on furniture without a padded barrier to protect the surface.



- Do not place furniture outside . For indoor use only.



- Not for commercial use. For residential use only.



- Stains may be removed with mild soap solution and damp cloth.



- Children should not climb or jump on the furniture.



- Dust and pick-up spills using a clean, non-colored, lint-free cloth.