



Installation & Assembly














Installation Diagram



Specification name: two drawer nightstand


Parts List

<p>①</p>  <p>400*400*17MM 1PC</p>	<p>②</p>  <p>400*400*17MM 1PC</p>	<p>③</p>  <p>316*400*27MM 1PC</p>
<p>④</p>  <p>316*400*27MM 1PC</p>	<p>⑤</p>  <p>366*55*17MM 2PCS</p>	<p>⑥</p>  <p>326*376*5MM 1PC</p>
<p>⑦</p>  <p>150* 45MM 4PCS</p>	<p>⑧</p>  <p>360*153.5*29MM 2PCS</p>	<p>⑨</p>  <p>300*120*12MM 4PCS</p>
<p>⑩</p>  <p>332*120*12MM 2PCS</p>	<p>⑪</p>  <p>342*286*5MM 2PCS</p>	



NOTE

Using the right screws can prevent damage to these components

Example













Mistake: Screws can cause boards to split




Correct: screws are the correct size

Specification name: two drawer nightstand


Hardware Table

<p>A</p>  <p>L=40MM 22+2PCS</p>	<p>B</p>  <p>15*11MM 22+2PCS</p>	<p>C</p>  <p>8*30MM 8+1PCS</p>
<p>D 平头快速牙</p>  <p>#8*30MM 16+2PCS</p>	<p>E</p>  <p>L=50MM 2PCS</p>	<p>F</p>  <p>#3.5*15MM 2+1PCS</p>
<p>G</p>  <p>M6*136MM 1PC</p>	<p>H</p>  <p>20MM 14+2PCS</p>	<p>I</p>  <p>1PCS</p>
<p>J Installed</p>  <p>M6*Φ19*15MM 4PCS</p>		


All-in-one Ratchet Screwdriver Instruction Manual




How to use the cam lock system




1. Screw cam bolt into panel




2. Push cam into panel - arrow feature on cam top points to panel edge



3. Align cam bolt(s) with cam(s) and insert all the way into cross-bored hole(s)




4. Rotate cam(s) clockwise 190°-230° to lock panels together



5. Panels should be tight against each other and connection should be rigid

Insert the wood dowel (A) at least half way by tapping lightly with a rubber mallet, IF NECESSARY




⚠ WARNING


- Unit must be placed on a level surface or leveled with included hardware (when applicable).
- Do not sit or stand on or allow children to climb, sit or stand on the assembled product.
- For safety reasons, it is imperative that this unit be mounted to the wall.
- Do not use without installing the tip restraint.
- Unit can tip over causing severe injury or death.
- Do not exceed the recommended weight limits.
- Evenly distribute the weight on each level and always keep the heavier loads on the bottom.
- Before cutting, drilling or hammering into any wall or floor surface, verify the location of electrical, plumbing and gas lines. Cutting may cause serious injury.

Specification name: two drawers nightstand


Step 1



3





A




4


As shown, hardware A is secured to part 3/4 with tool G

A	 L=40MM	8PCS
G	 M6*136MM	1PC


Step 2




1



A







2



E


F

As shown, attach hardware A to part 1/2 with tool G.
Attach hardware E/F to part 1/2 with tool G.




A	 L=40MM	14PCS	E	 L=50MM	2PCS
G	 M6*136MM	1PC	F	 #3.5*15MM	2PCS

Specification name: two drawers nightstand


Step 3






Attach parts 3/4/5 together with hardware B/G. Note the orientation of the hole in the center of part 5, and then cover the hole where part 5 is mounted with hardware H.

B	 Ø15*9MM	8PCS
G	 M6*136MM	1PC
H	 Ø20MM	8PCS

Step 4




As shown, use hardware B/C/G to connect part 1 to the parts grouped in Step3.

B	 Ø15*9MM	6PCS
C	 Ø8*30MM	4PCS
G	 M6*136MM	1PC


Specification name: two drawers nightstand

Step 5






Insert part 6 into the grouped parts of Step 4 as shown

Step 6






As shown, use hardware B/C/G to attach part 2 to the Step 5 grouped parts.




B	 Ø15*9MM	6PCS
C	 Ø8*30MM	4PCS
G	 M6*136MM	1PC

Specification name: two drawers nightstand



Step 7



Attach parts 1/2/5 parts with hardware B/G and cover with hardware H as shown.

B	 Ø15*9MM	2PCS
G	 M6*136MM	1PC
H	 Ø20MM	2PCS



Step 8



Tighten part 7 clockwise onto part 2 as shown.

Specification name: two drawers nightstand



Step 9





►As shown, rotate the appropriate hardware J to adjust the two drawer nightstand to level.

Step 10

Note that there are 2 identical drawers.




Attach parts 8/9 together with hardware D/G as shown.
Note that the same drawer has 2 .

D	 #8*25MM	8PCS
G	 M6*136MM	1PC

Specification name: two drawers nightstand

Step 11


▲ Note that there are 2 identical drawers.





Insert part 11 into Step8 grouped parts as shown. Note that the same drawer has 2 .

Step 12

Note that there are 2 identical drawers.




Attach parts 9/10 together with hardware D/G as shown. Note that the same drawer has 2.

D	 #8*25MM	8PCS
G	 M6*136MM	1PC


Specification name: two drawer nightstand

Step 13




As shown in the picture, place the assembled drawers into the cabinet assembled in Step9.

Step 14



As shown, use hardware I to secure the Step13 grouped parts to the wall

I		1PCS
---	---	------