







INSTALLATION INSTRUCTIONS

10'x12' LEAN TO GAZEBO



REQUIRED TOOLS

Tools			
	Gloves	Table	Ladder
			
	Power drill	Screw driver	Tape Measure

ASSEMBLY TIPS

Handle each part of the gazebo with care, as many components have sharp edges.

DO NOT attempt to assemble the gazebo before verifying that all parts are present as listed. Partially assembled structures can be severely damaged by light winds.

DO NOT attempt to assemble the gazebo on windy days, as this can make construction difficult and unsafe. Monitor the weather closely. During construction and until the gazebo is fully assembled, **keep children and pets away from the worksite to avoid distractions and potential accidents.** Avoid placing weight concentrated on the roof of the gazebo.

ASSEMBLY

The best location is a flat area.

Ensure there is adequate space around the gazebo to access the roof with a ladder.

TEAMWORK:


Two or more people are required to assemble the structure.

Maintenance

- Steel components for this gazebo are treated with rust inhibiting paint . However, due to the nature of steel, surface oxidation (rusting) will occur if these protective coatings are scratched. This is not a defect and thus not covered by the warranty.
- To minimize this condition, it is recommended to use care when assembling and handling the product to prevent scratching the paint. Should any scratching or damage occur, it is recommended to cover the scratch immediately with rust inhibiting resistant paint (not included).
- Do not use bleach, acid, or other abrasive cleaners on the roof or frame parts.
- Keep instruction manual for future reference.
- Keep the original packaging to store the gazebo.
- Periodically check and ensure that all bolts are well-tighten during use.





Installation size diagram

10x12







































Installation size diagram


10x12



Parts List



A X2  Top Back Leg	B X2  Top Front Leg	C X4  Bottom Leg	D1 X4  Side Beam
D4 X2  Middle Beam	E X5  Board Arm	E1 X5  Board Arm	F X4  Board Protection
G X6  Board Protection	G2 X2  Board Protection	H X5  Arm Down Connection	I X15  Arm Hold Tube
I4 X5  Arm Hold Tube	K X16  Board	L X4  Leg Connection	K10 X2  Board
N1 X4  Beam Connection	O X1  Right Beam Hold	P X1  Left Beam Hold	Q X10  Arm&Beam Connection
S X5  Arm Up Connection	U X4  Beam Plug	V X10  Arm Plug	Z2 X15  Middle Beam Connection
Z3 X10  Side Beam Connection	Z X1  Allen Wrench	M X10  Wall Connection&Base	W1 X167  Bolt M6*15
W2 X8  Bolt M6* 70	W4 X10  Bolt M6*35	X X75  Bolt ST4.2*10	X1 X74  Bolt ST4.2*13
X2 X75  Bolt Washer	Y X16  Bolt M6*15	Z5 X20  Expansion Bolt	Z5 X20  Tent stake

STEP 1




X2






2. Fix the A&C connection point with W1 bolts.



X2



4. Fix the B&C connection point with W1 bolts.





 A	x2	 L	x4
 B	x2		
 C	x4	 W1	x32

STEP 2





2. Use W2 to fix M in the specific hole of C.



1. Use W1 to fix M in the specific hole of A.




3. Repeat the last step. Use W2 to fix M in the specific hole of C.




STEP 3

X2

1. Connect D1 and D4 with N1.




3. Use U to plug D1.








X2

2. Fix the D1&D4 connection point with W1 bolts.




X2

	D1 x4		W1 x40
	D4 x2		U x4
	N1 x4		



STEP 4

1. Use Y to fix A/B and D1.



X4



! Note that the installation orientation of D4 must be on the same side.



STEP 5


1. Use W1 to fix O in the specific hole of D1&B.

The opposite side




STEP 6

X5









1. Use W1 to fix Q in the specific hole of E&E1.

2. Connect E and E1 with S, and fix them with W1 bolts.




X2




	E x5		Q x10
	E1 x5		W1 x40
	S x5		

STEP 7

1. Connect D1/D4 and E/E1 with Q,
and fix them with W1 bolts.



X10




W1 x20


STEP 8

1. Connect E and I with Z3, fix them with W1 and X1 bolts.


2. Connect E and I/I4 with Z2, fix them with W1 and X1 bolts.



X2





X3




	I x3		Z3x2
	I4 x1		X1 x8
	Z2x3		W1 x5

STEP 9

! These three holes do not need to be aligned with the holes on E/E1



1. Use V to plug H.




	H x5
	V x10
	W4 x10

STEP 10


! Note: The side holes of I/I4 should face outward.

1. Connect I and I/I4 with Z2, fix them with W1 and X1 bolts.


2. Connect E/E1 and I with Z3, fix them with W1 and X1 bolts.









X12



X8




	I x12		X1 x32
	I4 x4		
	Z2 x12		Z3 x8
			W1 x20


STEP 11

1. Put K on the I/I4 and E1, fix them with X and X2.

2. Stack up K and K10, fix them on I4 with X and X2.




X12





X4

2. Fix K and E1 with X2&X.



X4



STEP 12

1. Fix K and E with X2&X.

2. Stack K and K10, fix them on I4 with X and X2.









3. Put K on the I/I4 and E1, fix them with X and X2.

4. Fix K and K with X&X2.

5. Fix K and K with X&X2.

6. Fix K and K with X&X2.

7. Fix K10 and K10 with X&X2.




X2

X4

X14





X7



STEP 13


1. Use X1 to fix F on E/E1.

2. Stack F, and use X1 to connect them with E.






STEP 14


1. Use X1 to fix G2 and I4.




2. Use X1 to fix G and I.




STEP 15



1. Use X1 to fix G2/G and I/I4.



STEP 16



1. Secure the product to both the wall and the floor using Z5.

