



2 DRAWER DRESSER USER MANUAL




STRUCTURE FOR REFERENCE TO ASSEMBLY

Chest

















Drawer




PARTS IDENTIFICATION

CODE	DESCRIPTION	QTY
1	Top panel	1
2	Left side panel	1
3	Right side panel	1
4	Bottom panel	1
5	Front bottom panel	1
6	Left bottom panel	1
7	Right bottom panel	1
8	Back bottom panel	1
9	Drawer left side panel	2
10	Drawer right side panel	2
11	Lower drawer tail plate	2
12	Bottom panel of lower drawer	2
13	Front panel of drawer	2
14	Middle shelf	1
15	Upper back panel	1
16	Lower back panel	1

List of Parts


No.	Hard ware	Quantity
(A)		28+2
(B)	 Ø8x30MM	12
(C)	 Ø15x11MM	20+2
(D)	 Ø3.5x30MM	8
(E)	 Ø12x9MM	8+1
(F)		2
(G)	 M4x8MM	2+1
(H)	 Ø3.0x12MM	26+2
(I)	 Ø3.5x14MM	17+1
(J)	 12"	2
(K)		1
(L)		1
(M)	 3x 3x	3
(N)	 Ø7x48MM	4

How the knock down (kd) assembly system works




How do we install the wood dowel


Insert the wood dowel[B] at least half way by tapping lightly with a rubber mallet, IF NECESSARY.



CAM LOCK SYSTEM OPERATION




1. Screw the cam bolt [A] into the threaded insert on the panel.
2. Connect both panels together making sure cam bolt [A] goes into the pre-drilled large hole on the end of panel for cam lock [C].
3. Insert the cam lock [C] into the pre-drilled large hole on the panel. Make sure the cross slot of cam lock [C] faces out.
4. Rotate the cam lock [C] clockwise with a supplied screwdriver to lock the cam bolt [A] in place.




You are now ready to assemble the dresser

Before installation, observe the individual structures of the drawer dresser. The drawer dresser consists of two main parts. First, assemble the cabinet, then install the two drawers. Finally, take a look at the finished look, compare the list of parts and visualize how you can install it faster. We hope you find this helpful.




We recommend using a power drill to assemble.



Step 1-1

(J)



2 pcs

(H)




4 pcs

-Install the drawer slides (J) on the left side panel (2).

There is a CL sign on the track. We have 2 x (J), one batch (J) has one CL track. So we need to open 2 batches (J) to get 2 CL tracks

-Screw (H) to tighten the track slides as below shown

All the white wheels should be on the same side as the HORIZONTAL two adjacent small holes in the middle. And two adjacent small pre-drilled holes are for A screw and B wood stick to install reinforcement connect boards, not for H screw to install sliding rail. The white wheel is on the lower side



Make sure this end with the carving should be the upside


Step 1-2

(H)




2 pcs

-Screw (H) to tighten the track slides as below shown




There are no pre-drilled holes corresponds to the UPPER row holes of the tightening. We need to confirm the position of the track slide, then screw the (H) on.




Step 1-3

- Please refer the below look and check carefully after you assembled 2 x CL track slides
- Make sure you used 6x(H)
- Make sure the end with roller of the track slides are in one direction



Step 2-1

(J)



2 pcs


(H)



4 pcs

- Install the drawer slides (J) on the right side panel (3).
- There is a CR sign on the track. We have 2 x (J), one batch (J) has one CR track. So we need to open 2 batches (J) to get 2 CR tracks
- Screw (H) to tighten the track slides as below shown

All the white wheels should be on the same side as the HORIZONTAL two adjacent small holes in the middle. And two adjacent small pre-drilled holes are for A screw and B wood stick to install reinforcement connect boards, not for H screw to install sliding rail. The white wheel is on the lower side



Make sure this end with the carving should be the upside



Step 2-2

(H)



2 pcs


-Screw (H) to tighten the track slides as below shown



There are no pre-drilled holes corresponds to the UPPER row holes of the tightening. We need to confirm the position of the track slide, then screw the (H) on.


Step 2-3

- Please refer the below look and check carefully after you assembled 2 x CR track slides
- Make sure you used 6x(H)
- Make sure the end with roller of the track slides are in one direction




Step 3

A



2 pcs

-Attach screw A to the small hole in plate (2) as shown below



Step 4

(B)




2 pcs

(C)




2 pcs

-Attach (2) to (14) as below shown and screw (C) to lock (14) & (2)




Step 5

A



2 pcs

-Attach screw (A) to the small hole in plate (2) as shown below



Step 6

(B)




2 pcs

(C)



2 pcs

-Attach (3) to (14) as below shown and screw C to lock (14) & (3)



Step 7

(M)





3 pcs

(L)



1 pcs



Remove the plastic piece before using the remote.


Step 8

A



4 pcs

-Install (A) cam bolt on panel (1)



Step 9

(B)




4 pcs

(C)



4 pcs

-Flip (1), attach (1) and (2), (3) as below shown



Tips: Start by placing the (B) wood dowel in the (2)&(3) panel, then align all the pre-drilled holes and put them together gently. Finally use the (C) cam lock to tighten with (A) cam bolt.

Step 10

(N)




4 pcs

(B)




4 pcs

- First, put the Two Drawer Chest down and insert the wood dowel (B) into (2) and (3)
- Then, align the pre-drilled holes in the board (4) with the wood dowel (B) to bring (4) and (2)(3) together
- At last, align the pre-drilled holes in board (4) with (N) to connect (4) and (2)(3)



Step 11

(A)




8 pcs

(C)




8 pcs

-Assemble the bottom of the 2 drawers with cam bolt (A) and bolt cam (C) as shown below.




Step 12

(A)



4 pcs

-Install (A) cam bolt on panel (4).




Step 13

(C)



4 pcs

- Attach the main nightstand body and (5)(6)(7)(8) as below shown
- Screw (C) to lock (5), (6), (7) (8) and (4) as below shown



Tips: When assembling bottom, Insert (A) sticks in the (4) board first. Then align all the pre-drilled holes and put them together gently. Finally use the (C) nut to tighten with (A).


Step 14

(H)




2 pcs

(K)



1 pcs

-Screw (H) to lock (K) to the top panel as below shown




Step 15

I



17 pcs



1. It is recommended to attach the back panel (15) at the top panel (1) first. Please remember not to fully tighten all the screws (I) until all of them are in correct position.

2. Only the top of the board has pre-drilled holes, other backboards without pre-drilled holes, just screw directly into it.

3. For installing the back panel easier, we should lay down the body, let the front face the ground and the back should be up, then ready to assemble the back panel (15) and (16).

4. We suggest use a power drill to install the back panel.


Step 16

D



8 pcs

- Attach (9), (10), (11) as below shown
- Screw D to lock (9) & (10) & (11) as below shown



Start assembling the two smaller drawers.

Step 17

(A)




8 pcs

(E)



8 pcs

- Put into the (12) aligns the groove as below shown
- Screw (A) to (13) as below shown
- Attach (13) to (9) & (10) as below shown
- Screw (E) to lock (13) and (9) & (10) as below shown



Step 18

F



2 pcs


G



2 pcs

-Screw (G) to install (F) to (13) as below shown

please remove this spacer if
the handle screw not long
enough



Insert screw (G) first, then align the pre-drilled holes of the pull, and tighten the screws.


Step 19

(H)





12 pcs

(J)



4 pcs



-Install the drawer slides (J) on the drawer side panels (9)&(10) as below shown.



The white wheels should be installed on the back side.

Step 20

-Place the drawers in the cabinet to complete the assembly



When you put the drawer, please note that the drawer wheels on top of the wheels of the slide, then check whether the drawer is smooth when pulled out. Otherwise, the drawer will not be aligned with other drawers.