
INSTALLATION MANUAL




Ý		
1		
ł		
t		
1		
4		
ŧ		
\$		
1		
\$		
1.		
1		
1		
4		
1		
1		
1		
4		
-		
1		
-		
4		
1		
4		
1		
1		
4		
1		
1		
1		
4		
4		
1		
1		
4		
1		
1		
1		
4		
-i		
1		
4		
4		

IMPORTANT SAFETY INSTRUCTIONS

When using an electrical furnishing, basic precautions should always be followed ,including the following:

WARNING: To reduce the risk of burns,fire,electric shock or injury to persons. Use this furnishing only for its intended use as described in these instructions. Do not use attachments not recommended by the manufacturer. Never drop or insert any object into any opening.Do not use outdoors.



ELECTRIC CONNECTIONS

ALL WIRING SHOULD BE DONE BY A QUALIFIED LICENCED ELECTRICIAN.

WARNING: Shut off power before wiring. Requires 120 VAC 20 Amp GFI protected Circuit.


GROUNDING INSTRUCTIONS:


CAUTION: This product must be connected to a grounded metal permanent wiring system or an equipment-grounding conductor must be run with the circuit conductors and connected to the equipment grounding terminal or lead on the product.

MARNING: An Electrical option mirror must be wired to a 20 Amp GFI(Ground Fault Interrupter) protected circuit when used in bathrooms and all other locations required by the National Electric Code.

HOW TO CONNECTIONS

The electric wire comes through the access hole on the top of the cabinet, exact location of access hole varies depending on the product models. Please refer to the actual product for the exact location.

















Pencil



Power Drill

Mallet Tape Measure

sure Safe

Safety Goggles


Drill Bits

Level

	HARDWARE LISTS				
ITEM	IMAGE	NAME			
1		Mounting Screw			
2	Contraction of the second s	Wall Anchor			
3		Aluminum Alloy Mounting Bar			
4		Aluminum Corner Support			
5		Glass Shelf			
6		Side Aluminium Planel			
7	(+))))))))	Side Planel Screw			

INSTALLATIONINSTRUCTIONS

APPLY TO BELOW STYLE OF LED MEDICINE CABINET



Please read carefully and save these instructions

Don't discard any of the packaging until you are sure that you have all of the parts and the fitings Make sure power to the junction box is off before commencing installation.

IMPORTANT

- 1. Unpack LED cabinet. DO NOT lay cabinet on tiled or concrete surface prior to installation Cabinet must be on protected surface to prevent chipping of the corners
- 2. Care must be taken before drilling pilot holes to avoid any existing wiring or pipe work that may be concealed.
- 3. A certified electrician must perform all work. The mirror must be connected to a GFI


MAINTENANCE


Wipe clean with a soft damp cloth. Apply glass cleaner to cloth and do not apply directly to mirror Never use abrasive cleaners as these could damage the finish or exposed LEDstrip 2


INSTALLATION


Please refer to below surface mount or recess mount method.

SURFACE MOUNT INSTRUCTION









RECESS MOUNT INSTRUCTIONS

NOTE: Rough opening is not an exact measurement. The extra space allows cabinet to be inserted into the opening. Add shims to level and tighten space if necessary. Additional framing might be required.

Rough Wall	Opening
-------------------	---------


Overall Size	Rough Wall Opening	
20 in.(W) x 28 in.(H) x 5 in.(D)	19-1/4 in.(W) x 22-7/8 in.(H) x 3-7/8 in.(D)	
24 in.(W) x 30 in.(H) x 5 in.(D)	23-1/4 in.(W) x 24-7/8 in.(H) x 3-7/8 in.(D)	
36 in.(W) x 32 in.(H) x 5 in.(D)	35-1/4 in.(W) x 26-7/8 in.(H) x 3-7/8 in.(D)	
48 in.(W) x 32 in.(H) x 5 in.(D)	47-1/4 in.(W) x 26-7/8 in.(H) x 3-7/8 in.(D)	
60 in.(W) x 32 in.(H) x 5 in.(D)	59-1/4 in.(W) x 26-7/8 in.(H) x 3-7/8 in.(D)	

Step 1

NOTE: Before cutting the rough opening, check for pipes, electrical cables, or heatingducts. If it is required to remove part of stud, make sure that the wall is not a load bearing wall.


Prepare the opening in the wall for the cabinet body. Make sure that there is support on both sides of the opening to attach the cabinet body, as shown.

NOTE: The cabinet height should be a minimum 2 in. above faucet.



Step 2


Connect hardwire to power line. Make sure the power off (Voltage:AC110-12V,50/60Hz)



Step 3 Position the cabinet body in the rough wall opening. Make sure that the cabinet body flange covers the wall opening uniformly.

Secure both sides of the cabinet body to the wall supports using mounting screws .


NOTE: The cabinet body must be level for the door to work properly.



Step 4:

As for the shelf and cabinet door installation and adjusment, please refer to page 6 & 7.


INTRODUCTION OF TOUCH FUNCTION



- 1. Click the power button to turn the light ON/OFF.
 - 2. Long press the button to make the light gradually dims Long press the button again and the light gradually brightens.
- 1. Click this button turn the defogger ON/OFF.

 \bigcirc

 \div 1. Click to switch the color temperature of light by 3000k-4000k-6000k.



A - WidthB - HeightC - Depth

Unit: Inch

А	В	С
20	28	5
20	28	5
24	30	5
24	30	5
36	32	5
48	32	5
60	32	5

Note: All dimensions & specifications are approximate and subject to change without notice.