


Assembly Instructions



ASSEMBLY RATING

The Assembly Rating is a 5-point system that shows the degree of effort needed in assembling a specific product (with 1 being easy and 5 being difficult). For some products, two persons are recommended.


EASY



DIFFICULT

Tools Required For Assembly:

Allen Wrench



(Included)

Phillips Screwdriver



(Not Included)




2 PERSONS RECOMMENDED


ASSEMBLY & CARE ADVICE

FOR YOUR FURNITURE TO LAST, CORRECT ASSEMBLY AND PROPER MAINTENANCE ARE NECESSARY. PLEASE FOLLOW THE INFORMATION PROVIDED BELOW TO FULLY ENJOY YOUR FURNITURE.


BASIC ASSEMBLY TECHNIQUES




When lock or spring washer is used in an assembly, please make sure the lock or spring washer is placed between the larger flat washer and the head of the screw or bolt.




Position each part correctly and insert screws or bolts into their respective holes by hand tighten or using the proper hand tool. Only tighten when step is completed or when instructed to do so.




Use cardboard or carpet area when assembling furniture to prevent scratches. Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.



Some furniture comes with height adjustment knobs underneath each leg. To lower or to raise each leg, you need to turn clockwise or counterclockwise, respectively.



Make sure all parts are properly aligned, then use the appropriate hand tool to completely tighten the bolts or screws. Do not use power tools and do not overtighten.




Save the instructions and store the Allen wrench or any supplied tool for later maintenance. After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.



FAILURE TO FOLLOW THE GUIDELINES ABOVE MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.




Before you begin, please read Page 2 of "Assembly and Care Advice".

And remember, do not tighten until each step is completed or instructed.


Parts List




#1 x 1pc
Heardboard (Left)



#2 x 1pc
Heardboard (Right)




#3 x 1pc
Upper Front Side Rail



#4 x 1pc
Upper Back Side Rail




#5 x 2pcs
Lower Guardrail



#6 x 1set
Twin Slat Kit (13pcs)



#7 x 2pcs
Vertical Bar



#8 x 1pc
Frames (Left)

Hardware List



#A x 16pcs
Bolt 1/4" x 4-3/8"



#B x 16pcs
Barrel Nut 1/4" x 1/2"



#C x 18pcs
Bolt 1/4" x 1-3/8"



#D x 16pcs
Bolt 1/4" x 1"



#E x 12pcs
Wood Dowel 7/16" x 1-9/16"




#F x 1pc
Wood Dowel 7/16" x 1-3/16"



#G x 8pcs
Wood Dowel 7/16" x 3/4"




#H x 6pcs
Screw 3/16" x 1-3/16"




Before you begin, please read Page 2 of "Assembly and Care Advice".

And remember, do not tighten until each step is completed or instructed.


Parts List



#9 x 1pc
Frames (Right)




#10 x 1pc
Crossbar




#11 x 2pcs
Window


Hardware List




#1 x 1pc
Allen Wrench 4mm



#12 x 4pcs
Window




#13 x 2pcs
Window






#1


1) Insert dowels (#E) and barrel nuts (#B) to each ends of the side rails (#3,4). Align Side rails (#3,4) to the holes on the top of the headboards (#1,2). Secure by screwing bolts (#A) onto the barrel nuts (#B) of the side rails (#3,4).



#A x 16pcs
#B x 16pcs
#E x 12pcs




2) Attach dowels (#E) and barrel nuts (#B) to each ends of the guardrails (#5). Align guardrails (#5) to the holes of the headboards (#1,2). Secure by screwing bolts (#A) onto the barrel nuts (#B) of the guardrails (#5).



#2

#C x 3pcs

1) Align vertical bar (#7) to the right side holes of the frame (#8). Secure by using bolts (#C).
2) Align vertical bar (#7) to the left side holes of the frame (#9). Secure by using bolts (#C).




X 2




1) Align frames (#8,9) to the holes of the upper guardrail. Secure by using bolts (#C).

#C x 10pcs





2) Align frames (#8,9) to the holes of the headboards. Secure by using bolts (#C).



#D x 4pcs
#G x 2pcs



Insert dowels (#G) to the center hole of the window panel (#11). Attach window panel (#11) to the top holes of the window, then secure by using bolts (#D).







#D x 8pcs
#G x 4pcs

Insert dowels (#G) to the center hole of the window side panel (#12). Attach window side panel (#12) to the side holes of the window, then secure by using bolts (#D).



#D x 4pcs
#G x 2pcs



Insert dowels (#G) to the center hole of the window bottom panel (#13). Attach window bottom panel (#13) to the bottom holes of the window, then secure by using bolts (#D).






#C x 2pcs
#F x 1pc

Insert dowels (#F) to the center hole of the door crossbar (#10). Attach door crossbar (#10) to the top holes of the door, then secure by using bolts (#D).



#H x 6pcs



Align slat kit (#6) to the top of the bunk, then secure by using screws (#H).

