

A PERSONAL MESSAGE FROM TEAM SKYBOUND

When I shop, I am not just buying a product or service. I purchase why that brand focuses on what they do, what their corporate philosophy is, the quality of their products, and whether or not my personal core values align with that brand's vision. When I don't feel great about a company's brand, products, or how I'm being treated as a customer, then I know they are not delivering on what matters most: exceeding the customer expectation by delivering happiness with their products, quality, and service.

This primary focus is what drives our culture at Team Skybound. For supporting our vision, we would like to personally thank you for trusting us to deliver happiness to you and your family!

Team SkyBound

"Nurturing the inner-child in all of us by
uniting communities worldwide and
promoting an active lifestyle."

For customer service, please contact:
888-891-4689

Monday through Friday
8:00 am to 5:00 pm PST
or visit www.SkyBoundUSA.com



help@skyboundusa.com



36 INCH

DOOR ARMREST TRAMPOLINE

ASSEMBLY AND INSTALLATION MANUAL

www.SkyBoundUSA.com

IMPORTANT INFORMATION

WARNING

- Prior to assembling or using the trampoline, you must thoroughly read this manual.
- Keep this manual for future reference.
- This product is intended for domestic family use only.
- Adult supervision is required at all times.
- This trampoline is not intended for use by more than one person at any time.
- This product is recommended for use by children aged 3 and above.

Warning! Assembly by an adult.

This object is subject to wear and tear. No warranties whether expressed or implied are provided. Injury will likely occur with the use of a trampoline or any associated product.
Use with supervision. Use at your own risk.
Only Use in a well-lit, well secured down area.

WARNING - GENERAL

Prior to using the trampoline, you must read all the instructions contained in this manual. All information, including the warning instructions for care, maintenance, and use of the trampoline are intended to promote safe, enjoyable use of the trampoline.

- If user feels faint or dizzy, immediately stop using the sensory trampoline.
- Use only in a well lit area by responsible, mature, non-intoxicated persons.
- Never use trampoline on an un-level surface. Use only when dry.
- Overhead clearance is essential. A minimum of 10 feet of overhead clearance from ground level is required.
- Provide clearance from all surroundings and obstructions such as desks, chairs, trees, poles, wires, and other possible hazards.
- Lateral clearance is essential. Place the trampoline away from walls, structures, doors, and other play areas. Maintain a clear space on all sides of the trampoline.
- Place the trampoline on a stable level surface before use.
- The area under the trampoline should be free and clear of any objects or obstructions.
- Secure the trampoline against unauthorized and unsupervised use.
- Remove any obstructions from beneath the trampoline.
- The owner and supervisors of the trampoline are responsible for all users to be aware of the practices specified in the use instructions.
- This product is not intended for use by children under 3 years of age.
- Restrict usage to one person at any time.
- Prior to each use, inspect the trampoline for any worn, defective, misadjusted or missing parts. Ensure the frame and mat are correctly and securely positioned.

IMPORTANT INFORMATION

WARNING - USAGE

- DO NOT attempt or allow somersaults. Landing on the head or neck can cause serious injury, paralysis, or death even when landing in the middle of the bed.
- DO NOT allow more than one person on the trampoline. Use by more the one person at the same time can result in serious injury.
- Use trampoline only with mature, knowledgeable supervision at all times.
- Inspect the trampoline before each use. Make sure the frame padding is correctly and securely positioned. Replace any worn, defective, or missing parts.
- Step on and off the trampoline. Do not step on the frame when getting on and off the trampoline. Do not use the trampoline as a springboard to other objects. Do not mount or dismount the trampoline by jumping.
- Stop bounce by flexing knees as feet come in contact with the trampoline bed. Learn this skill before attempting others more advanced moves. Control is more important than bounce height.
- For information concerning skill training, contact a qualified fitness trampoline instructor.
- Store and protect trampoline from unauthorized use.
- Read all instructions before using the trampoline. Warning and instructions for the care, maintenance and use of this trampoline are included to promote safe, enjoyable use of the equipment.
- Remove any sharp or loose objects from pockets or on your body prior to use, such as glasses, watches, jewelry, chains, ornaments, clasps, and other sharp objects.
- Ensure the trampoline and surrounding areas are properly illuminated.
- Serious injury can occur from misuse or abuse of the trampoline. bounce in the center of the bed.

CARE, MAINTENANCE AND USE INTRUCTIONS MUST BE READ CAREFULLY PRIOR TO USING THE TRAMPOLINE!

This trampoline is constructed of high quality materials and craftsmanship. For years of exercise, fun and enjoyment and to reduce the risk of injury to the user, follow all required care and maintenance instructions closely listed below:

- Only one jumper should use the trampoline at any time.
- Do not allow pets on the trampoline in order to help prevent cuts, scrapes, tears or other types of damage to the mat or bands.
- Inspect the trampoline before each use and replace any worn defective, or missing parts. Any number of issues can raise the risk of injury.
- The following conditions could represent potential hazards:
 1. A bent or broken frame
 2. Fraying elastic bands
 3. A sagging mat
 4. Sharp protrusions on the frame or suspensions system

IF ANY OF THE PREVIOUS CONDITIONS ARE FOUND, OR ANY OTHER ISSUES YOU MAY FEEL MAY BE HARMFUL TO THE USER, THE SENSORY TRAMPOLINE SHOULD BE IMMEDIATELY DISASSEMBLED OR SECURED FROM ANY FUTURE USE UNTIL THE


You must check all the parts of the trampoline including the frame, suspension system, mat, and legs at regular intervals.

If these checks are not carried out, the trampoline could become dangerous.

PARTS LIST

Part #	Description	QTY	Part#	Description	QTY
1	Top Rail Frame	x3	6	Trampoline Pad	x1
2	Legs	x6	7	Trampoline Mat	x1
3	Left Handle Base	x1	8	Bungee tool	x1
4	Right Handle Base	x1	9	Bungee Cord	x18
5	Center Handle Bar	x1			-


ASSEMBLY INSTRUCTIONS



STEP 1


A. Connect 3X (Part 1) Top Rail Frame pieces to make the trampoline frame. Make sure that the metal push tabs are secure in each connection on the frame before proceeding.

B. To connect the third and final section of the top rail frame, push down on the last joint until the metal tab is fully inserted and snaps into place.




C. Insert the legs into the frame.

ASSEMBLY INSTRUCTIONS




STEP 2

First attach bungee ropes to one corner of the frame.




STEP 3

- A. Center the trampoline mat within the completed frame. Then attach 2 rubber ropes each to the exact opposite side at the corner of the frame.
- B. Begin to thread the bungee cord through the pre-sewn fabric loops, wrapping the cord once around the trampoline frame after each fabric loop.
- C. Do not pull the cord to tightly when beginning this process, as you want to keep the mat as centered as possible will threading the bungee cord. The court should be snug, but not pulled taut around the trampoline frame.




ASSEMBLY INSTRUCTIONS



STEP 4

A. Your completed mat, cord and frame assembly should look like the picture below.


B. As shown in the pictures below, attach the Trampoline Pad by fitting the precut holes in the pad over the Leg Housings.



STEP 5

A. Following the pattern shown in Diagram 2, insert 4x Legs into the Leg Housings, making sure the metal push buttons snap securely into the holes into each Leg Housing.

ASSEMBLY INSTRUCTIONS




STEP 6

- A. As shown in diagram 3, take the remaining 2x Legs, and place 1x Handle Base over each Leg.
- B. Take the Leg/Handle Base assembly, and place it onto the Leg Housing.
- C. First, secure the Leg's push button into the Leg Housing, then secure the push button through the hole in the Handle Base. You may have to rotate the Handle Base slightly to fit the push button through its hole.

Note:

Make sure the Handle Base "ends" are pointing directly towards each other (see picture on next page) before proceeding. If they are not, switch the Legs that the Handle Bases are on.



STEP 7

- A. Attach the Center Handle bar to one Handle Base, securing it with the push button on the Handle base.
- B. Slide the other end of the Center Handle Bar onto the remaining Handle Base until it snaps securely into place. Peel the foam back slightly on the Center Handle Bar once it is in place to make sure the push buttons are correctly aligned through the holes.