


# ASSEMBLY INSTRUCTION

---


## SKYBED




**Notice:**

1. 50% Tighten before fixing all screws, Allen wrench is recommended instead of an electric drill.
2. Place the item on a flat ground to adjust and make sure it remains stable.
3. Tighten up all screws with tools gradually.
4. If the screws are not aligned with holes during assembly, please loosen all the other screws to 50% and continue the assembly process.
5. If the item is not stable, please loosen all the screws, adjust it on a flat ground and tighten up all screws again.
6. Note : If one or some screws are fully tightened during assembly, chances are the others will not be aligned with holes. In addition, all the holes are designed to be relatively larger to provide more space for the adjustment of the screws.


# Employed View




# PART LIST




**Ax1**




**Bx2**



**Cx2**



**Dx4**




**Ex2**




**Fx8**




**Gx4**




**Hx2**




**Ix2**




**Jx1**



**Kx2**



**Mx1**



**1- Bulon 6x40 :28  
(Extra +2)**




**2- Washer :64  
(Extra +4)**




**3- Bulon 6x15 :68  
(Extra +2)**




**4- Allen Key : 2**




**5- Square bass : 4**



**6- Straight bass: 4**




**7- Straight bass: 8**




**8- Bulon 6x30 :16  
(Extra +2)**

# CARTON CONTENT :



**Bx2**



**Cx2**




**Gx4**




**Hx2**




**Ix2**



**Mx1**




**Jx1**




**Hardware**




**Fx8**




**Ax1**



**Dx4**





**Kx2**





**Ex2**

# Step 1





Ax1 Bx2 ①x4 ②x4

# Step 2






Cx2 ①x8 ②x8

# Step 3




Ex2 ①x8 ②x8

# Step 4







Fx8 ③x16 ②x16

# Step 5






# Step 6







Dx2 ③x16 ⑦x4





Gx2 ①x4 ②x4

# Step 9






Gx2 ①x4 ②x4

# Step 10






Ix2 ③x8 ②x8

# Step 11




Hx2 ③x8 ②x8

# Step 12





Mx1 ③x4 ②x4


# Step 13




# Step 14



## Step 15



## Step 16



# Step 17

