


Installation instruction




Assembling

What you need


- Use the packaging carton as a working surface to prevent product damage during assembly

Tool Required Not Provided



Use electric tools with care.

















Weight Limitation



What' included

Code	Description	Qty
A	Cam Bolt M6X35MM	3
B	Cam Lock 15X9MM	3
C	Wooden Dowel M6X30MM	4
D	Screw M4X8MM	4
E	Screw M4X40MM	9
F	Screw M4X14MM	2
G	Screw M6X12MM	12
H	Screw M6X25MM	23
I	Screw M6X35MM	2
J	Expansion tube	2
K	Nylon Strap	2
L	Screw wrench	1
M	Screw M6X45MM	4
N	Adjustable Leveler	4
O	Metal shake handhandle	2
P	Screw M6X20MM	9

The Hardwares

<p>A x 3</p>  <p>Ø6×35 mm</p>	<p>B x 3</p>  <p>Ø15×9 mm</p>	<p>C x 4</p>  <p>Ø6×30 mm</p>	<p>D x 4</p>  <p>Ø4×8 mm</p>	<p>E x 9</p>  <p>Ø4×40 mm</p>
<p>F x 2</p>  <p>Φ4×14 mm</p>	<p>G x 12</p>  <p>M6×12 mm</p>	<p>H x 23</p>  <p>M6×25 mm</p>	<p>I x 2</p>  <p>M6×35 mm</p>	<p>J x 2</p> 
<p>K x 2</p> 	<p>L x 1</p>  <p>4 mm</p>	<p>M x 4</p>  <p>M6×45 mm</p>	<p>N x 4</p> 	<p>O x 2</p> 
<p>P x 9</p>  <p>M6×20 mm</p>				


IMPORTANT:

1. Do not tighten bolts / screws completely until all bolts / screws are lined up and inserted into holes.
2. Do not over tighten screws and bolts to avoid stripping
3. You can use a screwdriver or an electric tool (be careful when using an electric tool).





Included Accessories




Code	Description	Qty
1	Panel	1
2	Bottom plate	1
3	Laminate	3
4	Middle vertical plate	1
5	Push-pull plate	2
6	Upper iron frame	2
7	Intermediate iron frame	2
8	Lower iron frame	2
9	Short crossbar	2
10	Long crossbar	1
11	Upper crossbar	3

The Accessoriss







Step 1

O x 2 	D x 4  Ø4x8 mm	C x 2  Ø6x30 mm	A x 3  Ø6x35 mm
--	--	--	--





Step 2



N x 4 	L x 1  4 mm	I x 2  M6x35 mm
--	--	--






Step 3

L x 1  4 mm	H x 7  M6x25 mm
--	--

Warning: The slot must be installed with the opening downward.
Ensure the small holes and openings on the encircled position are aligned in the same direction.





Step 4

L x 1  4 mm	M x 4  M6x45 mm	E x 4  Ø4x40 mm
---	--	--



Step 1: First, use M screws to install part No. 9.

Step 2: Then, use E screws to install part No. 4.


Note: Install with the large hole facing upward 






Step 5



E x 3  Ø4×40 mm	C x 2  Ø6×30 mm
---	---

Note: Install with the large hole facing upward






Step 6

L x 1  4 mm	H x 4  M6×25 mm	B x 3  Ø15×9 mm
--	---	---






Step 7

L x 1	G x 8
	
4 mm	M6x12 mm







Step 8

L x 1	G x 4
	
4 mm	M6x12 mm




Step 9

P x 9  M6x20 mm	L x 1  4 mm	H x 12  M6x25 mm
---	--	---





P x 9


I





x3









P x 9





Step 10




K x 2	F x 2
	
	Φ4×14 mm

Another piece of No. 5 component is assembled as shown in the figure



Step 11

J x 2	E x 2
	
	Ø4x40 mm



If the center position of the cabinet is too high or too low due to uneven bottom plates or other reasons, adjust the adjustable foot pads on feet ⑧ to adjust the upper and lower height