

ASSEMBLY INSTRUCTIONS

PARTS:






Notice - KEEP BACK GROOVES ALIGNED




Step 1: Insert edge of **bottom** piece into mortise of **side** piece. Make sure back grooves are aligned. Insert hex screws into each of (2) pre-drilled holes in **side** piece and tighten down halfway.

Step 2: Insert edge of **top** piece into opposite mortise of **side** piece making sure back grovoes align. Insert hex screws into each of (2) pre-drilled holes in **side** piece and tighten down halfway.







Step 4: Insert edge of remaining shelf piece into remaining mortise of side piece, making sure to align back grooves. Insert hex screws into each of (2) pre-drilled holes in side piece and tighten down halfway.





step 5: Insert sides of one back piece into back grooves of bottom piece and shelf piece. Slide down until edge rests firmly in back groove of side piece.



Step 6: Insert sides of **other** back piece into back grooves of **top** piece and **shelf** piece. Slide down







Step 8: Fit edges of assembled pieces into mortises and back grooves of remaining **side** piece. Insert hex screws into each of (8) pre-drilled holes in **side** piece and tighten down halfway.



Step 9: Tighten all screws snugly. DO NOT OVER TIGHTEN. DO NOT DRILL. Rotate unit so that it rests on bottom piece and edges of side pieces. Assembly is now complete.

