


HONGMAO



ITEM NO.HMGG0002

NOTE:

This brochure contains IMPORTANT safty info. Please read and keep for future reference.


MAINTAINANCE AND WARNING

- 1.Keep furniture away from heat sources.
- 2.Do not clean furniture with harsh cleaner or polishes.Do not use detergents,solvents,abrasives,spray packs or leather cleaner. Use non-color mild soa with warm water to clean spills(Mix 1:10 soap to water).
- 3.Do not place furniture under direct sunlight,material will possibly fade over time.
- 4.Do not use on site dry cleaning machine.Children should not climb or jump on the furniture.
- 5.Do not write on furniture that is not protectedby a padded barrier.
- 6.Not for commercial use,only for residential use.



















Weight Limitation
110 LBS






EXPLOSIVE VIEW






















PARTS LIST








PARTS LIST



HARDWARE LIST

#1	x23		
#2	x23		
#3	x22		φ8*30mm
#4	x2		
#5	x34		φ3*14mm*6#
#6	x4		φ3*16mm*6#
#7	x4		
#8	x8		
#9	x8		
#10	x8		φ4*19mm
#11	x44		φ3.5*14mm*7#
#12	x8		
#13	x4		
#14	x16		φ8#*1"
#15	x4		
#16	x4		φ3.5*35mm*7#
#17	x2		
#18	x1		
#19	x8		φ5/32"*1/2"

HARDWARE SPARE LIST


#1	x1		
#2	x1		
#3	x1		φ8*30mm
#5	x1		φ3*14mm*6#
#11	x1		φ3.5*14mm*7#

ASSEMBLY INSTRUCTIONS






STEP-1

1. Insert 1x Bolt (#1) into the designated holes on Part (C). Tighten Bolt (#1) using Screwdriver (#18).
2. Insert 2x Dowels (#3) into the alignment holes on Part B. Align Part (C) with the dowels on Part (B) and gently press them together. Insert Cam Locks (#2) into the holes on the assembled parts
3. Rotate the cam locks clockwise (typically 90°) using Screwdriver (#18) to lock them in place.

1:




2:





ASSEMBLY INSTRUCTIONS

STEP-2

Insert 10x Bolt (#1) into the designated holes on Part (E) and Part (D). Tighten Bolt (#1) using Screwdriver (#18).




#1	x10	#18	x1
			

ASSEMBLY INSTRUCTIONS

STEP-3

Connect 1x Magnetic catch (#4) in to the part (F) and use 2x screw (#5) to attach them , tighten screw(#5) with screwdriver (#18).




#4	x1	#5	x2	#18	x1
		ø3*14mm*6#			

ASSEMBLY INSTRUCTIONS

STEP-4

1. Insert 4x Dowels (#3) into the alignment holes on Part (E).
2. Insert Part (F&B) into part (E), make sure all holes align.
3. Insert 5x Cam locks (#2) into the designated holes on Part (B) and (F). using Screwdriver (#18) to lock them.



#2	x5
ø8*30mm	


#3	x4
ø8*30mm	

#18	x1

ASSEMBLY INSTRUCTIONS

STEP-5

1. Insert 4x Dowels (#3) into the alignment holes on Part (F) and Part (B).
2. Insert Part (D) into part (F) and (B), make sure all holes align.
3. Insert 5x Cam locks (#2) into the designated holes on Part (B) and (F). using Screwdriver (#18) to lock them.



#2	x5


#3	x4
ø8*30mm	

#18	x1

ASSEMBLY INSTRUCTIONS

STEP-6

1. Insert 4x Bolt (#1) into the designated holes on Part (G)). Tighten Bolt (#1) using Screwdriver (#18).




#1	x4

#18	x1

ASSEMBLY INSTRUCTIONS

STEP-7

1. Insert 4x Dowels (#3) into the alignment holes on Part (D) and Part (E).
2. Insert 4x Bolt (#1) into the designated holes on Part (G). Tighten Bolt (#1) using Screwdriver (#18). Insert Part (G) into part (D) and (E), make sure all holes align.
3. Insert 4x Cam locks (#2) into the designated holes on Part (D) and (E). using Screwdriver (#18) to lock them.



#1	x4

#2	x4


#3	x4
ø8*30mm	

#18	x1

ASSEMBLY INSTRUCTIONS

STEP-8

1. Insert 4x Dowels (#3) into the alignment holes on Part (G).
2. Insert Part (H) and Part (I) into Part (G), make sure all holes align.
3. Insert 4x Cam locks (#2) into the designated holes on Part (H) and (I).
using Screwdriver (#18) to lock them.




#2	x4	#3	x4	#18	x1
		ø8*30mm			

ASSEMBLY INSTRUCTIONS

STEP-9

1. Insert 4x Bolt (#1) into the designated holes on Part (A). Tighten Bolt (#1) using Screwdriver (#18).
2. Connect 1x Magnetic catch (#4) in to the part (A) and use 2x screw (#5) to attach them , tighten screw(#5) with screwdriver (#18).



#1	x4

#4	x1


#5	x2
ø3*14mm*6#	

#18	x1

ASSEMBLY INSTRUCTIONS

STEP-10

1. Insert 4x Dowels (#3) into the alignment holes on Part (H) and Part (I).
2. Insert Part (A) into part (H) and (I), make sure all holes align.
3. Insert 4x Cam locks (#2) into the designated holes on Part (H) and (I).
using Screwdriver (#18) to lock them.




#2	x4	#3	x4	#18	x1
		ø8*30mm			

ASSEMBLY INSTRUCTIONS

STEP-11



1. Insert back panel (J) and (K) into the groove of preassembled step 10, make sure all holes aligned and use 30x screw (#5) to attach them, tighten screw (#1) with screwdriver (#18).
2. Connect 2x part (#7) into the part (J) use 4x screw (#6) attach them, tighten screw (#6) with screwdriver (#18).



ASSEMBLY INSTRUCTIONS

STEP-12


1. Push 8x shelf holder(#8) into the matching holes.
2. Place 2x panel (L) on each top of shelf holder (#8).









ASSEMBLY INSTRUCTIONS

STEP-13

1. Use 12x screw (#11) to attach 4x hinge (#12) to door (M)&(N), tighten screw (#11) with Screwdriver (#18).
2. Insert 2x Iron plate (#13) into the alignment holes on the door (M)&(N), use 2x screw (#11) to attach Iron plate (#13), tighten screw (#11) with Screwdriver (#18).
3. Use 2x screw (#10) to attach 2x handle (#9) to door (M)&(N), tighten screw (#10) with Screwdriver (#18).










#9	x2	#10	x2	#11	x14	#12	x4	#13	x2	#18	x1
											
		φ4*19mm		φ3.5*14mm*7#							

ASSEMBLY INSTRUCTIONS

STEP-14

1. Use 12x screw (#11) to attach 4x hinge (#12) to door (O)&(P), tighten screw (#11) with Screwdriver (#18).
2. Insert 2x Iron plate (#13) into the alignment holes on the door (O)&(P), use 2x screw (#11) to attach Iron plate (#13), tighten screw (#11) with Screwdriver (#18).
3. Use 2x screw (#10) to attach 2x handle (#9) to door (O)&(P), tighten screw (#10) with Screwdriver (#18).





#9	x2	#10	x2	#11	x14	#12	x4	#13	x2	#18	x1
											
		φ4*19mm		φ3.5*14mm*7#							


ASSEMBLY INSTRUCTIONS

STEP-15

1. Move door (M)&(O) to corresponding position of side panel, make sure all holes aligned and use 8x screw (#11) to attach them, tighten screw (#11) with Screwdriver (#18).




#11	x8
	
ø3.5*14mm*7#	


#18	x1
	


ASSEMBLY INSTRUCTIONS

STEP-16

1. Move door (N)&(P) to corresponding position of side panel, make sure all holes aligned and use 8x screw (#11) to attach them, tighten screw (#11) with Screwdriver (#18).



#11	x8
	
ø3.5*14mm*7#	


#18	x1
	

ASSEMBLY INSTRUCTIONS


STEP-17



1. Connect part (R&S) to part (Q) using 8x screw (#14) and tighten it with screwdriver (#18).

2. slide in the part (U) into the groove in part (O&P). Make sure they are also in groove in part (S).



2: x2





#14	x8	#18	x1
			
ø8#*1"			





ASSEMBLY INSTRUCTIONS

STEP-18

1. Connect the part (T) connection using screw (#14), and tighten it with screwdriver (#18).

2. Use 2x screw (#10) to attach 2x handle (#9) to the drawer door, tighten screw (#10) with Screwdriver (#18).




#9	x4	#10	x4	#14	x8	#18	x1
							
		φ4*19mm		φ8#*1"			

ASSEMBLY INSTRUCTIONS

STEP-19

1. Attach drawer to preassemble unit at step 16.
2. Use 8x screw (#19) connect the part (Q) and tighten then by screwdriver (#18).




ASSEMBLY INSTRUCTIONS

STEP-20 1. Install the anti-collapse device.

2. Make the position on the wall, that corresponds to the location of part (#7) on the Top panel. Drill and insert the expandable screw part (#15) by hammer.

3. Assemble the part (#7) to the wall, Align the hole in the part (#7) with the expandable screw (15), use screw (#16) to attach it and tighten by screwdriver (#18)



#7	x2

#15	x4



#16	x4
φ3.5*35mm*7#	


#18	x1

ASSEMBLY INSTRUCTIONS

STEP-21

1. Let the plastic belt (#17) pass through the both part (#7) and pull tightly.



#17	x2
	

WARRANTY

1. We strive to offer high-quality products, and we also try our best to satisfy each and every customer that orders from us with product or service as needed.
2. We provide 30 days warranty starting from the time you receive the item. Each customer must provide a record of their order such as the order number, or item receipt for any items that are out of the warranty period you may also still receive.
3. Replacement parts by purchasing them with our company if they are available.

Are you having difficulty
With assembly? Missing parts?
Please send email with your order No to
hubeihongmao@163.com
For return, please check the return policy with
the retailer or market place you bought from.

Appreciate your purchasing from us.
Pop up your life by our furniture piece!