

# Assembly Instructions




If you have any questions, please follow these steps( “Find Your Orders” – “Problem with the Order” – “Contact Seller” ) to contact our customer service. Thanks!


Revsied 02/03/2024

# General Assembly Guidelines


- I. Ensure that all parts and hardware are available before beginning assembly.
- II. Follow each step carefully to ensure the proper assembly of this product.
- III. Two people are recommended for ease in the assembly of this product.
- IV. The three main types of hardware used to assemble this product are : wood dowels , screws and bolts.
- V. The provided glue is to secure wood dowels in place . When first inserting dowels , locate the appropriate hole for the dowel , place a small amount of glue in the hole and insert the dowel . Wipe away excess glue immediately.




In future assembly steps when dowels are necessary to attach assembly parts together , place a small amount of glue on the end of the dowel before attaching parts together . Wipe away excess glue immediately.




- VI. A Phillips head screwdriver is required for the assembly of this product .




- VII. Power tools should not be used to assemble this product .




- VIII. Concealed hinges are three-way adjustable.



Horizontal  
by screw adjustment




In-and-Out  
by loosening the hinge-arm  
mounting screw or via cam  
adjustment


















Vertical  
Via slots in the mounting  
plate or via cam adjustment

# Parts List



# Hardware List

A		Ø8x30mm	Wooden dowel	35 pcs
B		Ø6x35mm	Cam lock	46 pcs
C		Ø15x11mm	Cam lock	23 pcs
D		Ø15x9mm	Cam lock	23 pcs
E		Ø30mm	Sticker	46 pcs
F		Ø6x50mm	Bolt	9 pcs
G		M 4	Hex Key	1 pc
H		M6*12mm	Screw	24 pcs
I			Angular Code	12 pcs
J		Ø4x32mm	Screw	23 pcs
K		Ø4x25mm	Screw	3 pcs
L		Ø8x20mm	Wooden dowel	2 pcs
M		Individually packed	Drawer slides	5 Set
N		Ø3x12mm	Screw	60 pcs




Philips head screwdriver required for assembly  
(not included)

*The hardware quantities listed above are required for proper assembly.  
Some extra hardware may also have been included.*

# Hardware List


Q		128mm	Hold hands	2 pcs
R		160mm	Hold hands	3 pcs
S		Ø4x9mm	Screw	10 pcs
T			Anti-inversion hardware	4 pcs
U		Ø4*15mm	Screw	4 pcs
V			House lizard	4 pcs
W		Ø4x35mm	Screw	4 pcs
X			Strip	2 pcs
Y			Small White Glue	1 pc





Philips head screwdriver required for assembly  
(not included)


*The hardware quantities listed above are required for proper assembly.  
Some extra hardware may also have been included.*

# Step 1




L	A
	
X2	X35

# Step 2




Step 3


M-CL<sub>8</sub>




M-CR<sub>8</sub>



M-DL<sub>8</sub>



M-DR<sub>8</sub>







# Step 4

NOTE:






Refer to the images to identify M-CL8 (left) and M-CR8 (right). Attach M-CL8 to #3 panel and M-CR8 to #4 panel. [R] screws must go in the exact spots shown.




N	M
X24	X4

# Step 5







N	M
	
X6	X1

# Step 6






Step 7





C

X4


# Step 8




C

X3



# Step 9




C

X7



## Step 10



G	F
	
X1	X2


# Step 11



G	F
	
X1	X7






# Step 12




G	I	H
X1	X12	X12



# Step 13




G	H
	
X1	X2



# Step 14




G	H
	
X1	X2


# Step 15





G	H
	
X1	X8


# Step 16




K

X3


# Step 17




C

X9

# Step 18



J

X8



## Step 19




(X2)



# Step 20





D

X8

# Step 21






NOTE:  
Refer to the images to identify M-DL8 (left) and M-DR8 (right).  
Attach M-DL8 to #15 panel and M-DR8 to #16 panel. [R] screws must go in the exact spots shown.




N	M
X12	X2


## Step 22




S	Q
	
X4	X2


# Step 23




E

X8

# Step 24





J

X15

## Step 25






## Step 26



D

X15


# Step 27





N	M
	
X18	X3





# Step 28




S	R
	
X6	X3


# Step 29




E

X15

# Step 30






E

X23

# Step 31




# Step 32




T	U
	
X2	X4


# Step 33

Make Four holes 45MM deep




# Step 34



V

X4


# Step 35




T	W
X2	X4



# Step 36



X

X2

## Step 37

