




Package Contents: Parts





















x2




x2


Package Contents: Hardware

A x 24+3	B x 46+5	C x 46+5	D x 8	E x 32+4	F x 4
 M6.3x45				 ST3.5X12	
G x 4+1	H x 12+2	I x 12+2	J x 12+2	K x 12	L x 4
 M8	 ST3x12				 L-1, L-2, L-3, L-4
M x 2	N x 2+1	O x 4	P x 2	Q x 1	R x 50+6
	 ST4x12	 O-1, O-2			 dot stickers


Installation of Eccentric Unit




Bolt




Connecting piece




1




2



3




4





Pin
Board
No gap


⚠ Adjust connecting piece direction as illustrated.



⚠ Insert bolt when the connecting piece is as shown in Figure 2.

Initially  **Finally** 

1




B×8



Twist (B) into the holes on (3)(4) as displayed.

2




C×8




Connect (5)(22) with (3)(4), securing with (C).

3




A×4




Twist (A) to connect (6) with (3)(4).

4




Insert (19) into the grooves on Board(3)(4)(6).

5




A×4



Twist (A) to connect (1) with (3)(4).

6




B×8



Twist (B) into (14).

7




x 2

C×8



Connect (14) with (15)(16), securing with (C).


8




x 2

Insert (18) into the grooves on Board(14)(15)(16).

9




A×8




Twist (A) to connect (17) with (15)(16).

10




F×2

K×2



Secure (F) on (14) by (K).

11




B×8



Twist (B) into (10).

12




C×8



Connect (10) with (11)(12), securing with (C).


13



x 2


Insert (18) into the grooves on Board(10)(11)(12).

14




x 2

A×8



Twist (A) to connect (13) with (11)(12).


15



x 2



F×2

K×2




Secure (F) on (10) by (K).

16




PRESS UPWARD

PULL OUT THE COMPONENT




x 8

D×8

D-1
×8D-2
×8


Detach (D) into (D-1) (D-2).

17





D-2 × 4


E × 8



Twist (E) to secure (D-2)
on (15)(16).




18






D-2 × 4

E × 8




Twist (E) to secure (D-2)
on (11)(12).





FLAT - VIEW DRAWING




D-1×4

B×8


E×8



Twist (B) into the holes on (7),
then twist (E) to secure (D-1) on (7) as displayed.




FLAT - VIEW DRAWING




D-1×4

B×8

E×8



Twist (B) into the holes on (8),
then twist (E) to secure (D-1) on (8) as displayed.




C×16




Connect (7)(8) with (9)(20)(21)(22), securing with (C).

22




Twist (B) into the holes on (6) as displayed, then insert (G) into the rest of holes on (6). Twist (L3) to secure (L2) on (3)(4).

23



Connect (6) with (7)(8), securing with (C).





H×12

J×12





Insert (J) into the back of cabinet,
then use (H) to secure (J) on the board.








M×2	N×2	O×4	L×4

Twist (N) to secure (M) on (1).
 Install (O-1) on the wall, then twist (O-2) into (O-1) to secure (M) on the wall,
 and then twist o-2 into (O-1) to secure (21) on the wall.
 Install (L-4) on the wall, then twist (L-3) to secure (L-2) on (L-4).

 $L \times 4$ 


Insert (L-1) into (L-2). The length of (L-1) is adjustable by pushing and pulling the rod.



1x12



Insert (1) into the holes on (3)(4), then place (2) on (1).
Adjust (D-1) as displayed, then inset (D-2) into (D-1).



Done.