




# TV STAND WITH DRAWER



USER MANUAL



# Contents

## TOPIC

## PAGE

---

|           |  |              |
|-----------|--|--------------|
| <b>01</b> | <b>SAFETY INSTRUCTIONS</b>             | <b>01-01</b> |
|           | 1-1 Thank You For Choosing Our Product | 01           |
|           | 1-2 Precautions                        | 01           |

---

|           |                           |              |
|-----------|---------------------------|--------------|
| <b>02</b> | <b>INSTALLING MODULES</b> | <b>02-27</b> |
|           | 2-1 Disassembly Diagram   | 02           |
|           | 2-2 Parts List            | 03-04        |
|           | 2-3 Assembly Instructions | 05-27        |

---

|           |                                    |           |
|-----------|------------------------------------|-----------|
| <b>03</b> | <b>CUSTOMER SERVICE</b>            | <b>28</b> |
|           | 3-1 30-Day Return Policy           | 28        |
|           | 3-2 1-Year Warranty                | 28        |
|           | 3-3 Quick Response Within 24 Hours | 28        |

---


|           |                                   |           |
|-----------|-----------------------------------|-----------|
| <b>04</b> | <b>PROBLEMS YOU MAY ENCOUNTER</b> | <b>29</b> |
|           | 4-1 Problems You May Encounter    | 29        |

# Safety Instructions

## Thank You For Choosing Our Product

Before assembly, please read this USER MANUAL first, and check according to Parts List to make sure all parts are included. Feel free to contact us if you have any concerns or questions about your product, we are always ready to help. Your satisfaction is our first priority!


## Precautions



- Avoid long-term direct sunlight exposure.



- Keep away from sharp objects.




- Keep away from heat.



- Keep infants/children away from assembly parts to avoid choking and suffocation.




- Keep away from corrosive substances.




- Pay attention to avoid over-tightening fasteners, or they may induce cracking within the board.



















# Disassembly Diagram
























# Parts List

For ease and safety, we recommend two people for assembly.



|   |   |   |  |
|---|---|---|--|
| <b>A</b><br>x2<br>    | <b>B</b><br>x1<br>   | <b>C</b><br>x2<br>   | <b>D</b><br>x2<br>   |
| <b>E</b><br>x2<br>   | <b>F</b><br>x2<br>   | <b>G</b><br>x1<br>   | <b>H</b><br>x4<br>    |
| <b>I</b><br>x2<br>   | <b>J</b><br>x2<br>   | <b>K</b><br>x2<br>   | <b>M</b><br>x2<br>   |
| <b>N</b><br>x4<br>  | <b>O</b><br>x2<br> | <b>P</b><br>x2<br> | <b>Q</b><br>x2<br> |
| <b>S</b><br>x4<br> | <b>T</b><br>x4<br> |   |  |





# Parts List

|  |  |  |   |
|--|--|--|---|
| <p><b>L</b><br/>x4</p>                                |  | <p><b>R</b><br/>x4</p>   |   |
| <p><b>1</b><br/>x61</p>  <p><b>M6x23</b> 3 Spares</p> | <p><b>2</b><br/>x33</p>  <p><b>M6.3x40</b> 3 Spares</p> | <p><b>3</b><br/>x9</p>  <p><b>ST4x10</b> 1 Spare</p>  | <p><b>4</b><br/>x3</p>  <p><b>ST3.5x10</b> 1 Spare</p> |
| <p><b>5</b><br/>x5</p>  <p><b>M4x10</b> 1 Spare</p>   | <p><b>6</b><br/>x5</p>  <p>1 Spare</p>                  | <p><b>7</b><br/>x9</p>  <p>1 Spare</p>  | <p><b>8</b><br/>x4</p>                                |
| <p><b>9</b><br/>x7</p>  <p><b>Φ8x40</b> 1 Spare</p>   | <p><b>10</b><br/>x1</p>                                | <p><b>11</b><br/>x2</p>   | <p><b>12</b><br/>x1</p>                                |
| <p><b>13</b><br/>x1</p>                              | <p><b>14</b><br/>x2</p>  <p>1 Spare</p>               | <p><b>15</b><br/>x1</p>  <div data-bbox="788 1082 1055 1241"> <p><b>a</b> x2</p>  <p><b>b</b> x2</p>  <p><b>c</b> x2</p>  </div> |   |
| <p><b>16</b><br/>x9</p>  <p>1 Spare</p>             |  |  |   |


# Assembly Instructions

1

Connect Part Q to Part K and Part P to Part I. Incorrect connections will prevent proper assembly.



2



# Assembly Instructions


3

**This is a key step.**

Ensure the holes on Frame I, Frame K, and Frame N face the direction shown by the arrows. Install Frames I, K, and N as shown. Incorrect installation will prevent proper assembly.







x2



# Assembly Instructions

4




Install Frame J with the holes on its side facing Frame I.




# Assembly Instructions

5





Connect Frame O to Frame Q, ensuring the holes on Frame O are facing the correct direction.


|    |   |
|----|---|
| O  |  |
| x2 |   |
| 1  |  |
| x4 |   |
| 11 |  |
| x1 |   |



# Assembly Instructions



6



|    |   |
|----|---|
| C  |  |
| x2 |   |
| 1  |  |
| x4 |   |
| 9  |  |
| x2 |   |
| 11 |  |
| x1 |   |



# Assembly Instructions

7



|          |   |
|----------|---|
| 2<br>x8  |  |
| 11<br>x1 |  |



# Assembly Instructions

8


Install Frame M ensuring the holes face the correct direction.



# Assembly Instructions

9





Note the correct orientation (front/back side) of Panels A and B during installation.




|                |  |                |  |                 |  |                |  |                 |  |
|----------------|--|----------------|--|-----------------|--|----------------|--|-----------------|--|
| <b>A</b><br>x2 |  | <b>B</b><br>x1 |  | <b>1</b><br>x18 |  | <b>9</b><br>x4 |  | <b>11</b><br>x1 |  |
|----------------|--|----------------|--|-----------------|--|----------------|--|-----------------|--|





# Assembly Instructions


10

|    |   |
|----|---|
| E  |  |
| x2 |   |
| F  |  |
| x2 |   |
| 2  |  |
| x2 |   |
| 11 |  |
| x1 |   |



11



|     |   |
|-----|---|
| D   |   |
| x2  |   |
| H   |  |
| x4  |   |
| 2   |  |
| x20 |   |
| 11  |  |
| x1  |   |



# Assembly Instructions

12


The desk shelf can be used independently on its own or fixed securely to the desktop.



# Assembly Instructions


OR

You can choose either of the two installation methods.




# Assembly Instructions


13




1. Insert the guide rail diagonally at a 45° angle into the square hole simultaneously from both front and back.



2. Lift the lower corner of the guide rail and insert it into the square hole.




3. Align the guide rail with the steel pipe and press it down into place.




# Assembly Instructions


14




1. Insert the guide rail diagonally at a 45° angle into the square hole simultaneously from both front and back.



2. Lift the lower corner of the guide rail and insert it into the square hole.




3. Align the guide rail with the steel pipe and press it down into place.



# Assembly Instructions


15



# Assembly Instructions

16

Caution: During installation, take care to prevent the glass from falling and shattering to avoid injury.




# Assembly Instructions

17


12

x1



18


x4




# Assembly Instructions

19

Attention: Due to the special material, there may be a slight odor in the drawers. This odor is a normal phenomenon and is harmless to human health. Please do not wash the drawer. Simply allow for natural ventilation for a few days to reduce or eliminate the odor.




20



# Assembly Instructions

21



Light up the strip to distinguish between the front and back, then stick the 3M adhesive to the back of the strip. Sticking the 3M adhesive to the front of the strip will block the light.



# Assembly Instructions

22



Apply the LED strip to the back side of Panel A and Panel B.



# Assembly Instructions

23

Firstly, use an electric drill to create a hole in the wall with a diameter of 0.2-0.24 inches and a depth of 1.18-1.58 inches. Then, use a hammer to fully drive Part c into the hole. Lastly, use a screwdriver to lock Screw b through Part a into Part c. Note: Please be cautious not to over-tighten Part b.



|    |    |  |    |  |    |  |
|----|----|--|----|--|----|--|
| 15 | a  |  | b  |  | c  |  |
| x1 | x2 |  | x2 |  | x2 |  |

C

Static Color Button


M

Dynamic Mode Button

⏻

S / B

Speed & Brightness  
and Power Button



## STATIC COLOR BUTTON

Press this button once to switch to the static color mode, and then each pressing can change the color.

## DYNAMIC MODE BUTTON

Press this button once to switch to the dynamic mode effect, and then each pressing can change the dynamic mode.

Press this button for more than 3s to switch to the demo mode; In the demo mode, the strip will automatically cycle through various dynamic modes.

## SPEED & BRIGHTNESS AND POWER BUTTON

A. In the static mode, press this button to adjust the brightness of the light bar; each press can switch to a brightness level.

B. In the dynamic mode, press this button to adjust the dynamic mode speed; each press can switch to a speed level.

C. Press and hold this button to shut it down when the strip is on. Press this button to turn it on when the strip is off.

The product has a power-off memory function; the strip can restore the color, brightness, and mode in the next power-on.



## 30 DAY Return Policy

If you're not completely satisfied with your purchase, please return the merchandise via our Official Customer Support. Unused merchandise can be refunded or exchanged within 30 days of purchase.



## 1-Year Warranty

We guarantee your product is free from defects in product material and workmanship for one (1) year starting from the date of purchase during normal use of household conditions. If your appliance fails to operate properly within our warranty period, we will arrange a new one. Replacement is free and all shipping costs are covered.



## Quick Response within 24 Hours

If you are still unable to resolve the issue you are experiencing, please contact us immediately via our support email. It doesn't matter if the product has been installed or not, our customer support team will respond within 24 hours and assist you quickly and efficiently. The most efficient way to confirm your problem to us is to attach a video, which illustrates your product issues.

# Problems You May Encounter

| PART          | PROBLEM   | SOLUTION   |
|---------------|---|--|
| Whole Product | Parts are missing, defective or having wrong parts in package.            | You can contact us and we will get back to you within 24 hours.<br>Or, you can reach us via after-sales email.   |
|               | Having issue(s) while reading the instruction or completing the assembly. | You can contact us and we will get back to you within 24 hours.<br>Or, you can reach us via after-sales email.   |
|               | Encountering non-human caused damage during usage.                        | If the product is damaged due to non-human causes, please keep the product and send us photos of it. We will ascertain the cause of the product damage within 48 hours and provide you with a satisfactory solution.       |
| Table Surface | Board Surface is broken, scratched or lack of somescrew holes.            | You can contact us and we will get back to you within 24 hours.<br>Or, you can reach us via after-sales email.   |
|               | The screw holes that on the board and the steel frame don't line up.      | 1. Please tighten the screws on the board by 70%, do not tighten completely.<br>2. Adjusting board and steel frame until the screw holes are lined up, then tighten all the screws.  |
|               | The board is uneven or not tight that has gaps after being assembled.     | 1. Loosen the screws in the uneven or gap positions; adjust until the desktops are flat and tight, and then tighten the screws.<br>2. If your problem still can't be solved, please feel free to contact us.               |
| Steel Frame   | The steel frame is bent, broken, painted, rusted or damaged.              | You can contact us and we will get back to you within 24 hours.<br>Or, you can reach us via after-sales email.   |
|               | The table is unstable after being assembled.                              | 1. Check if the screws are tightened.<br>2. Read throughout the manual, check are there any parts installed incorrectly or missing assembled.<br>3. If your problem still can't be solved, please feel free to contact us. |
|               | Encountering non-human caused damage during usage.                        | If the product is damaged due to non-human causes, please keep the product and send us photos of it. We will ascertain the cause of the product damage within 48 hours and provide you with a satisfactory solution.       |

We are committed to providing our customers with premium quality products and convenient customer service.

MADE IN CHINA