



Metal Garden Shed

OWNER'S MANUAL

Size 10 Ft X 12Ft



Tall walk in Shed

Quick & Easy Assembly

Ridge Reinforced walls





Wide Double Doors

Available in Various Sizes

















Take care of sharp edges;

















Please wear gloves;

It will take 2 people 4 - 5 hours to install.







PARTS LIST



NO1	PART	QTY
D1		1
D1R		1
D1L		1
D2R		2
D2L		2
D3L		1
D3R		1
S1		1
S1L		1
S1R		1
S2R		2
S2L		2
S3L		1
S3R		1
KL		1
KR		1



NO1	PART	QTY
L1L		2
L1R		2
B1		4
B2L		2
B2R		2
C		2
L3		2
L4L		2
L4R		2
GB1		4
GB2		6
GW1		3
M2		4
M3		4
M4		2
M5L		1

NO1	PART	QTY
M5R		1
Q1		17
Q2		4
Q3		9
Q4		24
M		4
J1		4
FJT		4
GE		2
SK		1
HY		4
CS		2
F1		517

PARTS LIST

NO1	PART	QTY
F3		28
F8		9
LSM		95
F14		440

NO1	PART	QTY
F4		16
F10		20

NO1	PART	QTY
L5		1
F11		31

Install LSM at screw exposure, Prevent collisions.

This part is used with all screws, Such as F1 and F3, located in the external tool room, Easy to seal and waterproof.

Warning & Attention:

-Take care of sharp edges; Please wear gloves;

-All the tags except the foundation are facing inward

-You are advised to read the whole procedure before installing it

-Try to assemble this product on the flat ground, otherwise it is difficult to carry out;

-It would be much easier to assemble the product with three or more people;

-All panels are clearly marked and care should be taken to use the correct one. It is important that these instructions are followed step by step.

-After assembly, please check whether all screws are tightened, to prevent parts from falling apart.

Tools:



Gloves



Ladder



Electric drill



Phillips screwdriver




Safety Helmet Hat




goggles

Unit: mm



NO.	PART	Qty.	NO.	PART	Qty.	NO.	PART	Qty.	NO.	PART	Qty.
D1		1	D2R		2	D3L		1	F14		28
D1L		1	D2L		2	F1		28			
D1R		1	D3R		1	F8		9			

tips: All F1 and F14 should be used together.
The following steps are not explained.



Notice:


A: The foundation frame of the four corners is spliced together as shown in the figure, and it is fixed with F1.

B: Splice the foundation at point B, align the holes, and fix them with F1.

F8 Installation: After the overall installation is completed, if it is a dirt floor, please install the F8 to
The location is shown in the picture, and the expansion screws can be installed on other floors.






The installation space should be flat, and at least 4000x5000mm. The foundation is fixed on the ground in this space.



NO.	PART	Qty.
S1R		1
S1L		1
S1		1

NO.	PART	Qty.
S2L		2
S2R		2
S3L		1




NO.	PART	Qty.
S3R		1
F1		15
FJT		4




Notice:

A: FJT is installed at the junction of two arrows, please install the direction indicated by the arrow (→←), fix it with F1 after installation.

B: Connect two places as shown and fix them with F1.





NO.	PART	Qty.
Q2		4
F1		12




Notice:





In this step, only the three holes in the middle of Q2 need to be installed and reserved on both sides. The reserved holes are shared with the following steps.




NO.	PART	Qty.
F1		12











Notice:
 In this step, only the middle three holes need to be installed, and both sides need to be reserved.
 The reserved hole is shared with other steps.
 The walls are tiled on the outside and framed on the inside.


NO.	PART	Qty.
Q1		17
Q3		9
F11		29
F1		208



Notice:
 As shown in the picture, assemble the wall tiles in turn, Q1\Q3. The top, middle and bottom of the wall tiles need to be screwed.
 The upper and lower ends are fixed with F1, and the middle is fixed with F11.



NO.	PART	Qty.	NO.	PART	Qty.
KL		1	F11		2
KR		1			
F1		8			












Notice:


As shown in the picture, the steps of door frame and wall tile installation are the same.

The upper, middle and lower parts of KR and KL need screws.

The upper and lower ends are fixed with F1 (the hole position should be manually bent 90 degrees first) and F1, and the middle is fixed with F11.



NO.	PART	Qty.	NO.	PART	Qty.	NO.	PART	Qty.	NO.	PART	Qty.
B1		4	B2R		2	L1R		2	F3		6
B2L		2	L1L		2	C		2	F1		20





Notice:


Step A: Connect L1L and L1R with 2 B1s, fix F3 (fix the top two holes first), There are holes on both sides of B1, and the large holes are 2 B1 and L1R and L1L connected together. The position of the small hole is 2 B1s, connected to L1R and L1L respectively, and fixed with F1 from the outside to the inside.

Step B: Fix B2R and B2L to L1L and L1R with F1 as shown in the picture. There are holes on both sides of B2R and B2L, and the big holes of B2R and B2L connecting L1L and L1R. The small holes of B2R and B2L, connected to L1R and L1L respectively, and fixed with F1 from the outside to the inside.

Step C: As shown in the picture, install C to the specified position and secure it with F3.







NO.	PART	Qty.
F1		20






Notice:



Install the assembled roof support pieces on the wall tile in turn according to the holes, and fix them with F1.







NO.	PART	Qty.
L3		2
L4L		2
L4R		2



NO.	PART	Qty.
L5		1
F1		2

NO.	PART	Qty.
F3		22




Step A: Connect L4R and L4L with F3, mounting both sides outward, as shown in the picture.
 Step B: Insert the connected L4R and L4L into the B2L and B2R holes respectively, and fix them with F1.
 Step C: Fix L5 and 2 L3s together with F3, L3 above and L5 below, and place them on L1R and L1L. Position 1 requires temporary installation. This hole is shared with Q4. When installing the Q4, you need to disassemble and reconnect it.
 Step D: the other end of the part C needs to be connected to the L3 hole and fixed with F1.




NO.	PART	Qty.
Q4		24
F1		144





Special note: The installation of F1 must add plastic gaskets, which can play the role of roof waterproof.




Notice:

Q4 Installed in sequence, every 2 pieces overlap,
 There are 2 rows of holes in the tile, and the one near the edge is on the top, as shown in Figure A.
 The distance from the edge is far below, as shown in Figure C.
 Each Q4 requires a fixed 3 rows of F1, as shown in Figure ABC.




NO.	PART	Qty.	NO.	PART	Qty.
GB1		4	F1		8
GB2		6	J1		4


Special note: The installation of F1 must add plastic gaskets, which can play the role of roof waterproof.





Notice:


Step A: Fix 2 GB2 parts with F1, fix other holes with F1.
 Step B: Fix GB1, GB2, J1 parts with F1.



NO.	PART	Qty.
GW1		3

NO.	PART	Qty.
GE		2
F1		10

Special note: The installation of F1 must add plastic gaskets, which can play the role of roof waterproof.








Notice:




Step A: GW1 are fixed at the top with F1.




Step B: GE is fixed at both ends with F1.




① Description: The holes on the most sides are shared by GW1, Q4 and GB1.





NO.	PART	Qty.
M2		4
M3		4
M4		2


NO.	PART	Qty.
M5L		1
M5R		1
M		4


NO.	PART	Qty.
SK		1
HY		4
CS		2







NO.	PART	Qty.
F1		10
F4		16
F10		20



NO.	PART	Qty.
F4		18

NO.	PART	Qty.
F10		8

NO.	PART	Qty.
F11		2



Special Instructions:

Before installation, the HY must be mounted on the M4 and protected by the F10.

Two HYs must be installed on each M4, as shown in Figure A.

Then install the installed picture A on M → and M2 on the top and bottom of M



→ Install the M4/M5L/M5R on the left and right sides of the M → Mount the M3 on the inside of the M,


They are then secured with screw F11 as shown in Figure B.

Point E is inserted from the outside with F4 to facilitate the subsequent installation of the latch


Finally, the middle of both sides of M and the other end of M3 are reinforced

Use F4, as shown in Figures C and D.


NO.	PART	Qty.
F1		4
F4		2






NO.	PART	Qty.
F10		12



Notice:
Secure the installed door to the door frame with F10



NO.	PART	Qty.
SK		1
F1		6



Notice:
Mount SK to the door (M5R/M5L), secure with F1, mount A1 on one side of the door, Install the A2 section on the other side, as shown.

