

ASSEMBLY INSTRUCTIONS

3PC Bistro Set, Black / Cherry Finish




This page lists all the contents included in the box. Please take the time to identify the hardware as well as the individual components to this product. As you unpack and prepare for assembly, place the contents on a carpeted or padded area to protect them from damage.

cleaning & care Treat surface with care. Surface is resistant to scratches but is not scratch resistant. Clean surfaces with a dry or damp soft cloth. Do not use abrasive cleaners. Hardware may loosen over time. Periodically check that all connections are tight.


GENERAL INFORMATION, TIPS & TRICKS

1. Please read the assembly instructions prior to assembling this product.
2. To avoid damages, assemble this product on a non-abrasive surface such as carpet.
3. Make sure all bolts and nuts are tightly fastened before the product is used.
4. Not for commercial use.
5. Care: Wipe with a damp cloth. Use furniture polish or lemon oil on the wood as needed. Avoid prolonged exposure to moisture.


Please make sure you have all parts before beginning assembly. Please wait until all steps are completed before tightening bolts. We recommend two people to assemble.



A Phillips head screwdriver is necessary for assembly.



1. Insert the "T" nut into the larger predrilled hole in one panel, making sure its center hole is facing toward the hole through which the bolt will attach. Be sure the top of the "T" nut with the slots out. You can adjust the direction its center hole faces once it's in the hole using a Phillips screwdriver.
2. Attach both panels by inserting the bolt through the predrilled hole of the second panel and screwing it into the "T" nut.












1. Screw the metal dowel screw into the predrilled plastic hole.
2. Attach both panels. Ensure the head of the metal dowel screw is centered in the predrilled hole of the second panel. If it is not, then screw it in farther or back it out until the head is centered.
3. Insert the cam lock into the predrilled hole over head of the metal dowel screw. Use a Phillips screwdriver and turn the cam lock until tight, which is about one-half turn. Remember - completely tighten cam locks only after the entire unit is assembled.

Note: Over-tightening may result in the cam lock breaking. The cam lock is locked after half-a-turn or 180 degree turn.

Do not put hot pots or objects which are more than Fahrenheit 80 degrees directly on the table.

TABLE PARTS LIST

A. TABLE TOP	B. TABLE LEG (LEFT FRONT / RIGHT BACK)
	
QTY: 1 PC	QTY: 2 PCS
C. TABLE LEG (RIGHT FRONT / LEFT BACK)	D. BOTTOM PANEL
	
QTY: 2 PCS	QTY: 1 PC
E. TOP PANEL	F. SIDE PANEL
	
QTY: 1 PC	QTY: 2 PCS
G. MIDDLE PANEL	H. DIVIDER PANEL
	
QTY: 1 PC	QTY: 2 PCS
I. BASE SHELF	
	
QTY: 1 PC	

CHAIR PARTS LIST

















J. CHAIR BACK FRAME	K. SEAT BOARD
	
QTY: 2 PCS	QTY: 2 PCS
L. SEAT FRAME	M. CHAIR FRONT LEFT LEG
	
QTY: 2 PCS	QTY: 2 PCS
N. CHAIR FRONT RIGHT LEG	O. FRONT CROSSBAR
	
QTY: 2 PCS	QTY: 2 PCS
P. SIDE CROSSBAR	
	
QTY: 4 PCS	

TABLE HARDWARE LIST

1. BOLT 5/16" Dia x 2-1/2"L	2. SPRING WASHER
	
QTY: 8 PCS	QTY: 8 PCS
3. FLAT WASHER	4. BOLT 1/4" Dia x 2"L
	
QTY: 8 PCS	QTY: 4 PCS
5. CAM LOCK	6. METAL DOWEL SCREW
	
QTY: 4 PCS	QTY: 4 PCS
7. "T" NUT	8. WOOD DOWEL
	
QTY: 4 PCS	QTY: 8 PCS
9. ALLEN KEY	
	
QTY: 1 PC	

CHAIR HARDWARE LIST










10. LONG BOLT 1/4" Dia x 3"L	2. SPRING WASHER
	
QTY: 8 PCS	QTY: 22 PCS
3. FLAT WASHER	11. SHORT BOLT 1/4" Dia x 1-3/4"L
	
QTY: 22 PCS	QTY: 6 PCS
12. HEX NUT	13. WOOD SCREW
	
QTY: 8 PCS	QTY: 24 PCS
14. OPEN END WRENCH	
	
QTY: 1 PC	

TABLE ASSEMBLY INSTRUCTIONS

REQUIRED HARDWARE IN THIS STEP			
NO.	DESCRIPTION	SKETCH	QTY
5	CAM LOCK		4
6	METAL DOWEL SCREW		4




Diagram #1




Diagram #2

1. Screw the 4 metal dowel screw (6) into the pre drilled plastic hole. Attach side panels (F) to the top panel (E) using 4 cam locks (5) and 4 metal dowel screws (6) as shown.

TABLE ASSEMBLY INSTRUCTIONS




Diagram #3

2. Attach the middle panel (G) to the assembled from diagram #3 as shown.

TABLE ASSEMBLY INSTRUCTIONS




Diagram #4

3. Attach the divider panels (H) into the groove on the middle panel (G) as shown.

TABLE ASSEMBLY INSTRUCTIONS






REQUIRED HARDWARE IN THIS STEP			
NO.	DESCRIPTION	SKETCH	QTY
4	BOLT		4
7	NUT		4
9	ALLEN KEY		1

Diagram #5



4. Attach bottom panel (D) to the assembled from diagram #5 using 4 "T" nut (7) and 4 bolts (4) as shown. Tightly fasten the bolts using Allen key (9).

TABLE ASSEMBLY INSTRUCTIONS

REQUIRED HARDWARE IN THIS STEP			
NO.	DESCRIPTION	SKETCH	QTY
8	WOOD DOWEL		4




Diagram #6








Diagram #7

5. Attach bottom panel (D) to the assembled from diagram #7 using wood dowel (8) as shown.

TABLE ASSEMBLY INSTRUCTIONS

REQUIRED HARDWARE IN THIS STEP			
NO.	DESCRIPTION	SKETCH	QTY
1	BOLT		2
2	SPRING WASHER		2
3	FLAT WASHER		2
9	ALLEN KEY		1










Diagram #8

6. Attach base panel (I) to table legs (B&C) using 2 spring washers (2), 2 flat washers (3), 2 bolts (1) as shown. Tightly fasten the bolts using Allen key (9).

TABLE ASSEMBLY INSTRUCTIONS


REQUIRED HARDWARE IN THIS STEP			
NO.	DESCRIPTION	SKETCH	QTY
1	BOLT		2
2	SPRING WASHER		2
3	FLAT WASHER		2
8	WOOD DOWEL		4
9	ALLEN KEY		1



7. Attach table legs (B&C) to base panel (I) and side panel (F) using 4 wood dowel (8), 2 spring washers (2), 2 flat washers (3) and 2 bolts (1) as shown. Tightly fasten the bolts using Allen key (9).





TABLE ASSEMBLY INSTRUCTIONS

Diagram #10



8. turn the table base upright. Place the table top (A) on the table legs as shown.

TABLE ASSEMBLY INSTRUCTIONS

REQUIRED HARDWARE IN THIS STEP			
NO.	DESCRIPTION	SKETCH	QTY
1	BOLT		2
2	SPRING WASHER		2
3	FLAT WASHER		2
9	ALLEN KEY		1





Diagram #11



9. secure the table top (A) to the table base using 4 bolts (1), 4 spring washers (2) and 4 flat washers (3) as shown. Tightly fasten the bolts using Allen key (9).

TABLE ASSEMBLY INSTRUCTIONS





Diagram #12




10. The table is now ready for use.

CHAIR ASSEMBLY INSTRUCTIONS

Diagram #1

REQUIRED HARDWARE IN THIS STEP			
NO.	DESCRIPTION	SKETCH	QTY
2	SPRING WASHER		7
3	FLAT WASHER		7
10	LONG BOLT		4
11	SHORT BOLT		3





1. Attach seat frame (L) to back frame (J) using 7 spring washers (2), 7 flat washers (3), 3 short bolts (11) and 4 long bolts (10) as shown. Do not tighten at this point.

Note: Use the 3 short bolts (11) in the 3 holes near the center of the back of the seat frame (L) and the 4 long bolts (10) in the back corners of the seat frame (L).

CHAIR ASSEMBLY INSTRUCTIONS

Diagram #2

REQUIRED HARDWARE IN THIS STEP			
NO.	DESCRIPTION	SKETCH	QTY
13	WOOD SCREW		6







2. Place seat board (K) upside down on a non-abrasive table surface. The rear (tapered end) of the seat board (K) should be near the table edge.


Hint: Protect the non-abrasive table surface and seat board (K) by laying a towel in-between the chair seat and table.

3. Place the assembled chair frame on the seat board (K) as shown. Attach with 6 wood screws (13).

CHAIR ASSEMBLY INSTRUCTIONS

Diagram #3


REQUIRED HARDWARE IN THIS STEP			
NO.	DESCRIPTION	SKETCH	QTY
2	SPRING WASHER		4
3	FLAT WASHER		4
12	HEX NUT		4
14	OPEN END WRENCH		1




4. Attach the left and right front legs (M&N) to seat frame (L) using 4 spring washers (2), 4 flat washers (3), and 4 hex nuts (12) as shown. Do not tighten at this point.
5. Insert the front crossbar (O) into the oval holes of left and right front legs (M&N) as shown. The small holes on the edge of the crossbar need to face towards the bottom of the leg.
6. Insert side crossbars (P) into the round holes of left and right front legs (M&N) and back frame (J). The small holes on the bottom of the crossbars must face the bottom of the chair.

CHAIR ASSEMBLY INSTRUCTIONS

Diagram #4

REQUIRED HARDWARE IN THIS STEP			
NO.	DESCRIPTION	SKETCH	QTY
13	WOOD SCREW		6




7. Turn the chair upright. Make sure the assembled chair unit is level and square. Tightly fasten all bolts with the open-end wrench (4).
8. Secure the front and side crossbars (P) to their chair legs with 6 wood screws (13).

Note: Screwing the wood screws (13) to secure the front crossbar (O) by first. Then make sure the small holes on the bottom of side crossbars (P) are partial inside, screwing the wood screws (13) to secure the side crossbars (P).

CHAIR ASSEMBLY INSTRUCTIONS

Diagram #5



9. The Chair is now ready for use.

10. Repeat steps 1 to 8 to assemble the other chair.

Printed in Vietnam