


Metal Storage Shed 6'x8' FT

Instructions for Assembly



It will take 1.5-2 hours for 2 people to install.

WARNING

Please read the instruction manual carefully before assembly

Please assembly strictly in accordance with the instruction

Please double-check to ensure that all parts of the package contents intact

To avoid injury , work gloves are recommended during assembly

Owner's Manual

Before beginning construction, check local building codes regarding footings, location and other requirements. Study and understand this owner's manual. Important information and helpful tips will make your construction easier and more enjoyable.

Assembly Instructions: Instructions are supplied in this manual and contain all appropriate information for your building model. Review all instructions before you begin, and during assembly, follow the step sequence carefully for correct results.

Parts and Parts List: Check to be sure that you have all the necessary parts for building .

Separate contents of the carton by the part number while reviewing parts list.

The first few steps show how to join related parts to make larger sub assemblies which will be used later.

Familiarize yourself with the hardware and fasteners for easier use during construction.

These are packaged within the carton. Note that extra fasteners have been supplied for your convenience.

PLAN AHEAD

Watch the Weather: Be sure the day you select to install your building is dry and calm.

Do not attempt to assemble your building on a windy day.

Teamwork: Whenever possible, two or more people should work together to assemble your building. One person can position parts or panels while the other is able to handle the fasteners and the tools.

Tools and Materials: These are some basic tools and materials you will need for the construction of your building. Decide which method of anchoring and the type of foundation you wish to use in order to form a complete list of the materials you will need.

CARE & MAINTENANCE

Finish: For long lasting finish, periodically clean and wax the exterior surface. Touch-up scratches as soon as you notice them on your unit. Immediately clean the area with a wire brush; wash it and apply touch-up paint per manufacturer's recommendation.

Roof: Keep roof clear of leaves and snow with long handled, soft-bristled broom. Heavy amounts of snow on roof can damage building making it unsafe to enter. In snow country, Roof Strengthening Kits are available for most Arrow Buildings for added protection against heavy snow accumulation.

Doors: Always keep the door tracks clear of dirt and other debris that prevent them from sliding easily. Lubricate door track annually with furniture polish or silicone spray. Keep doors closed and locked to prevent wind damage

Fasteners: Use all washers supplied to protect against weather infiltration and to protect the metal from being scratched by screws. Regularly check your building for loose screws, bolts, nuts, etc. and retighten them as necessary.

Moisture: A plastic sheet (vapor barrier) placed under the entire floor area with good ventilation will reduce condensation.































Other Tips....































Wash off inked part numbers on coated panels with soap and water.

Silicone caulking may be used for watertight seals throughout the building.


Do not store swimming pool chemicals in your building. Combustibles and corrosives must be stored in air tight approved containers.









PARTS LIST

NO	PART	QTY
25L		1
25R		1
P1		2
P4		2
P2		4
27		2
15		2
16		2
17		2
17A		1
H1		2
P3		12
18		2
18A		1
13		4
14		4
P5		4
P5A		2
P6		4
P6A		2
P7		2
P7A		1
B1		8
13		1
14		1
H6		2
D1		1
D2		1
28		2
GJ		2
30		2

NO	PART	QTY
20		4
19		2
21L		2
21R		2
GF		4
1		2
2		2
3L		1
3R		1
4L		1
4R		1
5		1
6		1
7		1
8		1
9		2
11		2
10L		1
10R		1
F1		374
F2		100
F3		8
G2		4
S1		168
GC		4
GD		4
GE		2
GB		2
9L		2
9R		2



1. Assemble base bars from (1) to (4R) with (F1) Screws. Then place the entrance taper channel (5) on top of the bar (3L) and (3R). Secure with $\sigma 1$ screws to the foundation. Seeing the following figures. Make sure the base bar assembly in a perfect square.









PART	NO.	Qty.
	1	2
	2	2
	3L	1
	3R	1
	4L	1
	4R	1
	5	1
	F1	24


2. Place the wall panel(P1) (P2) (P3) and(P4)on the base as showing.

Side wall of the shed line up the holes With base bar. Secure with(F1).Screws with washers from outside.




PART	NO.	Qty.
	P1	2
	P2	4
	P3	12
	P4	2
	F1	73
	F2	19

3. Insert the 2 pieces of (G2). Top slide into the Sliding channel (8) (7) . Assemble Door bar (6) between front wall panel (P1) .And then place the sliding channel (7) and (8) on top of front wall panels from inside. Line up the holes with wall panel. Use (F1) screws with washers to fix. See the position in figures below .
 Note:sliding channel (7) and(8)are nit have holes. It's soft,The screws easy can fix.




PART	NO.	Qty.
	6	1
	7	1
	8	1
	G2	4
	F1	14





4. Place the top angle bars(9),(10L),(10R) and(11) on the top of wall panel. Line up holes with wall panels and fix with (F1)screws.




Note:Make sure the overlapping position.




PART	NO.	Qty.
	9	2
	10L	1
	10R	1
	11	2
	F1	71


5. Place the left door column (25L) on the top of base bar, Insert into the wall panel, Then secure the door column(25L) with (F1) Screws. Repeat the same for the right door column (25R) with (F1) screws.










PART	NO.	Qty.
	25L	1
	25R	1
	F1	12





6. Place 4 piece of the Gable panels (21L) and (21R). Then assembly 2 each Gable panels (21L) and (21R) together with connector (B1), and assemble the connectors (B1) as showed. secure them with (F2) bolt and nut. see figures blow. Join two roof supports (13) and (14) together then fix 4 sets of roof structures into the Gabel pannels (21L) and (21R). Align the holes and secure with (F2) bolt and nut.





PART	NO.	Qty.			
	13	4			
	14	4			
	B1	8			
	21L	2		GF	4
	21R	2		F2	40






7. Place 4 piece of the Gable panels(21L)and(21R)(13)(14)on the top of the sliding channels(7)(8)and back top bars (10L)(10R),Align the holes and secure them with(F1)screws from inside as showed.



PART	NO.	Qty.
	F1	28

8. Place the roof panels(P5)(P6)and(P7)on the top of Gable panels and roof supports. Line up the boles and secure with(F1)bolt and nut withwashers.











PART	NO.	Qty.
	P5	4
	P6	4
	P7	2
	F1	66
	S1	168

9. Assemble (13) and (14) as shown in figure 1 and fix them with (F2) screws.


Then assemble the two groups (H1) and (H6) respectively as shown in the figure, and fix them with (F1) screws.





Finally, install (P5A) as shown in the picture and fix it with (F1) screws.




PART	NO.	Qty.			
	13	1			
	14	1			
	H1	2			
	H6	2		F1	12
	P5A	1		F2	4









10. Install (P5A) (P6A) (P7A) on the roof as shown in the picture and fix it with (F1) screws.




PART	NO.	Qty.
	P5A	1
	P6A	2
	P7A	1
	F1	45



11. Install edge guard (15), (16), (17), (18), (17A), (18A) and corner guard (GC) as shown in the picture and fix them with (F1) screws.




PART	NO.	Qty.			
	15	2			
	16	2			
	17	2			
	18	2			
	GC	4		17A	1
	F1	20		18A	1







12. Fix two (19) as shown in the picture with (F1) (F2) screws and put them on the roof. Fix (19) and tile with (F1) screws at both ends of the roof. Finally, install (GE) on both ends of (19) and fix them with (F1) screws.





PART	NO.	Qty.
	19	2
	GE	2
	F1	9
	F2	2



13. Install two (20), one (27), and two (GD) on the door panel (D1) as shown, secure with (F2) screws, and install the other door (D2) in the same way.




PART	NO.	Qty.
	27	2
	20	4
	D1	1
	D2	1
	GD	4
	F2	16


14. Install the (GB) door handle on the door panel (D1) (D2) as shown and secure it with (F2) screws.



PART	NO.	Qty.
	GB	2
	F2	3

15. Install the door panel (D1) (D2) as shown in the picture and secure it with (F3) screws.



PART	NO.	Qty.
	F3	8