1. Assembling the Frame

a.Unpack all components from the box.

Note: Handle parts gently to prevent damage.

b.Lay out all parts on a clean, flat surface.

c. Align the side panels of the drawer cart.

d.Connect the top and bottom panels to the side panels using the provided screws.

Note: Refer to the user manual for the exact location of the screw holes.

e. Tighten all screws securely but avoid overtightening.

2. Installing the Drawers

a. Slide the drawers into the tracks on the frame.

Note: Drawers will slide in smoothly when aligned properly.

b. Push the drawer all the way in until it clicks into place.

Note: This indicates that the drawer has locked in securely.

3. Attaching the Casters/Wheels

a. Turn the drawer cart upside down.

b.Insert the stem of each caster into the designated holes at the bottom of the drawer cart

c.Press down firmly until the caster snaps into place.

Note: Refer to the user manual for information on the exact location of the caster holes.

4. Adding Handles or Knobs

a. Find the pre-drilled holes on the front of each drawer.

Note: Some models might come with handles already attached.

b. Align the handle or knob with the holes.

c.Secure the handle or knob using the provided screws.

Note: Refer to the user manual for instructions on how to perform that action.

5. Locking Mechanism Setup (For Lockable Models)

a.Insert the key into the lock.

b. Turn the key to ensure the locking mechanism operates smoothly.

Note: Keep the key in a safe place when not in use.

Note: Refer to the user manual for information on the exact location of the lock.

6. Applying Protective Pads (Optional)

a. Peel the backing off the adhesive side of the protective pad.

b. Stick the pad to the bottom corners of the drawer cart.

Note: Protective pads can prevent scratches on delicate floor surfaces.

7. Positioning Your Drawer Cart

a. Move the drawer cart to its desired location.

b.Lock the wheels to prevent the cart from moving unintentionally.

Note: Typically, wheels have a small lever or button to lock them in place. Refer to the user manual for information on the exact location and operation of the wheel locks.