




INSTRUCTION MANUAL

70" TV Stand with Fireplace

HKTS006-70



NOTE: This product is divided into 2 packages and may arrived on different days. Please make sure that all packages are delivered before unpacking and assembling the product, if you have any questions, contact us ASAP.

WELCOME TO THE FUTURE OF HOME ENTERTAINMENT!

Thank you for choosing our new electric fireplace and TV stands! Our products are designed to be both stylish and functional, with a focus on energy efficiency and sustainability.

We use high-quality materials to ensure that our pieces are built last, so you can enjoy them for years. Whether you're looking for a cozy electric fireplace or a stylish TV stand, we have something for everyone.

Our products are perfect for any home or office, and we're confident that you'll love them as much as we do!



Wolfthontech1@gmail.com

NOTICE

- 1.Children are not allowed to operate
2. Faster installation is possible with power tools.
3. Do not pull the door vigorously to prevent the storage cabinet from tipping over.
- 4.Please attach the storage cabinet to the wall with an anti-tip device after installation is complete.
5. When using the storage cabinet for the first time,please keep it in a ventilated environment to allow the smell to fully evaporate.
- 6.When placing the partitions,please make sure the nails are firmlyinstalled to prevent the partitions from falling off.
7. If any parts are missing,broken,damaged or worn,discontinue use of the product until repairs are made and/or factory replacement parts are installed
8. Do not use this product in a manner inconsistent with the manufacturer's instructionsas this may void the product warranty
- 9.If accessories are missing, please contact customer service for communication in time, we provide 7x24 hours after-sales service
- 10.Do not use any attachments or accessories other than the original factory attachments and accessories
- 11.Do not alter this equipment. Any alteration will create a safety hazard.

BEFORE YOU START

- ⚠ Please read all instructions carefully.
- ⚠ Retain instructions for future reference.
- ⚠ Separate and count all parts and hardware.
- ⚠ Read through each step carefully and follow the proper order.
- ⚠ We recommend that, where possible, all items are assembled near to the area in which they will be placed in use, to avoid moving the product unnecessarily once assembled.
- ⚠ Always place the product on a flat, steady and stable surface.
- ⚠ Keep all small parts and packaging materials for this product away from babies and children as they potentially pose a serious choking hazard.

PRE-INSTALLATION

GRAB YOUR TOOLS



Phillips Screwdriver




2 Persons Assembly



Up to 60 Minutes For Assembly


WHAT'S IN THE BOX

1




1PC

2




1PC

3




1PC

4




1PC

5



1PC

6



1PC

7



1PC

8











1PC





9



1PC




HARDWARE



PRE-ASSEMBLY PREPARATION


Ensure all parts and hardware are included in the package.
Lay out all components on a flat, soft surface to avoid scratches.



PRODUCT ASSEMBLY


STEP 1

Insert the part (C) into the designated holes on panel ②. Make sure the white plastic anchors are fully inserted into the holes before inserting the dowels.



Cx 8PCS

STEP 2



Cx 2PCS




A x 2PCS

PRODUCT ASSEMBLY

STEP 3


Attach parts ⑭, ⑮, and ⑯ using cam bolts (B) as shown.

Insert the cam bolts (B) into the holes on the sides of parts ⑯, and fix them to part ⑭ and ⑮.



Bx 2PCS

STEP 4




Connect parts ⑭, ⑮, and ⑯ together, then attach the assembled unit to part ② using cam locks (B).




Bx 8PCS

PRODUCT ASSEMBLY

STEP 5




STEP 6




PRODUCT ASSEMBLY

STEP 7




STEP 8



PRODUCT ASSEMBLY

STEP 9

Use 4 cam locks (B) to connect part ② with parts ⑦ and ④. Repeat the same method to connect part ② with parts ⑧ and ⑤ using another 4 cam locks (B).




 Bx 8PCS

STEP 10

 Bx 4PCS


 Ax 4PCS





Use 1 (A) to attach part ⑪ to ⑤.
Then use another (A) to attach part ⑪ to part ③.
Use 2 cam locks (B) to connect part ⑤ with part ②.
Repeat the same steps to connect the ④ and ⑪, ⑥ and ⑪, ⑥ and ②.

PRODUCT ASSEMBLY

STEP 11



STEP 12




PRODUCT ASSEMBLY

STEP 13




Bx 6PCS

Use 2 cam locks (B) to connect part with parts ② and ⑬, Use 2 cam locks (B) to connect part with parts ⑨ and ⑤, Use 2 cam locks (B) to connect part with parts ⑩ and ⑥.



STEP 14




Cx 14PCS

PRODUCT ASSEMBLY

STEP 15


The fireplace and TV cabinet are packed in two separate boxes and maybe delivered on different days. The LED light strip is included in the fireplace packaging. Please install the light strip only after receiving both two packages.



Use the clips to secure the light strip and tighten the screws.

Peel off the adhesive backing of the light strip and stick it onto the board.

STEP 16



 Ax 4PCS


 Bx 14PCS

PRODUCT ASSEMBLY

STEP 17




Dx 8PCS




PRODUCT ASSEMBLY

STEP 18

The LED strip can be plugged directly into the USB port behind the fireplace. With just one remote control, you can choose the color of both the LED strip and the fireplace.




STEP 19




PRODUCT ASSEMBLY


STEP 20



STEP 21



PRODUCT ASSEMBLY




Final Check

1. Ensure all screws are tightened.
2. Verify that all panels are securely fitted.
3. Clean any dust or debris from the assembly process.

Your TV stand is now successfully assembled and ready for use! We hope you enjoy your new TV stand! If you're happy with the result, we'd love to see how it looks in your space. Share a photo of your setup and inspire others with your creativity. Your experience help us continue improving our products!

HELP CENTER


Question about your product? We're here to help. Visit us at:




Chat Support



Product inquiry



Orders FAQ



Product Assembly



Returns & Refunds

WE STAND BEHIND THE QUALITY OF OUR FURNITURE

1. If you have any issues with your item, please let us know! We will always do our best to come up with a solution that you will be happy with.
2. Please get in touch with our customer service team before returning the product.
3. And please do not throw away the original box(es) if you have not finished assembling and confirmed no quality issues.

Length of return period:

You can return items within 30 days of purchase

In the meanwhile, everything you purchased from us comes with a one-year warranty.

Who is responsible for the return shipping fee:

We will cover the return shipping fees if:

1. Your item has a manufacturing defect in materials or workmanship. For example, torn wicker or misaligned screw holes. We will send you a prepaid shipping label after you send us photos or videos of the defect.
2. Your item has been damaged in transit. For example, glass is broken or product is damaged. We will send you a prepaid shipping label after you send us photos of the damage.
3. You receive the wrong box(es) due to a warehouse error. We will send you a prepaid shipping label after you send us photos of the wrong SKU numbers on the outer box(es).
4. One or more boxes are lost in transit. We will send you a prepaid shipping label if you no longer want the item.

* However, we still hope to work with you for a better solution instead of a return. Please don't hesitate to contact our customer service team.

Customer will cover the return shipping fees if:

- 1.You don't like the product(s) after receiving the box(es).
- 2.You no longer need the product(s) but have received the box(es).
- 3.You buy the product(s) by mistake but have received the box(es).
- 4.Order/shipment cancellation failed, and you have received the box(es).

Return Request

In order to get a full refund as described in this return policy, all items must be:

- 1.In a brand new/unused condition. Please provide photos before and after packaging.
- 2.When returning, all accessories and parts must be firmly packed in all original packaging. If your return does not meet these requirements, you may not receive a full refund.

When will I be refunded?

The refund is issued once the goods have been returned to our warehouse.

What if the product is damaged/defective outside of the valid return period?

We want you to be a happy customer. Please reach out to us via email, and we will work on a solution to ensure your satisfaction.

HELP CENTER

Confuzzled? Email Our Customer Service At:

 YouTube :BREEZEHEAT

 CONTACT INFO: Wolfthontech1@gmail.com

Please feel free to **send us the text or email**. We will reply to you within 24 hours. Also please feel free to contact us if you have received the defective items.

Follow our YouTube Channel then you will be able to find our **assembling video** pinned video.

SAVE THESE INSTRUCTIONS