
























<p>A</p>  <p>40+2 pcs</p>	<p>B</p>  <p>∅ 15*9.5mm 40+2 pcs</p>	<p>C</p>  <p>∅ 8*30mm 40+2 pcs</p>	<p>D</p>  <p>M3.5*30mm 14+1 pcs</p>
<p>E</p>  <p>2 pcs</p>	<p>F</p>  <p>M6*18mm 2 pcs</p>	<p>G</p>  <p>M4*45mm 6 pcs</p>	<p>H</p>  <p>M6*22mm 2 pcs</p>
<p>I</p>  <p>∅21mm 4 pcs</p>	<p>J</p>  <p>M4 1 pcs</p>	<p>K</p>  <p>1 pcs</p>	<p>L</p>  <p>1 pcs</p>
<p>M</p>  <p>M4*12mm 1 pcs</p>	<p>N</p>  <p>M4*32mm 1 pcs</p>	<p>O</p>  <p>M3.0*14mm 12+1 pcs</p>	<p>P</p>  <p>12+1 pcs</p>
<p>Q</p>  <p>R</p> <p>6 est</p>		<p>S</p>  <p>M3.5*12mm 24+2 pcs</p>	<p>T</p>  <p>M3.5*14mm 4 pcs</p>

Step:1







Press the plastic latch ① and then pull the M out of N in the meantime.

	6 pcs	Q
	6 pcs	R







Step:2




	8 pcs	A
	6 pcs	R
	12 pcs	S


Step:3






	2 pcs	A
	2 pcs	B
	2 pcs	C




Step:4



	3 pcs	B
	2 pcs	C




Step:5




1 pcs **D**

Step:6



9






2 pcs **B**




2 pcs **C**


Step:7




	3 pcs	B
	2 pcs	C




Step:8






	1 pcs	D
---	-------	----------

Step:9





Step:10




	10 pcs	C
	6 pcs	G



Step:11




	12 pcs	A
---	--------	---


Step:12






	4 pcs	B
	4 pcs	C



Step:13






	8 pcs	B
	8 pcs	C






Step:14




	6 pcs	A
	1 pcs	K
	1 pcs	M

Step:15




	2 pcs	H
	1 pcs	J


Step:16







Step:17



	6 pcs	B
	10 pcs	C
	4 pcs	I




Step:18




	12 pcs	A
	12 pcs	D
	6 pcs	Q
	12 pcs	S



Step:19




12 pcs B



Step:20







Please push the ball rail section to the front end of R.




Push Q horizontally into R until you hear a "click".

Step:21





	12 pcs	O
	12 pcs	P



Step:22




Please refer to Step 21 - Drill 1 holes in the wall at the required height and position for anti-falling device after product installed, and then put the " L " plastic part into the hole.



Move the cabinet to the appropriate position, and then use the "N" long screw to lock the plastic part in the wall through the holes of L-shaped metal plate.




	1 pcs	L
	1 pcs	N


Step:23



	2 pcs	E
	4 pcs	T

Step:24



	2 pcs	F
---	-------	---