

Queen Bolt On Headboard and Footboard


1. Remove the two sides of the frame and lay them on their side. They are not side specific or end specific.



2. Swing the cross arms open as shown. Lay the frame open as shown.



3. With cross arms open and 90 degrees to the side rail, insert the two rivet heads into the two key hole slots and pull to the end of the slot. These will be the set of slots furthest from the leg. There is a hole in the top of both cross arms. Install a nut and bolt through both cross arms at both ends of the frame. Secure with wrenches provided.



4. Find the 4 threaded glides/feet with the adjustment nut and black insert already on them. Insert the glides into the bed legs as shown. If you want your frame to be a specific height you can adjust that now, otherwise wait until you line up the head and footboard.




Queen Bolt On Headboard and Footboard

5. Next, find your headboard brackets. Attach the brackets to the head end of the frame loosely. Stand the headboard up to the brackets and see which holes you should use in the brackets to line up the mounting holes in the leg of the headboard. Pick the closest you can, then adjust the frame legs up or down to get it exact. Tighten the brackets and then use the same holes in the foot end of the bed. Ideally, you want the headboard and footboard to be resting on the floor with just the slightest amount of weight from the bed pushing down on the headboard and footboard.

If it is on carpeting, it will settle overnight, so you should check the 4 corners in the morning to make sure they are all touching the floor and all the weight is not on the head and footboard legs or that the legs of the head and foot also have some weight on them. You can tell by turning the glide. If it goes lower, too much weight is on the headboard.

6. Next find the 59 3/8" long center bar. It will go side to side across the middle of the bed. Put the remaining glide/foot into the leg on the center bar. Slide the bar under the siderail.

The hole in the siderail lines up with the hole in the center bar. Insert the bolt and nut and tighten. Adjust the center bar so the glide/foot just barely touch the floor or are slightly off. The weight of the bed will bring them firmly to the floor.



7. Should you have any issues or questions about this installation or other bedding related questions, email us and we will respond promptly.