



# WARNING!




Estimated Time for Assembly


**60 mins**




Weight Limitation




Watch out for collisions




Assembly the furniture on empty carton, carpet, or rug to prevent scratches or damage.




This furniture requires 2 people to assembly.  
Make sure no parts are missing or damaged before assembly.




Not actual size




Ⓐ X1




Ⓑ X1




Ⓒ X1




Ⓓ X1




Ⓔ X1




Ⓕ X1




Ⓖ X1




Ⓗ X3




Ⓘ X3




Ⓙ X1




Ⓚ X1




Ⓛ X1




Ⓜ X2




Ⓝ X2




Ⓞ X2




Ⓟ X1




Ⓠ X2



Ⓡ X1



Ⓢ X2



Ⓣ X2

①


X55+2



Ø15\*9.5

②


X55+2



Ø6\*35

③


X50+2



Ø6\*30

④


X32+2



Ø3\*12

⑤


X6



Ø4\*14

⑥

X3



Ø4\*50


⑦

X6




⑧

X1





# STEP 1






# STEP 2

Push a CAM LOCK into the part  
The arrow in the CAM LOCK must  
point toward the hole on the edge  
of the board







CAM LOCK



①	X4
	
ø15*9.5	


# STEP 3



①	X9	②	X9	③	X6
					
ø15*9.5		ø6*35		ø6*30	





# STEP 4





①	X8
ø15*9.5	


③	X8
ø6*30	

# STEP 5




①	X5
	
ø15*9.5	


②	X5
	
ø6*35	



③	X4
	
ø6*30	

# STEP 6




# STEP 7







①	X4	③	X4
			
ø15*9.5		ø6*30	

# STEP 8




# STEP 9



①	X6
	
ø15*9.5	


# STEP 10





①	X8
ø15*9.5	

③	X8
ø6*30	

# STEP 11




①	X4
	
ø15*9.5	


③	X4
	
ø6*30	





# STEP 12




X3


⑧	X1
	


②	X4
	
ø6*35	


③	X2
	
ø6*30	

⑥	X3
	
ø4*50	

# STEP 13




①	X4
	
ø15*9.5	




③	X4
	
ø6*30	

# STEP 14

Place two items underneath the product to make the product stable and easy to install




If the lifting is not standard, it will cause uneven force and lead to deformation of finished products



# STEP 15


We have included a set of tipping restraint hardware for this unit. You must install this hardware to prevent accidents or injuries that can result from the unit falling. When properly installed, this restraint can provide protection against the unexpected tipping of the unit due to small tremors, bumps or climbing. We strongly recommend mounting this hardware to a wall stud and your unit

NOTE: The tipping restraint hardware included is for wooden stud wall construction. It must be attached to a wall stud. Depending upon your wall construction different anchor hardware maybe required. Please contact your local hardware store for assistance. Young children can be seriously injured by tipping furniture. You must install the tipping restraint hardware with the unit to prevent the unit from tipping, causing any accidents or damage. The tipping restraints are intended only as a deterrent and are not a substitute for proper adult supervision. The tipping restraints are not earthquake restraints. If you wish to add the extra security of earthquake restraints, they must be purchased and installed separately.




## STEP1

drill two Ø6 holes on the wall




## STEP2

put two anchors in the holes



## STEP3

fix the device on the wall by the long screws



## STEP4

fix with 9C

