



CLOSET SYSTEM

ASSEMBLY INSTRUCTION





CAUTION

Put the screws in loosely until all pieces are together and then tighten them all.
It will save your time if you make a mistake while installing.

! IMPORTANT


Please follow the instruction manuals and use a pad to protect the product during your assembly.



Using Camlocks


Connect the male camlock as directed in the assembly instructions using a screwdriver.

1 DO NOT OVER TIGHTEN



Push the male camlock into the entry hole.


2



Insert the female camlock as shown in the instruction.

Note: ensure that the arrow on the top of the camlock points toward the entry hole for the male camlock.

3





Turn the female camlock clockwise with a screwdriver.

You should feel a click when the camlock is locked in place.




















The joint is now secure.

4






















PART LIST

<p>A</p>  <p>1 pc</p>	<p>B</p>  <p>1 pc</p>	<p>C</p>  <p>1 pc</p>
<p>D</p>  <p>1 pc</p>	<p>E</p>  <p>1 pc</p>	<p>F</p>  <p>2 pcs</p>
<p>G</p>  <p>1 pc</p>	<p>H</p>  <p>1 pc</p>	<p>I</p>  <p>1 pc</p>
<p>J</p>  <p>1 pc</p>	<p>K</p>  <p>1 pc</p>	<p>L</p>  <p>1 pc</p>
<p>M</p>  <p>1 pc</p>	<p>N</p>  <p>1 pc</p>	<p>O</p>  <p>2 pcs</p>
<p>P</p>  <p>2 pcs</p>	<p>Q</p>  <p>1 pc</p>	<p>R</p>  <p>1 pc</p>
<p>S</p>  <p>2 pcs</p>		



HARDWARE LIST

<p>①</p>  <p>M6x28 26 pcs</p>	<p>②</p>  <p>Ø12 26 pcs</p>	<p>③</p>  <p>M6x40 50 pcs</p>	<p>④</p>  <p>M6x30 12 pcs</p>
<p>⑤</p>  <p>M4x40 3 pcs</p>	<p>⑥</p>  <p>2 pcs</p>	<p>⑦</p>  <p>4 pcs</p>	<p>⑧</p>  <p>M3.5x12 40 pcs</p>
<p>⑨</p>  <p>56-100cm 2 pcs</p>	<p>⑩</p>  <p>2 pcs</p>	<p>⑪</p>  <p>2 pcs</p>	<p>⑫</p>  <p>M4x12 8 pcs</p>
<p>⑬</p>  <p>1 pc</p>	<p>⑭</p>  <p>M4 1 pc</p>	<p>⑮</p>  <p>M6x19 8 pcs</p>	



STEP 1





STEP 2



STEP 3





STEP 4





STEP 5



Keep the holes of the
Part P toward this
direction as shown





STEP 6




STEP 7




STEP 8





STEP 9





STEP 10



STEP 11




STEP 12



STEP 13


②  x4



STEP 14

③  x4


④  x4





STEP 15



STEP 16





STEP 17




Keep the holes of the
Part A toward this
direction as shown


STEP 18




STEP 19




STEP 20




STEP 21






STEP 22




STEP 23




- ③  x2
- ⑦  x2
- ⑧  x16



STEP 24








- ⑮  x8

There are 6 heights for the shelf to be adjusted as you need.


STEP 25

Pole Installation




9		x2
10		x2
11		x2
12		x8

Note: Twist the expandable pole clockwise to tighten. anticlockwise to loosen.



TIPPING RESTRAINT HARDWARE



Note: We have included three Tipping Restraint Hardware set for this Unit. When properly installed, this restraint can provide protection against the unexpected tipping of the Unit due to small tremors, bumps or climbing. We strongly recommend mounting this hardware to a wall stud and your Unit.

Note: You must install the Tipping Restraint Hardware with the unit in use to prevent any accidents or damage to the unit.

