



Item: BR2DSLNS

Assembly Instructions




General Assembly Guidelines


- I. Ensure that all parts and hardware are available before beginning assembly.
- II. Follow each step carefully to ensure the proper assembly of this product.
- III. Two people are recommended for ease in the assembly of this product.
- IV. The three main types of hardware used to assemble this product are wood dowels, screws and bolts.
- V. A Phillips head screwdriver and hammer is required for the assembly of this product.



- V I. Power tools should not be used to assemble this product.












Parts List




Part #	Description	Qty
5	Right crossbeam foot	02 pcs
6	Left crossbeam foot	02 pcs
7	Back panel	01 pc
8	Foot	04 pcs
13	Drawer bottom	02 pcs
21	Top panel	01 pc
22	Left side panel	01 pc
23	Right side panel	01 pc

Part #	Description	Qty
24	Bottom panel	01 pc
25	Right drawer side	02 pcs
26	Left drawer side	02 pcs
27	Drawer runner	04 pcs
28	Drawer back	02 pcs
29	Upper drawer front	01 pc
30	Lower drawer front	01 pc

Hardware List


A		Ø8*30mm	Wooden dowel	38 pcs
B		Ø10*20mm	Wooden dowel	08 pcs
C		Ø4,0*25mm	Screw	12 pcs
D		Ø3,5*30mm	Screw	26 pcs
E		Ø4,0*40mm	Screw	14 pc
F		Ø10*10mm	Nail	14 pcs
G		Ø7*60mm	Screw	04 pcs
H		4mm	Hex Key	01 pc
I		Ø8*40mm	Wooden dowel	04 pcs



Hammer recommended
for assembly (not included)



Philips head screwdriver required
for assembly (not included)





Tape measure
required
for assembly
(not included)


*The hardware quantities listed above are required for proper assembly.
Some extra hardware may also have been included.*

Step 1


Attention to the
dowel length:
ø10*20mm





Insert wood dowel (B) into part 27.



Step 2





 Please assemble on
a clean soft surface
to avoid damage.





Insert Wooden dowel (A) into parts (5), (6), (22), (23), (25) and (26).

Step 3






Use screw (E) to attach parts (22, 23) to part (24)

Step 4





Use screw (D) to attach part (5) to part (8) and attach part (6) to part (8), do this step twice

Step 5



Attach leg to body.
Secure feet to the body from inside the unit with bolt (G) and hex key (H).
Use screw (E) to secure legs to body




Step 6



Attach part (21) to the body using screw (D)


Step 7

Name and address of the supplier and date of production.




Attach back panel (7) to the body using nails (F)

Step 8




Use screw (C) to attach part (27) to parts (22, 23)
Note: The extra holes in part (27) should face the top of parts (22, 23).

Step 9




Insert wood dowel (A) into the front hole in the drawer rail (27).


Step 10




Attach parts (25, 26) to part (29), insert panel (13),
Attach part (28) to parts (25) and (26) with with screws (D),
and Phillips head screwdriver..




Step 11



Attach parts (25, 26) to part (30), insert panel (13),
Attach part (28) to parts (25) and (26) with with screws (D),
and Phillips head screwdriver..




Step 12



Insert wood dowel (I) on the inside of
all drawers, with the drawer inside the unit
after having passed the wood dowel
that is in the drawer slide.
The dowel is not flush with the panel, it is a
little inside the drawer to help when you need
to remove the lock dowel to remove the drawer.





Assembly Complete!