




# Product Installation Instructions







**Ax1**




**Bx4**




**Cx2**




**Dx2**




**Ex1**




**Fx1**




**Gx1**




**Hx1**




**Ix1**




**Jx2**




**K1x1**




**K2x1**




**Lx1**




**Mx2**



**Nx1**
















**Ox3**




**1**


# Accessories list

①		Two in one screw (6x28mm)	50pcs +4pcs
②		Two in one nut (10x12mm)	50pcs +4pcs
③		Wood chipping (6x30mm)	14pcs +2pcs
④		Screw (6x33mm)	1pcs
⑤		breathable lid	4pcs
⑥		Backboard card strip (1164mm)	1pcs
⑦		Fixing clip & screw (3x16mm)	8pcs +2pcs
⑧		Laminate Support Nail	12pcs +1pcs
⑨		Hinge & Screw (3.5x12mm)	36pcs +3pcs 6pcs
⑩		Cabinet door rebound device Screw (3x12mm)	3pcs 6pcs +1pcs
⑪		Handle & Screw (4x18mm)	3pcs +1pcs 3pcs
⑫		Wire Clamp	3pcs +1pcs
		AC/DC Adapter (12V=2.0A)	1pcs

Double-head screwdriver, use as required




1pcs




2

# Product structure decomposition




# Use parts ① and ②



Step 1




Step 2



Step 3





Use a screwdriver to lock in the direction of the "+" sign



Disassemble along the direction of "-" sign


Step 1




**B** x4


4


Step 2

②  x4





Step 3




②  x2




Step 4




Step 5





Step 6



2  x10



Step 7




Step 8




Step 9

2






x4

You can only install it this way.





You cannot install it this way.





9


Step 10




Step 11





Step 12

2  x2





Step 13

2  x2





Step 14

1  x4





Step 15


2  x4






Step 16







# Step 17



- 1  x10
- 10  x2  x4



# Step 18





- 1  x10
- 10  x1  x2

# Step 19

Detach part 5 and attach it to the backplate.




# Step 20




# Step 21


2





Setting the cabinet upright requires two people together.





# Step 22




- ③  x4
- ⑥  x1

Place the "L" board, Backboard card strip, and "L" board in order




# Step 23

2





x10

After installing the panel, thread the wires through the backplate hole.




Step 24





8  x12








Step 25



Step 26


- |    |   |   |
|----|---|---|
| 9  |  |  |
|    | x6  | x12   |
| 11 |  |  |
|    | x3  | x3  |






x3

Step 27

9




x8




First lock the elliptical hole  
then lock the fixed hole

Step 28



Turning this screw can effectively adjust the size of the door gap.




Adjust hole control the up and down height of the door


Turn this screw to adjust the door panel to be flat with the side panel.

Step 29

9






x16






Repeat the door panel installation steps.

Step 30

7  x8




Step 31




# Step 32

12






x3



Pull out the power cord inside the cabinet.

Step 33




## User's Guide

Thank you for purchasing this product. To use this product, please plug it into a 12V DC power supply. Please use if the product works normally after connecting to power.

## Introduction

The box is an intelligent controller. It has 1 USB port and 1 type-C port and can distribute the current output up to 5V DC-2A. With 2 touch buttons, it can turn ON/OFF the light, change light colors, and adjust the light luminance.

## Product Show



### ATTENTION PLEASE

1. If there is no touch response suddenly, Re-plug the power to reset the touch static electricity.
2. If bubbles appear on the panel, remove the protective film.

## Operation



This touch button is used to turn on/off, change colors, and adjust brightness.

A. Short touch -> lighting on -> short touch -> change light color -> short touch -> change light color -> short touch -> lighting off. B. Long touch -> adjust the luminance



This touch button is used to turn on/off the induction function.

A . Short touch to turn on the induction function. It can auto-turn on the light when people are close to the controller in 1 meters. It can auto power off the light when the body is far away from the controller after 30 seconds.

B . Long touch to turn off the induction function.

C . Note: When you touch the light button to change the light modes, the induction function will automatically turn off. It is best to turn on this function after selecting the light color and adjusting the brightness you want.