





Installation & Assembly




Version:1.0




EN_IMPORTANT, RETAIN FOR FUTURE REFERENCE: READ CAREFULLY.


USING CAM LOCK AND QUICKFIT




EN_QUICKFIT: Tighten quickfit until shoulder is flush with panel. Do not overtighten or undertighten.



EN_CAM LOCK: When fitting cam lock, ensure starting position is correct before you insert connecting quickfit.





















EN_Quickfit head should be in the centre of the cam lock when the two panels are joined.
Cam lock should be inserted before quickfit.



























EN_Turn cam lock clockwise to tighten.

PACKING DETAILS

NO.	PARTS	QTY	SPARE
①		x1	
②		x1	
③		x1	
④		x1	
⑤		x1	
⑥		x1	
⑦		x2	
⑧		x2	
⑨		x2	
⑩		x2	
⑪		x1	

NO.	PARTS	QTY	SPARE
⑫		x4	
⑬		x8	
⑭		x4	
⑮		x1	
⑯		x1	
⑰		x1	
	 Hardware Kit		





 <p>A x20 Ø6x35mm +2(spare)</p>	 <p>B x20 Ø15x10mm +2(spare)</p>	 <p>C x24 Ø6x30mm +2(spare)</p>	 <p>D x15 Ø4x35mm +1(spare)</p>	 <p>E x64 Ø3.5x12mm +5(spare)</p>	 <p>F x8</p>
 <p>G x8</p>	 <p>H x8</p>	 <p>I x4</p>	 <p>J x4</p>	 <p>K x4</p>	 <p>L x4</p>
  <p>M x2 Ø4x14mm</p> <p>M-1 M-2</p>	 <p>N x2 Ø6x30mm</p>	 <p>O x8 15mm +2(spare)</p>	 <p>P x4</p>	 <p>Q x16 Ø4x30mm +1(spare)</p>	 <p>R x4</p>
 <p>S x1 M5</p>	 <p>T x1</p>	  <p>U x6 Ø3x16mm +1(spare)</p> <p>U-1 U-2</p>			

A x4


E x4

F x4





E x4

F x4




A x2

M x2




M-1

M-2




C x2

D x2




B x2

C x2




B x4


C x4




D x5




07



A x8





08



x2


B x8

P x4





I x4

J x4




C x4

Q x14



Q x2




T x1





You can rotate part#T to level the cabinet with the ground.

C x6

D x6




A x6




B x6




C x6






U x6




U-1




U-2




D x2



N x2




WALL



(1)x2

First, use a ruler to measure the approximate height of the product on the wall, and then mark it with a pen.


WALL



(2)x2

Then use a tape drill to make holes in the wall that are suitable for the product screws.


WALL



(3)x2


Then, put the expansion bolt into the hole

WALL



(4)x2

Finally, pass the matching screws through the "anti-rewind" and tighten them to fix them on the wall.











E x48

K x4

L x4

R x4



x4


G x8




H x8




S x1




Please do not forcefully lock the installation screws to the maximum limit to avoid damaging the side panel.






**Need Two or More
People To Complete**





E x4





OR



E x4




OR



○ x8

23



Done

